


KUKA

KUKA System Technology

KUKA Roboter GmbH

KUKA.LaserTech 3.0

For KUKA System Software 8.2



Issued: 31.05.2012

Version: KST LaserTech 3.0 V2 en

© Copyright 2012

KUKA Roboter GmbH
Zugspitzstraße 140
D-86165 Augsburg
Germany

This documentation or excerpts therefrom may not be reproduced or disclosed to third parties without the express permission of KUKA Roboter GmbH.

Other functions not described in this documentation may be operable in the controller. The user has no claims to these functions, however, in the case of a replacement or service work.

We have checked the content of this documentation for conformity with the hardware and software described. Nevertheless, discrepancies cannot be precluded, for which reason we are not able to guarantee total conformity. The information in this documentation is checked on a regular basis, however, and necessary corrections will be incorporated in the subsequent edition.

Subject to technical alterations without an effect on the function.

Translation of the original documentation

KIM-PS5-DOC

| | |
|----------------|--------------------------------|
| Publication: | Pub KST LaserTech 3.0 (PDF) en |
| Bookstructure: | KST LaserTech 3.0 V2.1 |
| Version: | KST LaserTech 3.0 V2 en |

Contents

| | | |
|----------|---|-----------|
| 1 | Introduction | 7 |
| 1.1 | Target group | 7 |
| 1.2 | Industrial robot documentation | 7 |
| 1.3 | Representation of warnings and notes | 7 |
| 1.4 | Terms used | 8 |
| 1.5 | Trademarks | 8 |
| 2 | Product description | 9 |
| 2.1 | Overview of KUKA.LaserTech | 9 |
| 2.2 | Laser power and path velocity | 9 |
| 3 | Safety | 11 |
| 4 | Installation | 13 |
| 4.1 | System requirements | 13 |
| 4.2 | Installing or updating KUKA.LaserTech | 13 |
| 4.3 | Uninstalling LaserTech | 14 |
| 5 | Operation | 15 |
| 5.1 | Menus | 15 |
| 5.2 | Basic laser function status keys | 15 |
| 5.3 | LaserCut status keys | 16 |
| 6 | Start-up and configuration | 19 |
| 6.1 | Laser program | 19 |
| 6.2 | Configuring gas types for inline forms | 19 |
| 6.3 | Configuring the inputs/outputs for gases and other properties | 20 |
| 6.4 | Configuring the pilot laser | 21 |
| 6.5 | Modifying maximum values for ramp times | 22 |
| 7 | Programming | 23 |
| 7.1 | Programming with spline | 23 |
| 7.2 | Programming tips for KUKA.LaserTech | 23 |
| 7.3 | Programming laser functions | 25 |
| 7.3.1 | Inline form “ Activate process ” | 25 |
| 7.3.2 | Inline form “ Switch process ” | 27 |
| 7.3.3 | Inline form “ Deactivate process ” | 28 |
| 7.3.4 | Inline form “ Step seam ” | 29 |
| 7.3.5 | Inline form “ Laser test pulse ” | 31 |
| 7.3.6 | Option window “Media setting” – activating laser welding | 31 |
| 7.3.7 | Option window “Media setting” – switching laser welding | 32 |
| 7.3.8 | Option window “Media setting” – deactivating laser welding | 33 |
| 7.3.9 | Option window “ Media data ” – Step seam | 34 |
| 7.3.10 | Option window “ Laser data ” – “ Activate process ” | 35 |
| 7.3.11 | Option window “ Laser data ” – “ Switch process ” | 36 |
| 7.3.12 | Option window “ Laser data ” – “ Deactivate process ” | 36 |
| 7.3.13 | Option window “ Laser data ” – “ Step seam ” | 37 |
| 7.3.14 | Option window “ Step parameters ” | 38 |
| 7.3.15 | Option window “ Laser data ” – “ Laser test pulse ” | 38 |

| | | |
|-----------|---|-----------|
| 7.4 | Programming laser control | 39 |
| 7.4.1 | Inline form “ Initialize laser ” | 39 |
| 7.4.2 | Inline form “ Enable laser ” | 39 |
| 7.4.3 | Inline form “ Laser off ” | 40 |
| 7.4.4 | Inline form “ Laser request ” | 40 |
| 7.4.5 | Option window “Gas selection” – laser welding | 41 |
| 7.4.6 | Option window “Gas selection” – laser cutting | 42 |
| 7.4.7 | Option window “Laser network” – Initialize laser | 42 |
| 7.5 | Programming media control | 43 |
| 7.5.1 | Inline form “ Switch gas ” | 43 |
| 7.5.2 | Inline form “ Initialize gas ” | 43 |
| 7.5.3 | Inline form “ Cut wire ” | 44 |
| 7.6 | Programming sensor control | 45 |
| 7.6.1 | Inline form “ Switch sensor ” | 45 |
| 7.6.2 | Inline form “ Sensor settings ” | 46 |
| 7.7 | Programming laser cutting | 47 |
| 7.7.1 | Inline form “ Rectangle ”, “ Slot ”, “ Hexagon ”, “ Circle ” | 47 |
| 7.7.2 | Option windows “Geometry data” and “Geo motion data” | 48 |
| 7.7.3 | Option window: Frames | 51 |
| 7.7.4 | Option window “ Media data ” – activating laser cutting | 52 |
| 7.7.5 | Option window “ Media data ” – switching laser cutting | 52 |
| 7.7.6 | Option window “ Media data ” – deactivating laser cutting | 53 |
| 7.7.7 | Option window “ Laser data ” – Rectangle, Slot, Hexagon, Circle | 53 |
| 7.7.8 | Option window “ Sensor parameters ” and “ Process parameters ” | 54 |
| 8 | Example programs | 57 |
| 8.1 | Example program: step seam | 57 |
| 8.2 | Example program: gas and laser welding functions | 58 |
| 8.3 | Example program: set piercing and cutting data | 59 |
| 8.4 | Example program: piercing function | 59 |
| 9 | Messages | 61 |
| 9.1 | Basic laser function messages | 61 |
| 9.2 | LaserCut messages | 65 |
| 9.3 | LaserWeld messages | 65 |
| 10 | Appendix | 67 |
| 10.1 | Configuration parameters: overview of inputs/outputs, interrupts, timers and cyclical flags | 67 |
| 10.2 | LaserTech configuration parameters | 69 |
| 10.2.1 | LaserTech: Outputs to the laser | 69 |
| 10.2.2 | LaserTech: Inputs from the laser | 70 |
| 10.2.3 | LaserTech: Outputs to the periphery | 71 |
| 10.2.4 | LaserTech: Inputs from the periphery | 72 |
| 10.2.5 | LaserTech: Other outputs | 72 |
| 10.2.6 | LaserTech: Process options | 72 |
| 10.2.7 | LaserTech: Process constants | 74 |
| 10.3 | LaserWeld configuration parameters | 75 |
| 10.3.1 | LaserWeld: Outputs to the wire feed system | 75 |
| 10.3.2 | LaserWeld: Inputs from the wire feed system | 76 |

| | | |
|-----------|--|-----------|
| 10.3.3 | LaserWeld: Process parameters | 76 |
| 10.4 | LaserCut configuration parameters | 77 |
| 10.4.1 | LaserCut: Outputs to the sensor | 77 |
| 10.4.2 | LaserCut: Inputs from the sensor | 78 |
| 10.4.3 | LaserCut: Process parameters | 78 |
| 11 | KUKA Service | 81 |
| 11.1 | Requesting support | 81 |
| 11.2 | KUKA Customer Support | 81 |
| | Index | 89 |

1 Introduction

1.1 Target group

This documentation is aimed at users with the following knowledge and skills:

- Advanced KRL programming skills
- Advanced knowledge of the robot controller system
- Advanced knowledge of the laser controller systems
- Knowledge of the other peripheral controller systems (e.g. distance controller)
- Knowledge of field bus interfaces



For optimal use of our products, we recommend that our customers take part in a course of training at KUKA College. Information about the training program can be found at www.kuka.com or can be obtained directly from our subsidiaries.

1.2 Industrial robot documentation

The industrial robot documentation consists of the following parts:

- Documentation for the manipulator
- Documentation for the robot controller
- Operating and programming instructions for the KUKA System Software
- Documentation relating to options and accessories
- Parts catalog on storage medium

Each of these sets of instructions is a separate document.

1.3 Representation of warnings and notes

Safety

These warnings are relevant to safety and **must** be observed.



DANGER These warnings mean that it is certain or highly probable that death or severe injuries **will** occur, if no precautions are taken.



WARNING These warnings mean that death or severe injuries **may** occur, if no precautions are taken.



CAUTION These warnings mean that minor injuries **may** occur, if no precautions are taken.



NOTICE These warnings mean that damage to property **may** occur, if no precautions are taken.



These warnings contain references to safety-relevant information or general safety measures. These warnings do not refer to individual hazards or individual precautionary measures.

Notes

These hints serve to make your work easier or contain references to further information.



Tip to make your work easier or reference to further information.

1.4 Terms used

| Term | Description |
|---------------|--|
| Cross Jet | Gas that keeps the lens of the laser free of dirt. |
| Laser program | Program executed in the laser controller. |
| Process gas | The process gas keeps the welding site free from oxygen, thereby protecting the seam against oxidation. |
| Root gas | Process gas that protects the seam against oxidation from beneath. Only relevant in the case of through-welding of the plate and if gas can be fed in from underneath. |


1.5 Trademarks

TruControl is a trademark of Trumpf.

2 Product description

2.1 Overview of KUKA.LaserTech

- Functions** KUKA.LaserTech is an add-on technology package with the following functions:
- Configuration and programming of laser applications
 - Configuration and programming of laser cutting applications
 - Configuration and programming of laser welding applications with/without filler wire

 The backwards movement option is deactivated when working with this technology package.

- Areas of application**
- Laser cutting
 - Laser welding
- KUKA.LaserTech supports the following systems:
- TRUMPF laser controllers
 - PRECITEC distance controllers (for laser cutting)

For information about adaptation for systems from other manufacturers, please contact KUKA Roboter GmbH. (>>> 11 "KUKA Service" Page 81)

- Communication** The robot controller communicates with the laser controller via a field bus.

2.2 Laser power and path velocity

KUKA.LaserTech regulates the laser power proportionally to the velocity of the robot. If the programmed robot velocity is not reached, the laser power is reduced accordingly.

The proportionality is restricted by the upper and lower power limits of the laser. The lower power limit of the laser is always > 0, as the laser power cannot be regulated down to 0.

Precondition for velocity-dependent laser power:

The parameter LSR_UsePwrVelCtrlId must be set to TRUE in the configuration.




Fig. 2-1: Relationship between velocity and laser power

- 1 Laser power in watts
- 2 Upper laser power limit
- 3 Lower laser power limit
- 4 Velocity in m/s

3 Safety

This documentation contains safety instructions which refer specifically to the software described here.

The fundamental safety information for the industrial robot can be found in the “Safety” chapter of the Operating and Programming Instructions for System Integrators or the Operating and Programming Instructions for End Users.



The “Safety” chapter in the operating and programming instructions must be observed. Death to persons, severe injuries or considerable damage to property may otherwise result.



The safety standards must be observed when working with the laser. Injuries or damage to property may otherwise result. For further information and specification of the laser class, please refer to the documentation of the laser manufacturer.




The safety measures of the laser system must be observed when wiring the system. In particular the EMERGENCY STOP circuit and operator safety must be wired correctly before this software is used. Injuries or damage to property may otherwise result. The safety measures of the laser system can be found in the documentation of the laser manufacturer.

4 Installation

4.1 System requirements

- Hardware**
- KR C4
 - KUKA field bus cards (Interbus or PROFIBUS)
 - Specific components for the application
- Software**
- KUKA System Software 8.2

4.2 Installing or updating KUKA.LaserTech

 It is advisable to archive all relevant data before updating a software package.


- Preparation**
- Copy software from CD to KUKA USB stick.
The software must be copied onto the stick with the file Setup.exe at the highest level (i.e. not in a folder).

NOTICE Recommendation: Use a KUKA stick. Data may be lost if any other stick is used.

- Precondition**
- “Expert” user group

- Procedure**
1. Connect the USB stick to the robot controller or smartPAD.
 2. In the main menu, select **Start-up > Install additional software**.
 3. Press **New software**. The entry **LaserTech** must be displayed in the **Name** column and drive **E:** or **K:** in the **Path** column.
If not, press **Refresh**.
 4. If the specified entries are now displayed, continue with step 5.
If not, the drive from which the software is being installed must be configured first:
 - Press the **Configuration** button. A new window opens.
 - Select a line in the **Installation paths for options** area.
Note: If the line already contains a path, this path will be overwritten.
 - Press **Path selection**. The available drives are displayed.
 - Select **E:**. (If stick connected to the robot controller.)
Or select **K:**. (If stick connected to the smartPAD.)
 - Press **Save**. The window closes again.

The drive only needs to be configured once and then remains saved for further installations.
 5. Mark the entry **LaserTech** and click on **Install**. Answer the request for confirmation with **Yes**.
 6. Confirm the reboot prompts with **OK**.
 7. Remove the stick.
 8. Reboot the robot controller.
On rebooting, a reminder is displayed about installing the LaserWeld and LaserCut options. If the reminder should not be displayed again, select **No longer ask**.

 During installation of LaserTech, the LaserWeld and LaserCut options are copied to the directory D:\KUKA_OPT. If required, the options must be installed separately from this directory.

LOG file A LOG file is created under C:\KRC\ROBOTER\LOG.

4.3 Uninstalling LaserTech



It is advisable to archive all relevant data before uninstalling a software package.

Precondition ■ “Expert” user group

Procedure

1. Select **Start-up > Install additional software** in the main menu. All additional programs installed are displayed.
2. Depending on which part of the technology package is to be uninstalled, select the corresponding entry:
 - LaserTech: select the entry **LaserTech**.
 - LaserWeld: select the entry **LaserWeld**.
 - LaserCut: select the entry **LaserCut**.
3. Press **Uninstall**. Reply to the request for confirmation with **Yes**. Uninstallation is prepared.
4. Reboot the robot controller. Uninstallation is resumed and completed.

LOG file A LOG file is created under C:\KRC\ROBOTER\LOG.

5 Operation

5.1 Menus

The following menus and commands are specific to this technology package:

Main menu:

- **Configuration > Status keys**
 - LaserTech
 - Laser Cut

Menu sequence **Commands > LaserTech**













- **Switching**
 - Activate process
 - Switch process
 - Deactivate process
 - Step seam
 - Laser test pulse
- **Control commands**
 - Initialize laser
 - Enable laser
 - Laser off
 - Laser request
- **Media control**
 - Switch gas
 - Initialize gas
 - Cut wire
- **Sensor control**
 - Switch sensor
 - Sensor settings
- **Cutting**
 - Rectangle
 - Slot
 - Hexagon
 - Circle

5.2 Basic laser function status keys

Select **Configuration > Status keys > LaserTech** in the main menu to display the status keys.

For safety reasons, the status keys are deactivated. To activate them, the enabling switch on the smartPAD must be pressed.

The status keys are not available in Automatic External mode.







| | Off | On | Inactive | Description |
|-------------|---|---|---|---|
| Laser |  |  |  | <p>The status key "Laser off" is displayed: the program is executed without laser power.</p> <p>The status key "Laser on" is displayed: the program is executed with laser power.</p> |
| Pilot laser |  |  |  | <p>Pressing "Pilot laser off" switches the pilot laser on.</p> <p>Pressing "Pilot laser on" switches the pilot laser off.</p> |
| Gas |  |  |  | <p>Pressing "Gas off" activates the process gas, root gas and Cross-Jet.</p> <p>Releasing the status key stops the flow of gas.</p> <p>Note: When process gas, root gas and CrossJet is activated, the high pressure of the emerging gas may result in injuries and in material damage to sensitive system components. Do not aim the gas at the body.</p> |
| Wire |  |  |  | <p>Pressing "Wire off" activates the wire feed.</p> <p>Releasing the status key stops the wire feed.</p> <p>Note: Welding wire emerging from the wire feeder can cause injuries to hands, face and eyes. Be sure to maintain a safe distance.</p> |





5.3 LaserCut status keys

Select **Configuration > Status keys > Laser Cut** in the main menu to display the status keys.

For safety reasons, the status keys are deactivated. To activate them, the enabling switch on the KCP must be pressed.

The status keys are not available in Automatic External mode.

| | Off | On | Inactive | Description |
|------------------|---|---|---|--|
| Sensor |  |  |  | <p>Status key "Sensor off" is displayed: the sensor functions are inactive.</p> <p>Status key "Sensor on" is displayed: the sensor functions are active.</p> |
| Distance control |  |  |  | <p>Pressing "Distance control Off" switches distance control on.</p> <p>Pressing "Distance control On" switches distance control off.</p> |

| | Off | On | Inactive | Description |
|--------------------|-----|---|---|--|
| Reference run | — |  |  | Pressing “Reference run on” starts a reference run. |
| Sensor in position | — |  |  | Pressing “Sensor in position” moves the sensor to the “programmed position”. |

6 Start-up and configuration

Overview

| Step | Description |
|------|---|
| 1 | Install and prepare the laser controller; in particular: prepare the laser program. (>>> 6.1 "Laser program" Page 19) |
| 2 | Configure the field bus between the robot controller and the laser controller in WorkVisual. |
| 3 | Calibrate the tool and base. |
| 4 | Configure gas types for inline forms. (>>> 6.2 "Configuring gas types for inline forms" Page 19) |
| 5 | Configure the inputs/outputs for gases and other properties. (>>> 6.3 "Configuring the inputs/outputs for gases and other properties" Page 20) |
| 6 | Configure the program number for the pilot laser. (>>> 6.4 "Configuring the pilot laser" Page 21) |
| 7 | Modify maximum values for ramp times (optional). (>>> 6.5 "Modifying maximum values for ramp times" Page 22) |

6.1 Laser program

On the laser controller there must be a laser program which can read in the parameters from an external controller (robot).



Fig. 6-1: Required laser program (example)

6.2 Configuring gas types for inline forms

Here the user defines how many types of which gas are to be available in the inline forms. The names displayed in the inline forms for the gases can also be changed.

A maximum of 12 types of gas can be configured.

Precondition ■ Windows interface (**Minimize HMI**)

Procedure

1. Open the file LsrTechILf.xml in the directory C:\KRC\TP\LaserTech\LIB.
2. Find the section for gases in the file.
 - Process gases: section ProcessGas
 - Root gases: section RootGas
 - Cutting gases: section CutGas
3. To change the name of a gas, modify the value of EnumValue Key.
To add a gas, copy a line that starts with EnumValue Key and paste it after the other lines. Renumber the values of KrlValue="..." and OrderID="...".



No modifications may be made other than those specified here!

4. Close the file by means of the **Close** icon and answer the request for confirmation with **Yes**. The file is saved.

Description

Excerpt from the ProcessGas section. The structure of the sections for the other gases is analogous.

```
...
<TechParam xsi:type="TechParamEnum" Name="ProcessGas" ...
  <EnumValues Max="12">
    <EnumValue Key="Gas1" KrlValue="1" OrderID="0"
VisibleStyle="Allways"/>
    <EnumValue Key="Gas2" KrlValue="2" OrderID="1"
VisibleStyle="Allways"/>
    <EnumValue Key="Gas3" KrlValue="3" OrderID="2"
VisibleStyle="Allways"/>
    <EnumValue Key="Gas4" KrlValue="4" OrderID="3"
VisibleStyle="Allways"/>
  </EnumValues>
</TechParam>
...
```

6.3 Configuring the inputs/outputs for gases and other properties**Precondition**

- "Expert" user group

Procedure

1. Open file.
 - Process gases: R1\TP\LaserTech\laser.dat
Open the Process Gas Settings fold.
 - Cutting gases: R1\TP\LASERCUT\lsc_main.dat
Open the Cut Gas Settings fold.
 - Root gases: R1\TP\LaserTech\laser.dat
Open the Root Gas Settings fold.
2. Edit file.
3. Close the file by means of the **Close** icon and answer the request for confirmation with **Yes**. The file is saved.

Description

Excerpt from the Process Gas Settings fold in the file laser.dat:

```
LSR_ProcGAS[1]={OUT_NR 430,IN_NR 1025,ANA_GAS_OUT TRUE,
ANA_GAS_IN TRUE,ExtILf FALSE,ANA_MAX_VALUE 30.0,GAS_NAME[] "NONE"}
```

The structure of the folds in the other files is analogous. The excerpt shows the default values for the properties.

"Proportional Gas Valve" = FALSE

| Element | Description |
|---------------|--|
| OUT_NR | Number of the digital output that is used to activate the gas |
| IN_NR | Number of the digital input that is used to indicate that the gas has been activated |
| ANA_GAS_OUT | Only FALSE meaningful. |
| ANA_GAS_IN | The currently measured gas pressure is returned to this analog channel. |
| ExtIf | TRUE : advanced monitoring. Not only IN_NR is polled, but also the actual analog value of the gas pressure. |
| ANA_MAX_VALUE | Value irrelevant. |
| GAS_NAME[] | Default value: " NONE " Modification of the default value does not have any effect. |

"Proportional Gas Valve" = TRUE

| Element | Description |
|---------------|--|
| OUT_NR | Number of the digital output that is used to activate the gas (The number of the analog channel is defined using the configuration parameter LSRO_GasPressure.) |
| IN_NR | Number of the digital input that is used to indicate that the gas pressure is OK (The number of the analog channel is defined using the configuration parameter LSRI_GasPressure.) |
| ANA_GAS_OUT | TRUE : this gas uses a proportional gas valve. FALSE : this gas does not use a proportional gas valve. |
| ANA_GAS_IN | The currently measured gas pressure is returned to this analog channel. |
| ExtIf | TRUE : advanced monitoring. Not only IN_NR is polled, but also the actual analog value of the gas pressure. |
| ANA_MAX_VALUE | Maximum gas pressure transferred by the laser controller. If a higher value is set in the inline form, the lower value set here nonetheless applies. Unit: bar. Value must be greater than 0.0. |
| GAS_NAME[] | Default value: " NONE " Modification of the default value does not have any effect. |

6.4 Configuring the pilot laser

Here the program number is defined that is to be selected internally when the pilot laser is switched on using the status key. The program number must be present in the laser controller.

Precondition ■ "Expert" user group

- No program is selected.

Procedure

1. Open the file laser.dat in the directory R1\TP\LaserTech.
2. Open the **Temporary Process Setting** fold. In the following declaration, specify the desired program number for the element LSR_PRG.

```
DECL GLOBAL LSR_PWR_T LSR_LsrPilotSet={LSR_MAX_PWR 2000,  
LSR_MIN_PWR 1, LSR_PRG 20,LSR_RAISE_TIME 1,LSR_DROP_TIME 1}
```

In this example, laser program 20 is selected (LSR_PRG 20). In order to be able to use the pilot laser, there must be a program with the number 20 on the laser controller.



The correct fiber number must be entered in the laser program that is selected here. Otherwise it is possible that the pilot laser will not be visible.

Further settings in the laser controller software must be observed.

3. Close the file by means of the **Close** icon and answer the request for confirmation with **Yes**. The file is saved.

6.5 Modifying maximum values for ramp times

Description

The ramp time when switching on (Laser power rise time) is programmed in the option window **Laser data – Activate process**.

(>>> 7.3.10 "Option window "Laser data" – "Activate process"" Page 35)

The ramp time when switching over (Laser power switching time) is programmed in the option window **Laser data – Switch process**.

(>>> 7.3.11 "Option window "Laser data" – "Switch process"" Page 36)

The ramp time when switching off (Laser power drop time) is programmed in the option window **Laser data – Deactivate process**.

(>>> 7.3.12 "Option window "Laser data" – "Deactivate process"" Page 36)

The maximum values can be modified in the registry.

Procedure

1. Press the Windows **Start** button and select **Run...**
2. In the **Open** box, enter "regedit" and press **OK**. The **Registry editor** window opens.
3. Select the following folder under "HKEY_CURRENT_USER\Software\VB and VBA Program Settings\KUKATPLASER" in the tree structure:
 - LSR_DROP_TIME (for ramp time when switching off)
 - LSR_RAISE_TIME (for ramp time when switching on)
4. Click on the parameter **Max** and select **Change**.
5. Enter the desired value and confirm it by pressing **OK**.

7 Programming

NOTICE

Following creation of a laser program or modification of laser and motion commands, the program sequence, the actual switching points of the laser and the periphery must be checked. Damage to the system may otherwise result.

7.1 Programming with spline

Overview

The overview shows which LaserTech commands can be used in spline blocks.

| Command | Usable in spline block? |
|---|-------------------------|
| Activate process | Yes |
| Switch process | Yes |
| Deactivate process | Yes |
| Step seam | Yes |
| Laser test pulse | No |
| Initialize laser | No |
| Enable laser | Yes |
| Laser off | No |
| Laser request | No |
| Switch gas | Yes |
| Initialize gas | No |
| Cut wire | No |
| Switch sensor | Yes |
| Sensor settings | Yes |
| Rectangle, Slot, Hexagon, Circle | No |

7.2 Programming tips for KUKA.LaserTech

Ramp times

- To be able to execute ramps, the parameter LSR_RampOption must be set to TRUE.
(>>> 10.2.6 "LaserTech: Process options" Page 72)
- The ramp time when switching on (Laser power rise time) is programmed in the option window **Laser data – Activate process**.
(>>> 7.3.10 "Option window "Laser data" – "Activate process"" Page 35)
- The ramp time when switching over (Laser power switching time) is programmed in the option window **Laser data – Switch process**.
(>>> 7.3.11 "Option window "Laser data" – "Switch process"" Page 36)
- The ramp time when switching off (Laser power drop time) is programmed in the option window **Laser data – Deactivate process**.
(>>> 7.3.12 "Option window "Laser data" – "Deactivate process"" Page 36)
- The maximum values in the option windows can be modified in the registry.
(>>> 6.5 "Modifying maximum values for ramp times" Page 22)

Delay times

Procedure:

1. Program weld seams.
2. Determine the delay times empirically.

Set the following parameters according to these times:

- LSR_ShutterDelayConst
- LSR_ShutterOn
- LSR_ShutterOff

(>>> 10.2.6 "LaserTech: Process options" Page 72)

3. For the other weld velocities, adapt the switching points by means of the Path specification in the inline forms.

Parameter values:

The delay times are defined using the following parameters:

- Delay time when switching on = LSR_ShutterDelayConst + LSR_ShutterOn
- Delay time when switching off = LSR_ShutterDelayConst + LSR_ShutterOff
- Delay time when switching over = LSR_ShutterDelayConst - LSR_ShutterOn



These parameters are only used to compensate for delay times. They must not be used to offset switching points.

NOTICE

If laser programs are already present and the delay times are changed, this can cause the activation and deactivation points of the laser to be shifted so far that damage to the device or other system components can result. Check existing programs following a modification.

Example 1

Required delay:

- When switching on: 80 ms
- When switching off: 50 ms
- When switching over: 20 ms

Set parameters:

- LSR_ShutterDelayConst = 50
- LSR_ShutterOn = 30
- LSR_ShutterOff = 0

Example 2

Required delay:

- When switching on: 80 ms
- When switching off: 50 ms
- When switching over: 0 ms

If the delay when switching over is to be 0 ms, LSR_ShutterDelayConst and LSR_ShutterOn must always have the same value.

Set parameters:

- LSR_ShutterDelayConst = 40
- LSR_ShutterOn = 40
- LSR_ShutterOff = 10

Standstill monitoring

If the robot is stationary and the laser power is active, the shutter automatically closes after a defined time. The time is defined via the parameter LSR_Stop_InspectionTime. The purpose is to prevent the laser from burning through the material.

If welding is to be carried out for longer at a specific position, i.e. without robot motion, the value of `LSR_Stop_InspectionTime` must be increased.

(>>> 10.2.6 "LaserTech: Process options" Page 72)

NOTICE If the value of `LSR_Stop_InspectionTime` is changed or if the option is deactivated, this can result in damage to the system.

If a test pulse is generated using the instruction **Laser test pulse**, the parameter `LSR_Stop_InspectionTime` is not active.

- Switching points**
- Program switching points in phases in which the velocity is as constant as possible.
 - If a switching action is to be carried out before the taught point, the approximate positioning radius must be selected in such a way that the action is executed in the approximate positioning range of the point.
- Circles**
- To generate full circles, it is advisable not to teach the coordinates, but to calculate them.
 - If the KUKA.ExpertTech technology package is available, use the specification **CA** for the circular angle.

7.3 Programming laser functions

7.3.1 Inline form "Activate process"

- Call**
- Select the menu sequence **Commands > LaserTech > Switching > Activate process**.

Description This instruction switches the laser on.

i This instruction refers to the next motion instruction in the program. This motion instruction must be a CP motion. There must be no instructions triggering an advance run stop between the laser instruction and the motion instruction.

The CP motion to the laser activation position is generally approximated. In the case of exact positioning to the point, the laser is aimed at the point for longer than in the case of approximate positioning. This means that more energy is directed onto the point than is generally desirable.

If the CUT application is selected, the piercing and cutting data for laser cutting can optionally be defined.

If the piercing and cutting data are defined, the instruction calls a piercing function that implicitly activates the distance sensor. In this case, the instruction replaces the instruction **Switch sensor**.

(>>> 7.6.1 "Inline form "Switch sensor"" Page 45)




Fig. 7-1: Inline form "Activate process" (with Weld)




Fig. 7-2: Inline form “Activate process” (with Cut)

| Item | Description |
|------|---|
| 1 | <p>Selects an application.</p> <ul style="list-style-type: none"> ■ [Empty box]: Only displayed if LaserWeld is not installed. ■ WELD: Laser welding (with wire feed) ■ CUT: Laser cutting |
| 2 | <p>Shifts the activation point of the laser.</p> <ul style="list-style-type: none"> ■ -100 ... 100 mm <p>Note: If the activation point is shifted to the wrong point, this can result in damage to the device or other system components.</p> |
| 3 | <p>Name for the media data (name freely definable)</p> <p>Touch the arrow to edit the data. The corresponding option window is opened.</p> <ul style="list-style-type: none"> ■ For the applications [Empty box] and WELD: (>>> 7.3.6 "Option window “Media setting” – activating laser welding" Page 31) ■ For the application CUT: (>>> 7.7.4 "Option window “Media data” – activating laser cutting" Page 52) |
| 4 | <p>Name for the laser data (name freely definable)</p> <p>Touch the arrow to edit the data. The corresponding option window is opened.</p> <p>(>>> 7.3.10 "Option window “Laser data” – “Activate process”" Page 35)</p> |
| 5 | <p>Only relevant for WELD application:</p> <p>Use of filler wire</p> <ul style="list-style-type: none"> ■ Check box active: use filler wire. ■ Check box not active: do not use filler wire. |
| 6 | <p>Only relevant for CUT application:</p> <p>Name for the piercing and cutting data (name freely definable)</p> <p>Touch the arrow to edit the data. The corresponding option window is opened.</p> <p>(>>> 7.7.8 "Option window “Sensor parameters” and “Process parameters”" Page 54)</p> <p>This box can be displayed or hidden using the Add Cut and Rem Cut buttons.</p> |

i If the gas is activated with the **Switch gas** instruction before the **Activate process** instruction and the setting “Continuous” is activated, the robot controller ignores the media data of the **Activate process** instruction (“Gas pressure” and “Gas preflow time”).
 (>>> 7.5.1 "Inline form “Switch gas”" Page 43)
 If there is no preceding **Switch gas** instruction with the setting “Continuous”, the gas is activated by the **Activate process** instruction.

7.3.2 Inline form “Switch process”

Call ■ Select the menu sequence **Commands > LaserTech > Switching > Switch process**.

Description This instruction is used to modify the weld parameters within a weld path. The monitoring functions of the laser and weld media remain active following this instruction. If the application WELD is selected, the wire is fed further.

i This instruction refers to the next motion instruction in the program. This motion instruction must be a CP motion. There must be no instructions triggering an advance run stop between the laser instruction and the motion instruction.




Fig. 7-3: Inline form “Switch process”

| Item | Description |
|------|--|
| 1 | Selects an application. <ul style="list-style-type: none"> ■ [Empty box]: Only displayed if LaserWeld is not installed. ■ WELD: Laser welding (with wire feed) ■ CUT: Laser cutting |
| 2 | Shifts the switching point of the laser. <ul style="list-style-type: none"> ■ -100 ... 100 mm |
| 3 | Name for the media data (name freely definable) Touch the arrow to edit the data. The corresponding option window is opened. <ul style="list-style-type: none"> ■ For the applications [Empty box] and WELD: (>>> 7.3.7 "Option window “Media setting” – switching laser welding" Page 32) ■ For the application CUT: (>>> 7.7.5 "Option window “Media data” – switching laser cutting" Page 52) |

| Item | Description |
|------|---|
| 4 | Name for the laser data (name freely definable) Touch the arrow to edit the data. The corresponding option window is opened. (>>> 7.3.11 "Option window "Laser data" – "Switch process" Page 36) |
| 5 | Only relevant for WELD application: Use of filler wire <ul style="list-style-type: none"> ■ Check box active: use filler wire. ■ Check box not active: do not use filler wire. |

i If the **Switch process** instruction is preceded by a **Switch gas** instruction with the setting "Continuous", the robot controller ignores the parameters in the media set of the **Switch process** instruction ("Gas pressure" and "Gas preflow time").
(>>> 7.5.1 "Inline form "Switch gas"
Page 43)

7.3.3 Inline form "Deactivate process"

Call ■ Select the menu sequence **Commands > LaserTech > Switching > Deactivate process**.

Description This instruction switches off the laser power and terminates the laser program. The laser is not switched off.

If the gas has been activated earlier in the program with the **Switch gas** instruction and the setting "Continuous", the robot controller ignores the media data of the **Deactivate process** instruction ("Gas pressure" and "Gas postflow time").

The gas must be deactivated with the **Switch gas** instruction in such a case.

If there is no preceding **Switch gas** instruction with the setting "Continuous", the gas is deactivated by the **Deactivate process** instruction.

i This instruction refers to the next motion instruction in the program. This motion instruction must be a CP motion. There must be no instructions triggering an advance run stop between the laser instruction and the motion instruction.




Fig. 7-4: Inline form "Deactivate process" (with Weld)




Fig. 7-5: Inline form “Deactivate process” (with Cut)

| Item | Description |
|------|--|
| 1 | Selects an application. <ul style="list-style-type: none"> ■ [Empty box]: Only displayed if LaserWeld is not installed. ■ WELD: Laser welding (with wire feed) ■ CUT: Laser cutting |
| 2 | Shifts the end point. <ul style="list-style-type: none"> ■ -100 ... 100 mm |
| 3 | Name for the media data (name freely definable) Touch the arrow to edit the data. The corresponding option window is opened. <ul style="list-style-type: none"> ■ For the applications [Empty box] and WELD: (>>> 7.3.8 "Option window "Media setting" – deactivating laser welding" Page 33) ■ For the application CUT: (>>> 7.7.6 "Option window "Media data" – deactivating laser cutting" Page 53) |
| 4 | Name for the laser data (name freely definable) Touch the arrow to edit the data. The corresponding option window is opened. (>>> 7.3.12 "Option window "Laser data" – "Deactivate process"" Page 36) |
| 5 | Only relevant for WELD application: Use of filler wire <ul style="list-style-type: none"> ■ Check box active: use filler wire. ■ Check box not active: do not use filler wire. |
| 6 | <ul style="list-style-type: none"> ■ Check box active: The laser is enabled. ■ Check box not active: Not enabled. |
| 7 | Only relevant for CUT application: Distance sensor <ul style="list-style-type: none"> ■ Off: Distance sensor OFF ■ Hold: The distance sensor remains in the current position. ■ PrPos: The distance sensor goes to the programmed position. |

7.3.4 Inline form “Step seam”

Call

- Select the menu sequence **Commands > LaserTech > Switching > Step seam**.

Description

This instruction performs a step seam. The instruction cannot be used with laser welding or laser cutting.

i This instruction refers to the next motion instruction in the program. This motion instruction must be a CP motion. There must be no instructions triggering an advance run stop between the laser instruction and the motion instruction.

The step seam is canceled in the following cases:

- **Activate process** instruction
- **Deactivate process** instruction
- Exact positioning
- A smooth transition is made from a CP motion to a PTP motion.

i Step seams are only possible without filler wire.

i Step seams are velocity-dependent. If the velocity is modified, the seam must then be checked and optimized.




Fig. 7-6: Inline form "Step seam"

| Item | Description |
|------|--|
| 1 | Shifts the activation point of the laser. ■ -100 ... 100 mm |
| 2 | Execution of the instruction is brought forward in time or delayed. ■ -100 ... 100 ms |
| 3 | Name for the laser data (name freely definable) Touch the arrow to edit the data. The corresponding option window is opened. (>>> 7.3.13 "Option window "Laser data" – "Step seam" Page 37) |
| 4 | Name for the media data (name freely definable) Touch the arrow to edit the data. The corresponding option window is opened. (>>> 7.3.9 "Option window "Media data" – Step seam" Page 34) |
| 5 | Name for the step parameters (name freely definable) Touch the arrow to edit the data. The corresponding option window is opened. (>>> 7.3.14 "Option window "Step parameters" Page 38) |

7.3.5 Inline form “Laser test pulse”

Call ■ Select the menu sequence **Commands > LaserTech > Switching > Laser test pulse**.

Description This instruction generates a test pulse.

- The test pulse can be measured to test the laser power. (Precondition: T1 mode.)
- The test pulse can be executed several times to determine the focus of the optics. (Precondition: operating mode T1 or T2.)

NOTICE Not all monitoring functions are active with this instruction. Incorrect use can cause material damage. The instruction may only be used by trained personnel.




Fig. 7-7: Inline form “Laser test pulse”

| Item | Description |
|------|---|
| 1 | Select function. <ul style="list-style-type: none"> ■ Test: Test the laser power. ■ Focus: Determine the focus of the optics. |
| 2 | Name for the laser data (name freely definable) Touch the arrow to edit the data. The corresponding option window is opened. (>>> 7.3.15 "Option window “Laser data” – “Laser test pulse” Page 38) |
| 3 | Duration of the test pulse <ul style="list-style-type: none"> ■ 12 ... 20 000 ms |

7.3.6 Option window “Media setting” – activating laser welding




Fig. 7-8: Option window “Media setting: gas” – activating laser welding, without wire




Fig. 7-9: Option window “Media setting: wire” – activating laser welding, with wire

| Item | Description |
|------|--|
| 1 | Gas pressure ■ 0 ... 10 bar |
| 2 | Gas preflow time ■ 0 ... 25 s |
| 3 | Wirefeed ■ 0 ... 25 m/min |
| 4 | Minimum wire feed rate ■ 0 ... 15 m/min |
| 5 | Wirefeed delay ■ -30 ... 30 mm |

7.3.7 Option window “Media setting” – switching laser welding




Fig. 7-10: Option window “Media setting: gas” – switching laser welding, without wire




Fig. 7-11: Option window “Media setting: wire” – switching laser welding, with wire

| Item | Description |
|------|--|
| 1 | Gas pressure ■ 0 ... 10 bar |
| 2 | Wirefeed ■ 0 ... 25 m/min |
| 3 | Minimum wire feed rate ■ 0 ... 15 m/min |
| 4 | Wirefeed delay ■ -30 ... 30 mm |

7.3.8 Option window “Media setting” – deactivating laser welding




Fig. 7-12: Option window “Media setting: gas” – deactivating laser welding, without wire




Fig. 7-13: Option window “Media setting: wire” – deactivating laser welding, with wire

| Item | Description |
|------|-----------------------------------|
| 1 | Gas pressure ■ 0 ... 10 bar |
| 2 | Gas postflow time ■ 0 ... 25 s |
| 3 | Wirefeed delay ■ -30 ... 30 mm |

7.3.9 Option window “Media data” – Step seam




Fig. 7-14: Option window “Media data” – Step seam

| Item | Description |
|------|----------------------------------|
| 1 | Gas pressure ■ 0 ... 10 bar |
| 2 | Gas preflow time ■ 0 ... 25 s |

If the gas preflow time overlaps with the gas postflow time of the previous motion, the gas continues to flow without interruption.

7.3.10 Option window “Laser data” – “Activate process”




Fig. 7-15: Option window “Laser data” – “Activate process”

| Item | Description |
|------|---|
| 1 | Laser power at 100% velocity <ul style="list-style-type: none"> ■ 60 ... 6 000 W |
| 2 | Laser program number <ul style="list-style-type: none"> ■ 1 ... 200 |
| 3 | Laser power rise time Time that elapses after activation before the laser reaches full power <ul style="list-style-type: none"> ■ 1 ... 2 000 ms The maximum laser power rise time can be modified in the registry. (>>> 6.5 "Modifying maximum values for ramp times" Page 22) Note: The setting is only displayed if the parameter LSR_RampOption has the value TRUE. |

Precondition for velocity-dependent laser power:

The parameter LSR_UsePwrVelCtrlId must be set to TRUE in the configuration.

7.3.11 Option window “Laser data” – “Switch process”




Fig. 7-16: Option window “Laser data” – “Switch process”

| Item | Description |
|------|--|
| 1 | Laser power at 100% velocity <ul style="list-style-type: none"> ■ 60 ... 6 000 W |
| 2 | Laser power switching time Time that elapses after switching before the laser reaches full power <ul style="list-style-type: none"> ■ 1 ... 2 000 ms The maximum laser power switching time can be modified in the registry. (>>> 6.5 "Modifying maximum values for ramp times" Page 22) Note: The setting is only displayed if the parameter LSR_RampOption has the value TRUE. |

7.3.12 Option window “Laser data” – “Deactivate process”




Fig. 7-17: Option window “Laser data” – “Deactivate process”

| Item | Description |
|------|--|
| 1 | Power limit during deactivation <ul style="list-style-type: none"> ■ 60 ... 6 000 W |
| 2 | Laser power drop time Time taken after deactivation for the laser to decrease its power <ul style="list-style-type: none"> ■ 1 ... 2 000 ms The maximum laser power drop time can be modified in the registry. (>>> 6.5 "Modifying maximum values for ramp times" Page 22) Note: The setting is only displayed if the parameter LSR_RampOption has the value TRUE. |

7.3.13 Option window "Laser data" – "Step seam"




Fig. 7-18: Option window "Laser data" – "Step seam"

| Item | Description |
|------|--|
| 1 | Laser power at 100% velocity <ul style="list-style-type: none"> ■ 60 ... 6 000 W |
| 2 | Laser program number <ul style="list-style-type: none"> ■ 1 ... 200 |

7.3.14 Option window “Step parameters”




Fig. 7-19: Option window: Step parameters

| Item | Description |
|------|---|
| 1 | Length of the step seam <ul style="list-style-type: none"> 10 ... 10,000 mm |
| 2 | Number of steps <ul style="list-style-type: none"> 2 ... 500 |
| 3 | Length of a step <ul style="list-style-type: none"> 2 ... 50 mm |

7.3.15 Option window “Laser data” – “Laser test pulse”




Fig. 7-20: Option window “Laser data” – “Laser test pulse”

| Item | Description |
|------|--|
| 1 | Laser power for the test pulse <ul style="list-style-type: none"> 60 ... 6,000 W |
| 2 | Laser program number <ul style="list-style-type: none"> 1 ... 200 |

7.4 Programming laser control

7.4.1 Inline form “Initialize laser”

Call ■ Select the menu sequence **Commands > LaserTech > Control commands > Initialize laser**.

Description This instruction initializes the laser. The first laser instruction in the KRL program must always be **Initialize laser**.

This instruction triggers an advance run stop.




Fig. 7-21: Inline form “Initialize laser”

| Item | Description |
|------|---|
| 1 | <p>Selects an application.</p> <ul style="list-style-type: none"> ■ [Empty box]: Only displayed if LaserWeld is not installed. ■ WELD: Laser welding (with wire feed) ■ CUT: Laser cutting |
| 2 | <p>Defines whether the laser is to be allocated to the robot during initialization. Only relevant if the robot belongs to a laser network.</p> <ul style="list-style-type: none"> ■ True: Laser is allocated to the robot during initialization. ■ False: Laser is not allocated to a robot during initialization. |
| 3 | <p>Name for the defined gas types (name freely definable)</p> <p>Touch the arrow to select the gas type. The corresponding option window is opened.</p> <ul style="list-style-type: none"> ■ For the application WELD: (>>> 7.4.5 "Option window “Gas selection” – laser welding” Page 41) ■ For the application CUT: (>>> 7.4.6 "Option window “Gas selection” – laser cutting” Page 42) |
| 4 | <p>Name for the defined lasers (name freely definable)</p> <p>Touch the arrow to select the laser. The corresponding option window is opened.</p> <p>(>>> 7.4.7 "Option window “Laser network” – Initialize laser” Page 42)</p> |
| 5 | <p>Only relevant for WELD application:</p> <p>Use of filler wire</p> <ul style="list-style-type: none"> ■ Check box active: use filler wire. ■ Check box not active: do not use filler wire. |

7.4.2 Inline form “Enable laser”

Call ■ Select the menu sequence **Commands > LaserTech > Control commands > Enable laser**.

Description

This instruction can be used to enable the laser for use by other robots at the end of a path. It is only relevant if the robot belongs to a laser network.

The instruction has the following effects:

- The gas supply is shut off.
- The laser is enabled.

LSR Free

Fig. 7-22: Inline form “Enable laser”

7.4.3 Inline form “Laser off”

Call

- Select the menu sequence **Commands > LaserTech > Control commands > Laser off**.

Description

This instruction has the following effects:

- The laser is deactivated.
- The gas supply is shut off.
- The laser is enabled.
- The laser lamp is switched off.

NOTICE

This instruction should only be used if the laser is to be deactivated for a prolonged period.

LSR Off

Fig. 7-23: Inline form “Laser off”

7.4.4 Inline form “Laser request”

Call

- Select the menu sequence **Commands > LaserTech > Control commands > Laser request**.

Description

This instruction requests the laser via the signal LSRO_LsrRequest.

It is possible to program the robot controller to wait for the laser if the laser is allocated. To do so, use the instruction with **Allocate** (check box is activated).

The switching point for the instruction should be far enough before the next activation point to enable the robot to brake before the start of the seam to wait for allocation of the laser. Following allocation, the robot must be able to accelerate in order to reach the programmed velocity at the start of the seam. This is possible with the parameters **Path** and **Delay**.



This instruction refers to the next motion instruction in the program. This motion instruction must be a CP motion. There must be no instructions triggering an advance run stop between the laser instruction and the motion instruction.




Fig. 7-24: Inline form “Laser request”

| Item | Description |
|------|--|
| 1 | <p>The point at which the instruction is executed is shifted forwards or backwards.</p> <ul style="list-style-type: none"> ■ -2,000 ... 1,000 mm |
| 2 | <p>Execution of the instruction is brought forward in time or delayed.</p> <ul style="list-style-type: none"> ■ -2,000 ... 1,000 ms |
| 3 | <p>Laser Allocate</p> <ul style="list-style-type: none"> ■ Check box active: The robot controller accesses the laser if it is not allocated. If the laser is allocated, the robot stops. The robot controller waits for the laser to be assigned to it. ■ Check box not active: If the laser is allocated, the robot controller does not wait until the laser is assigned to it. |

7.4.5 Option window “Gas selection” – laser welding




Fig. 7-25: Option window “Gas selection” – laser welding

| Item | Description |
|------|--|
| 1 | <p>Select process gas.</p> <p>The range of values depends on how many gas types have been configured.</p> <p>(>>> 6.2 "Configuring gas types for inline forms" Page 19)</p> |
| 2 | <p>Select root gas.</p> <p>The range of values depends on how many gas types have been configured.</p> <p>(>>> 6.2 "Configuring gas types for inline forms" Page 19)</p> <p>Note: This selection box is only displayed if the configuration parameter Lsr_useRootGas is set to TRUE.</p> |

7.4.6 Option window “Gas selection” – laser cutting




Fig. 7-26: Option window “Gas selection” – laser cutting

| Item | Description |
|------|--|
| 1 | Select cutting gas. The range of values depends on how many gas types have been configured. (>>> 6.2 "Configuring gas types for inline forms" Page 19) |

7.4.7 Option window “Laser network” – Initialize laser




Fig. 7-27: Option window “Laser network” – Initialize laser

| Item | Description |
|------|--|
| 1 | Select laser number. ■ 1 ... 15 |
| 2 | Select light path number. ■ 1 ... 8 |
| 3 | Select robot number. ■ 1 ... 6 |

7.5 Programming media control

7.5.1 Inline form “Switch gas”

Call ■ Select the menu sequence **Commands > LaserTech > Media control > Switch gas**.

Description This instruction switches the gas on or off.




Fig. 7-28: Inline form “Switch gas”

| Item | Description |
|------|--|
| 1 | <p>Selects a gas.</p> <ul style="list-style-type: none"> ■ Proc_Gas: process gas ■ Root_Gas: root gas ■ Cut_Gas: cutting gas ■ CrossJet ■ All: all gases <p>Note: It is not possible to activate all gases simultaneously. All can only be used to deactivate the gases simultaneously.</p> |
| 2 | <p>Switches the selected gas on or off.</p> <ul style="list-style-type: none"> ■ ON: Switches the gas on. ■ OFF: Switches the gas off. <p>Note: The gas is only switched off if the laser is not active.</p> |
| 3 | <p>Gas pressure</p> <ul style="list-style-type: none"> ■ 0 ... 20 bar <p>This box is only displayed if the configuration parameter “Proportional Gas Valve” is set to TRUE.</p> |
| 4 | <p>Only relevant for ON:</p> <ul style="list-style-type: none"> ■ Continuous: The instruction applies until the next Switch gas instruction is programmed. Until then, the gas parameters (gas pressure, gas preflow time, gas postflow time) for the Activate process, Switch process and Deactivate process instructions are ignored. ■ Once: The gas parameters for the subsequent Activate process, Switch process and Deactivate process instructions in the program apply until a new gas is activated with the instruction Switch gas. |

7.5.2 Inline form “Initialize gas”

Call ■ Select the menu sequence **Commands > LaserTech > Media control > Initialize gas**.

Description This instruction is used to select the gases required for the process. The instruction must be used at least once in an application program. It must be placed before the **Initialize laser** instruction and before the first **Activate process** instruction.

Within a program, the instruction is used to change the type of gas. If there is a process gas active when the instruction is executed, the process gas is deactivated. The **Switch gas** instruction is then required to activate the gas.

i If the **Initialize gas** instruction is not used in a KRL program, the gas is automatically initialized with the **Initialize laser** instruction.



Fig. 7-29: Inline form “Initialize gas”

| Item | Description |
|------|--|
| 1 | Selects an application. <ul style="list-style-type: none"> ■ [Empty box]: Only displayed if LaserWeld is not installed. ■ WELD: Laser welding (with wire feed) ■ CUT: Laser cutting |
| 2 | Name for the defined gas types (name freely definable) Touch the arrow to select the gas type. The corresponding option window is opened. <ul style="list-style-type: none"> ■ For the application WELD: (>>> 7.4.5 "Option window “Gas selection” – laser welding" Page 41) ■ For the application CUT: (>>> 7.4.6 "Option window “Gas selection” – laser cutting" Page 42) |

7.5.3 Inline form “Cut wire”

Call ■ Select the menu sequence **Commands > LaserTech > Media control > Cut wire**.

Description To cut the welding wire to length reliably using a cutting device, the wire can be advanced a certain distance using this instruction. (Check box **Cut** is not active.)




Fig. 7-30: Inline form “Cut wire” (without Cut)

This instruction is used to cut the wire with the laser. (Check box **Cut** is active.)




Fig. 7-31: Inline form “Cut wire” (with Cut)

| Item | Description |
|------|---|
| 1 | Wire cutting with laser pulse <ul style="list-style-type: none"> ■ Check box active: Wire is cut with laser pulse. ■ Check box not active: Wire is not cut with laser pulse. |
| 2 | Velocity of the wire feed <ul style="list-style-type: none"> ■ 0 ... 25 m/min |
| 3 | Duration of the wire feed <ul style="list-style-type: none"> ■ 100 ... 3,000 ms |
| 4 | Laser program number <ul style="list-style-type: none"> ■ 1 ... 200 <p>This box is only displayed if the check box Cut is activated.</p> |
| 5 | Laser power for cutting the wire <ul style="list-style-type: none"> ■ 60 ... 60,000 W <p>This box is only displayed if the check box Cut is activated.</p> |
| 6 | Wire feed rate <ul style="list-style-type: none"> ■ 0 ... 25 m/min |
| 7 | Pulse duration for cutting the wire <ul style="list-style-type: none"> ■ 100 ... 3,000 ms |

7.6 Programming sensor control

7.6.1 Inline form "Switch sensor"

Call ■ Select the menu sequence **Commands > LaserTech > Sensor control > Switch sensor**.

Description This command is used to define the settings for the distance sensor.
Depending on the configuration parameter LSC_AnaCutDistance, the cutting distance is specified as an analog value or under program control.

- TRUE: Analog
- FALSE: program control

Procedure for InDLY > 0:

1. Tip compensation time 2 is taken into consideration.
2. Motion stop
3. The robot moves to the point specified by the value defined in LSC_SecDistance.
4. The wait time defined in InDLY expires.
5. The cutting gas is switched. The distance defined in the inline form is set.
6. The wait time defined in LSC_SecInDly expires.
7. The motion is resumed.

The instruction is also used to modify an existing cutting distance. In this case, LsrCutSensor = On, InDLY = 0 and the new distance are programmed.



Detailed information about the distance sensor and distance controller is contained in the PRECITEC documentation.




Fig. 7-32: Inline form “Switch sensor” (analog distance)




Fig. 7-33: Inline form “Switch sensor” (program-controlled distance)

| Item | Description |
|------|---|
| 1 | Distance sensor <ul style="list-style-type: none"> ■ On: Distance sensor ON ■ Off: Distance sensor OFF ■ Hold: The distance sensor remains in the current position. ■ PrPos: The distance sensor goes to the programmed position. |
| 2 | Piercing position after the end point of the motion. <ul style="list-style-type: none"> ■ 0 ... 4,000 ms |
| 3 | Cutting distance; unit: 1/10 mm <ul style="list-style-type: none"> ■ 1 ... 300 This box is only displayed if the configuration parameter LSC_AnaCutDistance is set to TRUE. |
| 4 | Number of the program in the sensor controller that regulates the cutting distance <ul style="list-style-type: none"> ■ 1 ... 3 |

7.6.2 Inline form “Sensor settings”

- Call**
- Select the menu sequence **Commands > LaserTech > Sensor control > Sensor settings**.

Description This instruction can be used to set the cutting and piercing data for laser cutting and call a piercing function. This piercing function implicitly switches the distance sensor on.




Fig. 7-34: Inline form “Sensor settings”

| Item | Description |
|------|--|
| 1 | Name for the piercing and cutting data (name freely definable) Touch the arrow to edit the data. The corresponding option window is opened. (>>> 7.7.8 "Option window "Sensor parameters" and "Process parameters"" Page 54) |

7.7 Programming laser cutting

7.7.1 Inline form "Rectangle", "Slot", "Hexagon", "Circle"

Call

- Select the menu sequence **Commands > LaserTech > Cutting**.

The following menu items are available:

- **Rectangle**
- **Slot**
- **Hexagon**
- **Circle**

Description

This command defines which pattern will be cut. Optionally, the cutting and piercing data for laser cutting can be defined.

If the piercing and cutting data are defined, the instruction calls a piercing function that implicitly activates the distance sensor. In this case, the instruction replaces the instruction **Switch sensor**.

(>>> 7.6.1 "Inline form "Switch sensor"" Page 45)

Every cutting pattern is executed as a spline motion.

NOTICE These instructions execute a calculated motion based on the parameters set in the option window. Incorrectly set parameters can result in damage to the system. Always carry out a test run after creating or modifying these instructions.

i To cut lines, a LIN motion command is used.




Fig. 7-35: Inline form "Rectangle"

| Item | Description |
|------|--|
| 1 | <p>Selects a pattern.</p> <ul style="list-style-type: none"> ■ LsrCutRect: Rectangle ■ LsrCutSlot: Slot ■ LsrCutHex: Hexagon ■ LsrCutCircle: Circle |
| 2 | <p>Name for the geometry data (name freely definable)</p> <p>Touch the arrow to edit the data. The corresponding option window is opened.</p> <p>(>>> 7.7.2 "Option windows "Geometry data" and "Geo motion data"" Page 48)</p> |
| 3 | <p>Name of the end point (name freely definable)</p> <p>Touch the arrow to edit the point data. The corresponding option window is opened.</p> <p>(>>> 7.7.3 "Option window: Frames" Page 51)</p> |
| 4 | <p>Velocity</p> <ul style="list-style-type: none"> ■ 0.01 ... 10 m/min |
| 5 | <p>Name for the media data (name freely definable)</p> <p>Touch the arrow to edit the data. The corresponding option window is opened.</p> <p>(>>> 7.7.4 "Option window "Media data" – activating laser cutting" Page 52)</p> |
| 6 | <p>Name for the laser data (name freely definable)</p> <p>Touch the arrow to edit the data. The corresponding option window is opened.</p> <p>(>>> 7.7.7 "Option window "Laser data" – Rectangle, Slot, Hexagon, Circle" Page 53)</p> |
| 7 | <p>Name for the piercing and cutting data (name freely definable)</p> <p>Touch the arrow to edit the data. The corresponding option window is opened.</p> <p>(>>> 7.7.8 "Option window "Sensor parameters" and "Process parameters"" Page 54)</p> <p>This box can be displayed or hidden using the Add Cut and Rem Cut buttons.</p> |

7.7.2 Option windows "Geometry data" and "Geo motion data"

Description

This option window is called from the following inline forms:

- **Rectangle**
- **Slot**
- **Hexagon**
- **Circle**

The meaning of the boxes depends on the pattern selected in the inline form.




Fig. 7-36: Option window "Geometry data"




Fig. 7-37: Option window "Geo motion data"

Rectangle

| Item | Description |
|------|---|
| 1 | Side length of 1st cut <ul style="list-style-type: none"> Positive values |
| 2 | Side length of 2nd cut <ul style="list-style-type: none"> Positive values |
| 3 | Orientation angle of the rectangle in the XY plane relative to the current base system <ul style="list-style-type: none"> 0° ... 360° |
| 4 | Area within the rectangle where initial piercing takes place <ul style="list-style-type: none"> 1 ... 4 |
| 5 | Initial cutting direction <ul style="list-style-type: none"> -1: to the left 1: to the right |
| 6 | Interval between laser switch-on and start of robot motion <ul style="list-style-type: none"> 0 ... 3000 ms |
| 7 | Acceleration Refers to the maximum value specified in the machine data. The maximum value depends on the robot type and the selected operating mode. |
| 8 | Approximation distance |

Slot

| Item | Description |
|------|---|
| 1 | Length of the long side The value must be greater than the length of the short side. |
| 2 | Length of the short side The value must be less than the length of the long side. |
| 3 | Orientation angle of the slot in the XY plane relative to the current base system ■ 0° ... 360° |
| 4 | Area within the slot where initial piercing takes place ■ 1 ... 4 |
| 5 | — — — |
| 6 | Interval between laser switch-on and start of robot motion ■ 0 ... 3000 ms |
| 7 | Acceleration Refers to the maximum value specified in the machine data. The maximum value depends on the robot type and the selected operating mode. |
| 8 | Approximation distance |

Hexagon

| Item | Description |
|------|---|
| 1 | Side length of hexagon ■ Positive values |
| 2 | — — — |
| 3 | Orientation angle of the hexagon in the XY plane relative to the current base system ■ 0° ... 360° |
| 4 | Area within the hexagon where initial piercing takes place ■ 1 ... 4 |
| 5 | Initial cutting direction ■ -1: to the left ■ 1: to the right |
| 6 | Interval between laser switch-on and start of robot motion ■ 0 ... 3000 ms |
| 7 | Acceleration Refers to the maximum value specified in the machine data. The maximum value depends on the robot type and the selected operating mode. |
| 8 | Approximation distance |

Circle

| Item | Description |
|------|---|
| 1 | Diameter of the circle ■ Positive values |
| 2 | Angle, if only an arc is being cut ■ Positive values |
| 3 | — — — |
| 4 | Area within the circle where initial piercing takes place ■ 1 ... 4 |

| Item | Description |
|------|---|
| 5 | Initial cutting direction <ul style="list-style-type: none"> ■ -1: to the left If an arc is cut , "-1" must be entered. ■ 1: to the right |
| 6 | Interval between laser switch-on and start of robot motion <ul style="list-style-type: none"> ■ 0 ... 3000 ms |
| 7 | Acceleration Refers to the maximum value specified in the machine data. The maximum value depends on the robot type and the selected operating mode. |
| 8 | Approximation distance |

7.7.3 Option window: Frames




Fig. 7-38: Option window: Frames

| Item | Description |
|------|--|
| 1 | Tool selection. <ul style="list-style-type: none"> ■ [1] ... [16] If True in the box ExternalTCP : workpiece selection. |
| 2 | Interpolation mode <ul style="list-style-type: none"> ■ False: The tool is mounted on the mounting flange. ■ True: The tool is a fixed tool. |

7.7.4 Option window “Media data” – activating laser cutting




Fig. 7-39: Option window “Media data” – activating laser cutting

| Item | Description |
|------|----------------------------------|
| 1 | Gas pressure ■ 0 ... 10 bar |
| 2 | Gas preflow time ■ 0 ... 25 s |

If the gas preflow time overlaps with the gas postflow time of the previous motion, the gas continues to flow without interruption.

7.7.5 Option window “Media data” – switching laser cutting




Fig. 7-40: Option window “Media data” – switching laser cutting

| Item | Description |
|------|--------------------------------|
| 1 | Gas pressure ■ 0 ... 10 bar |

7.7.6 Option window “Media data” – deactivating laser cutting




Fig. 7-41: Option window “Media data” – deactivating laser cutting

| Item | Description |
|------|---|
| 1 | Gas pressure <ul style="list-style-type: none"> ■ 0 ... 10 bar |
| 2 | Gas postflow time <ul style="list-style-type: none"> ■ 0 ... 25 s |

If the gas preflow time overlaps with the gas postflow time of the previous motion, the gas continues to flow without interruption.

7.7.7 Option window “Laser data” – Rectangle, Slot, Hexagon, Circle




Fig. 7-42: Option window “Laser data” – Rectangle, Slot, Hexagon, Circle

| Item | Description |
|------|---|
| 1 | Laser power at 100% velocity <ul style="list-style-type: none"> ■ 60 ... 6 000 W |
| 2 | Minimum power for control When power control is active, the set power corresponds to the power of a stationary robot. <ul style="list-style-type: none"> ■ 60 ... 6 000 W <p>Note: The setting is only displayed if the parameter LSR_UsePwrVelCtrlId has the value TRUE.</p> |

| Item | Description |
|------|---|
| 3 | Laser program number <ul style="list-style-type: none"> ■ 1 ... 200 |
| 4 | Laser power rise time Time that elapses after activation before the laser reaches full power <ul style="list-style-type: none"> ■ 1 ... 2 000 ms The maximum laser power rise time can be modified in the registry. (>>> 6.5 "Modifying maximum values for ramp times" Page 22) Note: The setting is only displayed if the parameter LSR_RampOption has the value TRUE. |

7.7.8 Option window “Sensor parameters” and “Process parameters”




Fig. 7-43: Option window: Sensor parameters

| Item | Description |
|------|---|
| 1 | Piercing distance (TCP of the sensor – component); unit: 1/10 mm <ul style="list-style-type: none"> ■ 0 ... 300 |
| 2 | Cutting distance; unit: 1/10 mm <ul style="list-style-type: none"> ■ 0 ... 300 |
| 3 | Piercing time <ul style="list-style-type: none"> ■ 0 ... 3,000 ms |
| 4 | Wait time after changing the cutting gas <ul style="list-style-type: none"> ■ 0 ... 3,000 ms |




Fig. 7-44: Option window “Process parameters”

| Item | Description |
|------|---|
| 5 | Cutting gas number <ul style="list-style-type: none"> ■ 0 ... 30 |
| 6 | Cutting gas pressure during cutting <ul style="list-style-type: none"> ■ 0 ... 30 bar |
| 7 | Laser power during cutting <ul style="list-style-type: none"> ■ 60 ... 6,000 W |

8 Example programs

8.1 Example program: step seam



The velocity of the laser must be kept constant until the switching point is reached. Otherwise it is possible that the laser may switch before or after the planned switching point.

Program

```

1 DEF step( )
2 INI
3 PTP HOME Vel= 100 % DEFAULT
4 PTP Start CONT Vel=100 % PDAT0 Tool[1] Base[0]
5 LSR WELD Allocation=True Gas: GasDef LSN: LSNDef
6 LIN P1 CONT Vel=0.2 m/s CPDAT1 Tool[1] Base[0]
7 GasSwi Proc_Gas ON
8 GasSwi CrossJet ON Haltend
9 LIN P2 CONT Vel=0.2 m/s CPDAT2 Tool[1] Base[0]
10 LSR StepOn Path=0 mm Dly=0 ms LSet=LS22 SSet=SP3
11 LIN P3 CONT Vel=0.1 m/s CPDAT3 Tool[1] Base[0]
12 LIN P4 CONT Vel=0.1 m/s CPDAT4 Tool[1] Base[0]
13 LSR WELD End Path=0 mm Min=100 W MSet=ME10 LSet=LS11 Release
14 LIN P5 CONT Vel=0.1 m/s CPDAT5 Tool[1] Base[0]
15 GasSwi All OFF
16 PTP HOME Vel= 100 % DEFAULT
17 END

```

Description

| Line | Description |
|------|---|
| 5 | <p>Initializes the laser. The instruction carries out an implicit request. Light path and laser are selected.</p> <p>This instruction does not perform a reset.</p> <p>The robot motion is generally stopped due to handshake operations with the laser.</p> |
| 7 | The process gas is switched on. |
| 8 | <p>CrossJet is activated.</p> <p>Continuous: until <code>GasSwi All OFF</code>, the gas parameters (pressure, gas preflow time, gas postflow time) for all <code>LaserOn</code>, <code>LaserSwi</code> and <code>LaserEnd</code> instructions are ignored.</p> |
| 10 | <p>The next motion instruction executes a step seam.</p> <p>The overall length of the step seam and the number and length of the steps are defined in the option window Step parameters.</p> |
| 13 | The laser power is switched off and the laser program terminated at the end point of the motion block LIN P5. The laser itself is not switched off. |
| 15 | All gases are deactivated. |

8.2 Example program: gas and laser welding functions

Program

```

1 DEF Gas ( )
2 INI
3 PTP HOME Vel=100 % DEFAULT
4 PTP Start CONT Vel=100 % PDAT0 Tool[1] Base[0]
5 LSR WELD Allocation=True Gas: GasDef LSN: LSNDDef
6 LIN P1 CONT Vel=0.2 m/s CPDAT1 Tool[1] Base[0]
7 GasSwi Proc_Gas ON Nicht Haltend
8 GasSwi CrossJet ON Nicht Haltend
9 GasSwi Root_Gas ON Nicht Haltend
10 LIN P2 CONT Vel=0.2 m/s CPDAT2 Tool[1] Base[0]
11 LSR WELD On Path=0 mm Min=500 W MSet=ME19 LSet=LS21 Wire
12 LIN P3 CONT Vel=0.1 m/s CPDAT3 Tool[1] Base[0]
13 LIN P4 CONT Vel=0.1 m/s CPDAT4 Tool[1] Base[0]
14 LIN P5 CONT Vel=0.1 m/s CPDAT5 Tool[1] Base[0]
15 LSR WELD Switch Path=0 mm MSet=ME8 LSet=LS9
16 LIN P6 CONT Vel=0.1 m/s CPDAT6 Tool[1] Base[0]
17 LSR WELD End Path=0 mm Min=100 W MSet=ME10 LSet=LS11 Release
18 LIN P7 CONT Vel=0.1 m/s CPDAT7 Tool[1] Base[0]
19 PTP HOME Vel= 100 % DEFAULT
20 END

```

Description

| Line | Description |
|------|--|
| 5 | <p>Initializes the laser. The instruction carries out an implicit request. Light path and laser are selected.</p> <p>This instruction does not perform a reset.</p> <p>The robot motion is generally stopped due to handshake operations with the laser.</p> |
| 7 | The process gas is switched on. |
| 8 | CrossJet is activated. |
| 9 | The root gas is switched on. |
| 11 | <p>The instruction refers to the next motion instruction. The laser program starts at the end point of the motion block LIN P3.</p> <p>If the laser has not yet been requested, it is now requested implicitly by means of this instruction. This causes the motion to stop.</p> |
| 15 | Modification of the weld parameters. The instruction refers to the next motion instruction. |
| 17 | <p>The laser power is switched off and the laser program terminated at the end point of the motion block LIN P7. The laser itself is not switched off.</p> <p>The instruction switches the gas off, as a GasSWI ON instruction has been programmed with the setting "Once". It is not necessary to deactivate the gas with GasSWI OFF.</p> <p>The laser power is ramped down if a ramp time has been programmed.</p> |

8.3 Example program: set piercing and cutting data

Program

```

1 DEF SetCut( )
2 INI
3 PTP HOME Vel=100 % DEFAULT
4 PTP Start CONT Vel=100 % PDAT0 Tool[1] Base[0]
5 LSR CUT Allocation=True Gas: GasDef LSN: LSNDef
6 PTP P1 CONT Vel=10 % PDAT1 Tool[2] Base[0]
7 LIN P2 CONT Vel=0.2 m/s CPDAT1 Tool[1] Base[0]
8 LsrCut InData: CS1
9 LsrCut Sensor=On InDLY=500 msec PgNo=1
10 LIN P3 CONT Vel=0.1 m/s CPDAT4 Tool[1] Base[0]
11 LIN P4 CONT Vel=0.1 m/s CPDAT5 Tool[1] Base[0]
12 LIN P5 CONT Vel=0.1 m/s CPDAT6 Tool[1] Base[0]
13 LsrCut Sensor=Hold InDLY=500 msec PgNo=1
14 LIN P6 CONT Vel=0.1 m/s CPDAT7 Tool[1] Base[0]
15 PTP HOME Vel= 100 % DEFAULT
16 END

```

Description

| Line | Description |
|------|---|
| 5 | Initializes the laser. The instruction carries out an implicit request. Light path and laser are selected. This instruction does not perform a reset. The robot motion is generally stopped due to handshake operations with the laser. |
| 8 | The piercing and cutting data are set. |
| 9 | The distance sensor is switched on. If InDLY > 0, piercing is carried out from a standstill. |
| 13 | The distance sensor remains in the current position. |

8.4 Example program: piercing function

When the piercing function is called, the following piercing operation is executed:

1. The piercing data are set before the laser is switched on.
2. The robot waits at the start point of the cut (exact positioning).
3. The sensor is moved to the piercing distance.
4. Once the sensor has reached the piercing distance (LSCI_SnsrPosReached = TRUE), it remains in this position.
5. After a wait time (=piercing time), the sensor is set to the cutting distance.
6. The laser power is reduced to approx. 1% of the maximum power.
7. The cutting gas is changed.
8. The robot starts the laser cutting.

Program

```

1 DEF Shape_einsteichen( )
2 INI
3 PTP HOME Vel=100 % DEFAULT
4 PTP Start CONT Vel=100 % PDAT0 Tool[1] Base[0]
5 LSR CUT Allocation=True Gas: GasDef LSN: LSNDef
6 LIN P6 CONT Vel=0.2 m/s CPDAT1 Tool[1] Base[0]
7 GasSwi Cut_Gas ON Nicht Haltend
8 GasSwi CrossJet ON Nicht Haltend
9 LIN P7 CONT Vel=0.2 m/s CPDAT2 Tool[1] Base[0]
10 LsrCutHex Shape=GP1 P12 Vel=1 m/min MSet=ME20 LSet=LS22
    InData=CS1
11 LIN P8 CONT Vel=0.1 m/s CPDAT3 Tool[1] Base[0]
12 LSR Free
13 PTP HOME Vel= 100 % DEFAULT
14 END

```

Description

| Line | Description |
|------|---|
| 5 | Initializes the laser. The instruction carries out an implicit request. Light path and laser are selected. This instruction does not perform a reset. The robot motion is generally stopped due to handshake operations with the laser. |
| 7 | The cutting gas is switched on. |
| 8 | CrossJet is activated. |
| 10 | The piercing and cutting data are set. The piercing function is called and the distance sensor is switched on. |
| 12 | The laser is enabled. |

9 Messages

9.1 Basic laser function messages

| Message | Description/remedy | Key |
|--|---|---|
| <i>Collision protection device triggered! Please move the robot clear in Test1 or Test2 mode</i> | A collision has occurred. <ul style="list-style-type: none"> ■ Move away from the collision in T1 or T2 mode. ■ Resume program execution or re-set program and laser. | CollisionDe- tected |
| <i>The laser shutter will be closed during block selection</i> | For safety reasons, use of the laser power is prevented during block selection. | LaserShutDown- AtBlockSelect |
| <i>Laser is still not activated: No LASER ON state</i> | Possible causes: <ul style="list-style-type: none"> ■ The laser is not switched on. ■ The laser is currently being reset. ■ The laser is in manual mode. | NoLaserOnSta- tus |
| <i>No laser application possible without crossjet!</i> | <ul style="list-style-type: none"> ■ Activate CrossJet. ■ Acknowledge the message. ■ Resume or restart program | MissingCrossJet |
| <i>Block command failed.</i> | An error has occurred during execution of a technology-specific instruction. Please contact the Service Department if this error recurs. | BlockCommand- Failed |
| <i>No valid inline form</i> | An error has occurred during execution of a technology-specific instruction. Please contact the Service Department if this error recurs. | NoInlineForm |
| <i>Wrong value of \$PRO_I_O[] (\$CUSTOM.DAT) or no submit routine selected</i> | <ul style="list-style-type: none"> ■ Deselect program. ■ Deselect Submit. ■ Change value, start Submit. | WrongSubmitInt- erpreter |
| <i>Error message at laser system</i> | <ul style="list-style-type: none"> ■ Eliminate laser error. ■ Acknowledge the message. ■ Resume or restart program | ErrorAtLaser |
| <i>Continuing the process only sensible with correct operating mode and previous override value!</i> | A collision has occurred. <ul style="list-style-type: none"> ■ Move away from the collision in T1 or T2 mode. ■ Reset program and laser. | CollisionCor- rectModeOpera- tion |
| Internal error! | An error has occurred during execution of a technology-specific instruction. Please contact the Service Department if this error recurs. | InternalError |
| <i>No gas available! Please check gas equipment</i> | This error message is triggered by the process gas monitoring. | NoGasFlow |

| Message | Description/remedy | Key |
|---|---|-------------------------------------|
| <i>Laser is not available and shutter is closed</i> | Possible causes: <ul style="list-style-type: none"> ■ A required signal has not been generated or was not detected by the laser. ■ Error in the laser controller | NoLaserActive-AndShutter-Closed |
| <i>No feedback of the laser by external control</i> | The signal LSRI_LsrExternEnabled is not generated. Possible causes: <ul style="list-style-type: none"> ■ The laser is not switched on. ■ The laser is currently being reset. ■ The laser is in manual mode. | NoExternMode-Possible |
| <i>Laser is still not in standby mode</i> | Possible causes: <ul style="list-style-type: none"> ■ A required signal has not been generated or was not detected by the laser. ■ Error in the laser controller | LaserStillNotIn-Standby |
| <i>Laser still not ready or not assigned</i> | The laser program cannot be started. Possible causes: <ul style="list-style-type: none"> ■ The laser is not switched on. ■ The laser is currently being reset. ■ The laser is in manual mode. | LaserStill-NotReady |
| <i>Laser flags critical error to cell control</i> | An error has occurred in the laser periphery. Depending on the configuration, this may also be a robot error. | LsrExternError |
| <i>Laser still waiting for allocation</i> | The instruction LSR Allocate has been called. The laser is not free, however. This message is displayed during the wait time. | LaserWaiting-ForAllocation |
| <i>Laser error -> Details on console of laser system</i> | Refer to message on the laser console. | DetailsToLsrErrorsOnConsole |
| <i>Laser error -> Details on laser console ---> Resumption of program after laser reset</i> | Refer to message on the laser console. | LsrErrorLookOn-Console |
| <i>Laser error has occurred</i> | <ul style="list-style-type: none"> ■ Eliminate laser error. ■ Acknowledge the message. ■ Resume or restart program Depending on the nature of the error, the message "ErrorAtLaser" may also be generated. | LaserErrorAvailable |
| <i>Invalid laser command -> LASER INIT command necessary</i> | An invalid laser command has been initiated. A program reset is generally required. | LaserCommand-IncompatibleTo-Package |

| Message | Description/remedy | Key |
|--|---|------------------------|
| <i>Laser program was canceled</i> | The laser signals the cancelation of an active program. Possible causes: <ul style="list-style-type: none"> ■ The signal LSRO_LsrReset is set during an active program. ■ The signal LSRO_LsrStartStatic is reset before the signal LSRO_LsrStopProgram has been set. | LsrProgramCancel |
| <i>Laser program could not be activated: Please check errors on laser console</i> | Possible causes: <ul style="list-style-type: none"> ■ A required signal has not been generated or was not detected by the laser. ■ Error in the laser controller | NotProgramActive |
| <i>Laser was switched to manual mode ---> Resumption of process after laser reset</i> | Cause: Manual mode has been forced on the laser console. | LsrInManual-Mode |
| <i>Check media control!</i> | <ul style="list-style-type: none"> ■ Eliminate media error. ■ Acknowledge the message. ■ Resume or restart program | CheckMedia-Control |
| <i>Periphery not in a safe state</i> | <ul style="list-style-type: none"> ■ Check the safety equipment. ■ Eliminate problem. ■ Reset program and laser. | LsrPeripheryNot-Safe |
| <i>Complete program will be continued without active process. Resumption with active process by executing LASER_INIT command</i> | Cause: Following an error, this option (= continue complete program without active process) has been selected as a response in a dialog window. | CompleteCold-Run |
| <i>Cold run selected</i> | The value of LSR_UseLaserPower is FALSE. To use the laser, set the value to TRUE. | NoLsrControl-ColdRun |
| <i>Program was aborted or external error signal active</i> | <ul style="list-style-type: none"> ■ Eliminate problem. ■ Acknowledge the message. ■ Resume or restart program | ProgAbortOrExt-Failure |
| <i>No process gas!</i> | <ul style="list-style-type: none"> ■ Activate process gas. ■ Acknowledge the message. ■ Resume or restart program | MissingProcess-Gas |
| <i>Please acknowledge errors on laser console first</i> | Laser errors cannot be reset from the robot. | LsrReceiptMessage |
| <i>Robot was stopped by an interpreter stop</i> | The robot interpreter has been stopped by: <ul style="list-style-type: none"> ■ STOP key ■ EMERGENCY STOP ■ Operator safety ■ Operating mode change ■ Releasing the enabling switch | LsrInTechStop |
| <i>Laser safety circuit is still open: Ensure laser safety before the robot program is resumed</i> | Possible causes: <ul style="list-style-type: none"> ■ The safety circuit is open. ■ Light path settings in the laser do not match the requested light path. | SikContactOpen |

| Message | Description/remedy | Key |
|---|---|------------------------|
| <i>Safety circuit open, shutter closed</i> | Possible causes: <ul style="list-style-type: none"> ■ The safety circuit is open. ■ Light path settings in the laser do not match the requested light path. | ShutterOpen |
| <i>Standstill monitoring: Laser was switched off because robot welded for too long at the same position</i> | If welding is to be carried out for longer at a specific position, i.e. without robot motion, the value of LSR_Stop_InspectionTime must be increased. | RobotStandStill |
| <i>Standstill monitoring: Laser has not been used for a long time and has just been shut down</i> | The interval after which the laser is deactivated can be increased in the configuration. (LSR_LaserStandbyDelay) | LaserStandStill |
| <i>Robot stopped ---> Resumption of the process</i> | <ul style="list-style-type: none"> ■ Eliminate cause of the stop reaction. ■ Answer the dialog and resume or restart the program. | LsrRobotError |
| <i>Error of laser system ---> Resumption of process possible after dialog and forced reset of laser</i> | Refer to message on the laser console. | CollectionErrorOfLaser |
| <i>Test commands only possible in operating mode Test1 or Test2!</i> | <ul style="list-style-type: none"> ■ Change operating mode. ■ Restart the program. | NoFocusPulsInAutomatic |
| <i>Invalid parameter list</i> | An error has occurred during execution of a technology-specific instruction. Please contact the Service Department if this error recurs. | ParamListHandleUnknown |
| <i>Insufficient gas pressure! Please check gas equipment.</i> | <ul style="list-style-type: none"> ■ Eliminate problem. ■ Reset program. | NotEnoughGasPressure |
| <i>No root gas!</i> | <ul style="list-style-type: none"> ■ Activate root gas. ■ Acknowledge the message. ■ Resume or restart program | MissingRootGas |
| <i>Cell or laser safety error. Check safety equipment!</i> | <ul style="list-style-type: none"> ■ Eliminate problem. ■ Acknowledge the message. ■ Resume or restart program | LsrCellOrSafetyError |
| <i>Gas pressure too low. The current program will be aborted. Please check gas !!!</i> | <ul style="list-style-type: none"> ■ Correct the gas pressure. ■ Acknowledge the message. ■ Resume or restart program | LastPartToLessGas |
| <i>Laser allocation denied</i> | Possible causes: <ul style="list-style-type: none"> ■ The laser is allocated to a different station. ■ The laser is in manual mode. ■ An error has occurred. | LaserAllocationAvoided |

9.2 LaserCut messages


| Message | Description/remedy | Key |
|---|---|----------------------------|
| <i>Error in user-defined sensor code!</i> | An error has occurred within the user-defined function so that the return value $\neq 0$. Remedy: Eliminate the error and ensure that the return value = 0. | ErrorInUserDef-SnsrProc |
| <i>Function not implemented!</i> | A non-implemented function has been called. Please inform the Service Department. | NOT_IMPLEMENTED |
| <i>Initialization of user-defined sensor code failed!</i> | An error has occurred within the user-defined function so that the return value $\neq 0$. Remedy: Eliminate the error and ensure that the return value = 0. | InitOfUserDef-SensorFailed |
| <i>Programmed position not reached</i> | <ul style="list-style-type: none"> ■ Reset the sensor using the sensor controller. ■ Reset program. | NoProgPos |
| <i>Sensor error</i> | Eliminate the sensor controller error and acknowledge the message. | SnsrError |
| <i>Sensor cable interrupted!</i> | <ul style="list-style-type: none"> ■ Eliminate problem. ■ Reset program. | SnsrCableError |
| <i>Collision monitoring</i> | The distance sensor signals a collision. Eliminate the sensor controller error and acknowledge the message. | SnsrCollision |
| <i>Use of a reserved sensor type!</i> | An attempt has been made to initialize a reserved sensor type within a user-defined function. | UseOfReserved-SnsrType |

9.3 LaserWeld messages

| Message | Description/remedy | Key |
|--|--|----------------------|
| <i>Wire or wirefeeder not available</i> | <ul style="list-style-type: none"> ■ Check wire feed system. ■ Check configuration for the wire feed system in the robot controller. | WireFeeder-NotReady |
| <i>Please acknowledge errors of the wirefeed unit</i> | <ul style="list-style-type: none"> ■ Acknowledge message on wire feed system. ■ Acknowledge this message on the robot controller. | WfdReceiptMessage |
| <i>Please acknowledge errors on the wire heater unit</i> | <ul style="list-style-type: none"> ■ Acknowledge message on the welding wire heater. ■ Acknowledge this message on the robot controller. | AcknWfdHeat-Message |
| <i>Wire heater error</i> | <ul style="list-style-type: none"> ■ Eliminate error in the wire heater. ■ Acknowledge the message. | WireFeedHeat-Problem |

10 Appendix

10.1 Configuration parameters: overview of inputs/outputs, interrupts, timers and cyclical flags

 The numbers for inputs/outputs, interrupts, timers and cyclical flags may only be assigned once in the entire robot controller.

NOTICE Incorrect configuration of the internal analog channels can result in the laser working with incorrect parameters. Damage to the system may result.

Analog outputs

Outputs 1 to 32 are available.

| Parameter | Variable name | Values |
|--|-----------------------|------------------|
| Analog channel for laser power (>>> 10.2.1 "LaserTech: Outputs to the laser" Page 69) | LSRO_LsrPwr | Default value: 2 |
| Analog channel for wirefeeder (>>> 10.3.1 "LaserWeld: Outputs to the wire feed system" Page 75) | LSWO_WireFeedChannel | Default value: 9 |
| Analog channel for wire heater (>>> 10.3.1 "LaserWeld: Outputs to the wire feed system" Page 75) | LSWO_WireFeedHeatChan | Default value: 8 |
| Analog channel for gas pressure (>>> 10.2.3 "LaserTech: Outputs to the periphery" Page 71) | LSRO_GasPressure | Default value: 4 |
| Analog channel for the working distance (>>> 10.4.1 "LaserCut: Outputs to the sensor" Page 77) | LSCO_LscDistance | Default value: 5 |
| Analog channel for tip compensation (>>> 10.4.1 "LaserCut: Outputs to the sensor" Page 77) | LSCO_LscTipComp | Default value: 6 |
| Analog channel for the programmed position (>>> 10.4.1 "LaserCut: Outputs to the sensor" Page 77) | LSCO_LscProgPos | Default value: 7 |

Analog inputs

Inputs 1 to 32 are available.

| Parameter | Variable name | Values |
|--|------------------|------------------|
| Analog channel for gas pressure (>>> 10.2.4 "LaserTech: Inputs from the periphery" Page 72) | LSRI_GasPressure | Default value: 4 |

Interrupts

NOTICE If the priority of the interrupts is changed, this may result in a double assignment. Furthermore, the interrupts for the LaserTech monitoring functions may receive a priority that is so low that they are processed too late. This can cause damage to the system.

| Parameter | Variable name | Values |
|--------------------------------|--------------------------|---------------------------------|
| Interrupt media | LSR_InterruptMedias | ■ 4 ... 39 Default value: 10 |
| Interrupt step function | LSR_TC_STEP | ■ 1 ... 39 Default value: 17 |
| Interrupt step seam monitoring | LSR_InterruptStepMon | ■ 1 ... 39 Default value: 11 |
| Interrupt anticollision device | LSR_InterrAntiCollission | ■ 4 ... 39 Default value: 7 |
| Interrupt laser safety | LSR_InterruptLaserSafety | ■ 4 ... 39 Default value: 8 |
| Interrupt distance sensor | LSR_InterruptDistSensor | ■ 4 ... 39 Default value: 9 |

Timer

| Parameter | Variable name | Values |
|--|-------------------|---------------------------------|
| Timer number gas post-flow control | LSR_TC_PostGas | ■ 1 ... 32 Default value: 15 |
| Timer number gas preflow time | LSR_TC_PreFlowGas | ■ 1 ... 32 Default value: 16 |
| Timer number sensor status keys (>>> 10.4.3 "LaserCut: Process parameters" Page 78) | LSC_TC_PrecPLC | ■ 1 ... 32 Default value: 19 |

Cyclflags

NOTICE If the number of cyclical flags is changed, this may result in a double assignment. Furthermore, the numbers of the cyclical flags for the LaserTech monitoring functions may be overwritten. This can cause damage to the system.

| Parameter | Variable name | Values |
|---|----------------------|---|
| Cycflag step control | LSR_CF_STEP | <ul style="list-style-type: none"> ■ 1 ... 32 Default value: 29 |
| Cycflag step seam monitoring | LSR_InterruptStepMon | <ul style="list-style-type: none"> ■ 1 ... 32 Default value: 13 |
| Cycflag gas control | LSR_CF_GasCtrl | <ul style="list-style-type: none"> ■ 1 ... 32 Default value: 11 |
| Cycflag media monitoring | LSR_CF_MediaCtrl | <ul style="list-style-type: none"> ■ 1 ... 32 Default value: 32 |
| Cycflag laser monitoring | LSR_CF_LaserCtrl | <ul style="list-style-type: none"> ■ 1 ... 32 Default value: 30 |
| Cycflag sensor control (>>> 10.4.3 "LaserCut: Process parameters" Page 78) | LSR_CF_SensorCtrl | <ul style="list-style-type: none"> ■ 1 ... 32 Default value: 31 |

10.2 LaserTech configuration parameters

NOTICE

Incorrect configuration of inputs and outputs can result in the laser switching on or off at the wrong time and/or with incorrect parameters. This can cause damage to the system.

10.2.1 LaserTech: Outputs to the laser



Detailed information about the laser controller is contained in the TRUMPF documentation.




The signals described in this section can be found in the file \$config.dat in the directory R1\System. To adapt the values, the file must be edited.

| Parameter | Description/variable name | Data type |
|----------------------------------|--|-----------|
| Laser request | LSRO_LsrRequest | BOOL |
| Pilot laser on | LSRO_LsrPilotOn | BOOL |
| Sync with laser 1 | Query whether laser ready. LSRO_LsrSync1 | BOOL |
| Sync with laser 2 | Query whether laser ready. By default, the robot controller uses LSRO_LsrSync1 for the query. LSRO_LsrSync2 | BOOL |
| Error in the peripherie of laser | Robot fault (fault that is external to the laser controller) LSRO_LsrFaultExtern | BOOL |
| Laser reset | LSRO_LsrReset | BOOL |

| Parameter | Description/variable name | Data type |
|-------------------------------------|---------------------------|-----------|
| Stop laser program | LSRO_LsrStopProgram | BOOL |
| Laser program start dynamic | LSRO_LsrStartDynamic | BOOL |
| Laser program start static | LSRO_LsrStartStatic | BOOL |
| Set laser to standby | LSRO_LsrStandby | BOOL |
| Laser on | LSRO_LsrOn | BOOL |
| Disable laser console | LSRO_LsrOperationOff | BOOL |
| Enable external control | LSRO_LsrExternControl | BOOL |
| BCD code program number upper bits* | LSRO_LsrPrgNrBCD10 | 4 bits |
| BCD code program number lower bits* | LSRO_LsrPrgNrBCD1 | 4 bits |
| Laser program number binary coded* | LSRO_LsrPrgSetDual | Byte |
| Laser Fiber | LSRO_LsrFiber | Byte |
| Laser number | LSRO_LsrLaserNr | Byte |
| Robot number | LSRO_LsrRobotNr | Byte |
| Laser control word 0 | LSRO_LsrDataWord0 | Word |
| Analog channel for laser power | LSRO_LsrPwr | INT |
| Laser control word 3 | LSRO_LsrDataWord3 | Word |
| Laser control word 4 | LSRO_LsrDataWord4 | Word |
| Ramp length | LSRO_LsrRampTime | Word |
| Ramp start value; ramp up | LSRO_LsrRmpUpStartVal | Word |
| Ramp end value; ramp up | LSRO_LsrRmpUpEndVal | Word |
| Ramp start value; ramp down | LSRO_LsrRmpDownStartVal | Word |
| Ramp end value; ramp down | LSRO_LsrRmpDownEndVal | Word |


* Whether program numbers are transferred as BCD coded or binary coded values depends on the parameter LSR_MPI_Interface .

10.2.2 LaserTech: Inputs from the laser


 The signals described in this section can be found in the file \$config.dat in the directory R1\System. To adapt the values, the file must be edited.

| Parameter | Description/variable name | Data type |
|-----------------------------|--|-----------|
| Warnlamps are on | LSRI_LsrWarnLampOn | BOOL |
| Pilot laser is on | LSRI_LsrPilotOn | BOOL |
| Laser is assigned | LSRI_LsrAssigned | BOOL |
| Monitoring message of laser | LSRI_LsrInternFault | BOOL |
| Internal laser error | LSRI_LsrFailure | BOOL |
| Shutter is closed | LSRI_LsrShutterClosed | BOOL |
| Sync input 1 | LSRI_LsrSet1 | BOOL |
| Sync input 2 | LSRI_LsrSet2 | BOOL |
| Sync input 3 | By default, the robot controller polls sync input 3. LSRI_LsrSet3 | BOOL |
| Laser program canceled | LSRI_LsrProgAbort | BOOL |
| End of laser program | LSRI_LsrProgEnd | BOOL |
| Laser program is active | LSRI_LsrProgActive | BOOL |
| Laser is in standby | LSRI_LsrStandby | BOOL |

| Parameter | Description/variable name | Data type |
|----------------------------------|---------------------------|-----------|
| Laser is active | LSRI_LsrActive | BOOL |
| External control is enabled | LSRI_LsrExternEnabled | BOOL |
| Laser fiber number | LSRI_LsrFiberNo | Word |
| Laserfiber number from safetybox | LSRI_LsrFiberSafetyCode | Word |
| Safetycircuit monitoring | LSRI_LsrUserSafety | BOOL |
| Keyswitch monitoring (laser) | LSRI_LsrKeyEnable | BOOL |

 Detailed information about the laser controller is contained in the TRUMPF documentation.

10.2.3 LaserTech: Outputs to the periphery

 The signals described in this section can be found in the file \$config.dat in the directory R1\System. To adapt the values, the file must be edited.

| Parameter | Description/variable name | Data type |
|---|---|-----------|
| Cell error, flag to PLC | LSRO_Error_Cell | BOOL |
| Media error, flag to PLC | LSRO_Error_Media | BOOL |
| Collision monitoring, flag to PLC | LSRO_AntiCollissionDev | BOOL |
| Sensor error, flag to PLC | LSRO_Error_Sensor | BOOL |
| Without power for one section, flag to PLC | The next section is carried out as a dry run. The section is what comes between the following commands: <ul style="list-style-type: none"> ■ LaserOn - LaserSwi ■ LaserSwi - LaserSwi ■ Laser Swi - Laser End LSRO_ColdFor1Section | BOOL |
| Next seam without power, flag to PLC | The next seam is carried out as a dry run. The seam is what comes between the following commands: <ul style="list-style-type: none"> ■ LaserOn - LaserEnd LSRO_ColdFor1Seam | BOOL |
| Without power to next init command, flag to PLC | LSRO_ColdForEver | BOOL |
| Activate/deactivate CrossJet | LSRO_CrossJet | BOOL |
| Analog channel for gas valve | Number of the analog channel for the gas pressure Only relevant if "Proportional Gas Valve" = TRUE LSRO_GasPressure | INT |
| Output enable the selected gas | Only relevant if "Proportional Gas Valve" = TRUE LSRO_GasEnable Note: Normally used with an additional main valve. | BOOL |

10.2.4 LaserTech: Inputs from the periphery



The signals described in this section can be found in the file \$config.dat in the directory R1\System. To adapt the values, the file must be edited.

| Parameter | Description/variable name | Data type |
|---------------------------------------|--|-----------|
| CrossJet is On/Off | CrossJet gas is OK. LSRI_CrossJet | BOOL |
| Anloge in channel actual gas pressure | Number of the analog channel for the gas pressure Only relevant if "Proportional Gas Valve" = TRUE LSRI_GasPressure | INT |
| State of collision Sensor | LSRI_AntiCollisionDev | BOOL |
| User defined Input 1 | This input can be used to integrate customer signals into the process monitoring in order to stop the process in the event of a fault. LSRI_UsrInput1 | BOOL |
| User defined Input 2 | This input can be used to integrate customer signals into the process monitoring in order to stop the process in the event of a fault. LSRI_UsrInput2 | BOOL |

10.2.5 LaserTech: Other outputs



The variables described in this section can be found in the file Laser.dat in the directory R1\TP\LaserTech. To display or change the values, select **Display > Variable > Single** from the main menu.

| Parameter | Description/variable name | Values |
|-------------------------------|--|---------------|
| Output number submit watchdog | This output can be used together with the parameter S_Int_Cycl to monitor whether the submit interpreter is running cyclically. The monitoring only works usefully if this output is continuously TRUE. To achieve this, the value of S_Int_Cycl must be a little higher than the cycle time of the SPS.SUB program. S_Int_Flag | ■ 1 ... 4 096 |
| Suspend error messages | This output is used internally during monitoring of the process. The output may only be used once. LSRO_Error_Bypass | ■ 1 ... 4 096 |

10.2.6 LaserTech: Process options



The variables described in this section can be found in the file Laser.dat in the directory R1\TP\LaserTech. To display or change the values, select **Display > Variable > Single** from the main menu.

| Parameter | Description/variable name |
|--|---|
| Activate/deactivate CrossJet | <p>TRUE: CrossJet is activated on initialization of the laser and deactivated at the end of the program.</p> <p>FALSE: CrossJet is activated and deactivated via the inline forms "Activate process", "Deactivate process" and "Switch gas".</p> <p>LSR_CrossJetOption</p> |
| Activate/deactivate ramp function on LaserSwi | <p>TRUE: Ramps are possible on switching over the laser power.</p> <p>Note: For this, a suitable laser program is required.</p> <p>FALSE: No ramps are possible on switching over the laser power.</p> <p>LSR_RampOption</p> |
| Enable/Disable velocity controlled laser power | <p>TRUE: Laser power is proportional to the robot velocity.</p> <p>FALSE: The laser power remains constant at the value entered in the inline form.</p> <p>LSR_UsePwrVelCtrl</p> |
| Enable/Disable mirror laser fiber | <p>TRUE: The laser fiber number mirrored by the laser controller is evaluated.</p> <p>FALSE: The laser fiber number mirrored by the laser controller is not evaluated.</p> <p>LSR_LsrFiberMirrorOption</p> |
| Run programs without laser | <p>TRUE: The programs are executed without laser power. This is suitable, for example, for test purposes where no laser power is desired.</p> <p>LSR_UseLaserPower</p> |
| Proportional Gas Valve | <p>Note: If this parameter has been changed, the user interface must be reinitialized.</p> <p>TRUE: The gas pressure can be defined.</p> <p>FALSE: The gas pressure cannot be defined.</p> <p>The value of this parameter also influences which properties can be defined for the gases.</p> <p>(>>> 6.3 "Configuring the inputs/outputs for gases and other properties" Page 20)</p> <p>LSR_PropGasValve</p> |
| Analog power control | <p>The parameter must only be used if the laser has an analog input module. Additionally, the scaling values must be set.</p> <p>(>>> 10.2.7 "LaserTech: Process constants" Page 74)</p> <p>TRUE: The value is output as a real analog value.</p> <p>FALSE: The value is output in binary coded form via the field bus.</p> <p>Lsr_UseAnaModPwr</p> |
| Use root for tech commands | <p>Note: If this parameter has been changed, the user interface must be reinitialized.</p> <p>TRUE: An additional process gas (root gas) can be used.</p> <p>FALSE: No additional process gas (root gas) can be used.</p> <p>LSR_UseRootFlag</p> |

10.2.7 LaserTech: Process constants

The specified ranges of values contain the values that will be accepted by the system. They do not, however, constitute a recommendation of which values are useful in practice.



The variables described in this section can be found in the file Laser.dat in the directory R1\TP\LaserTech. To display or change the values, select **Display > Variable > Single** from the main menu.

| Parameter | Description/variable name |
|--|--|
| Time for reset pulse | Time for which the reset signal is set to acknowledge a laser fault. <ul style="list-style-type: none"> ■ 0 ... 9 999 s LSR_PulsTime |
| Timeout for error signal | Maximum wait time for a response from the laser during initialization. <ul style="list-style-type: none"> ■ 0 ... 9 999 s LSR_Timeout |
| Shutter delay constant | Minimum value for starting the laser switching actions before the taught point. <ul style="list-style-type: none"> ■ -10 000 ms ... +9 999 ms The value must be determined empirically. LSR_ShutterDelayConst |
| Additional to Shutter-delay at laser Off | Delay at end of welding, additional to LSR_ShutterDelayConst. This value is added to the shutter delay of the laser (LSR_ShutterDelayConst) when switching off the laser (LaserEnd). <ul style="list-style-type: none"> ■ -10 000 ms ... +9 999 ms LSR_ShutterOff |
| Additional to Shutter-delay at laser On | Delay at start of welding, additional to LSR_ShutterDelayConst. This value is added to the shutter delay of the laser (LSR_ShutterDelayConst) when switching on the laser (LaserOn). <ul style="list-style-type: none"> ■ -10 000 ms ... +9 999 ms LSR_ShutterOn |
| Delay for test commands | Interval between activating the shielding gas and switching on the laser. This time applies only to the commands "Test the laser power" and "Determine the focus of the optics". <ul style="list-style-type: none"> ■ 0 ... 9 999 ms LSR_TestDelay |
| Scaling Gas pressure | Scaling factor for the gas pressure <ul style="list-style-type: none"> ■ 1 ... 65 535 LSR_GasScale |
| Submit Watchdog Time | This parameter can be used together with the output S_Int_Flag to monitor whether the submit interpreter is running cyclically. The monitoring only works usefully if the output S_Int_Flag is continuously TRUE. To achieve this, the value of this parameter must be a little higher than the cycle time of the SPS.SUB program. <ul style="list-style-type: none"> ■ 1 ... 9 999 ms S_Int_Cycl |

| Parameter | Description/variable name |
|---|---|
| Scaling laser power | Only relevant if the parameter "Analog power control" is TRUE. <ul style="list-style-type: none"> ■ 1 ... 9 999 PwrScale |
| Maximum laser power | Maximum laser power of the laser used (in watts). Only relevant if the parameter "Analog power control" is TRUE. LSR_MAX_POWER |
| Gas init delay | Delay on triggering the GasInit command. <ul style="list-style-type: none"> ■ -2 000 ms ... +2 000 ms Lsr_InitGasDly |
| Gas check pressure | Gas pressure used when checking the process gases during initialization. Only relevant if the parameter "Proportional Gas Valve" is TRUE. <ul style="list-style-type: none"> ■ 1 ... 30 bar LSR_GasCheckPressure |
| Gas switch delay | Delay on triggering the GasSwi command. <ul style="list-style-type: none"> ■ -2 000 ms ... +2 000 ms Lsr_GasDlySwi |
| Enable/Disable increase impact pressure | Wait time for the robot controller in order to eliminate the back-pressure in the gas line. Corresponds to the gas preflow time on switching on the laser when the laser is restarted after a fault. <ul style="list-style-type: none"> ■ 0 ... 9 999 s Note: This wait time is ignored with the commands "Test the laser power" and "Determine the focus of the optics". LSR_TimeToAvoidGasPress |
| Standstill monitoring at active laser | If the robot is stationary and the laser power is active, the laser is deactivated after the time defined. <ul style="list-style-type: none"> ■ 0 ... 9 999 ms LSR_Stop_InspectionTime |
| Switching delay | Time difference between setting the laser parameters and starting the laser program <ul style="list-style-type: none"> ■ 0 ... 9 999 ms PreDelay |

10.3 LaserWeld configuration parameters

10.3.1 LaserWeld: Outputs to the wire feed system




The signals described in this section can be found in the file \$config.dat in the directory R1\System. To adapt the values, the file must be edited.

| Parameter | Description/variable name | Data type |
|------------------------|---|-----------|
| Wirefeed manual On/Off | Wire feed on/off via status key LSWO_WireFeedForward | BOOL |
| Wirefeed On/Off | LSWO_WireFeedStart | BOOL |

| Parameter | Description/variable name | Data type |
|--------------------------------|---------------------------|-----------|
| Analog channel for wirefeeder | LSWO_WireFeedChannel | INT |
| Analog channel for wire heater | LSWO_WireFeedHeatChan | INT |
| Wireheater On/Off | LSWO_WireFeedHeater | BOOL |
| Wirefeeder error, flag to PLC | LSWO_ErrorWireFeeder | BOOL |
| Wireheater error, flag to PLC | LSWO_ErrorWireHeat | BOOL |


10.3.2 LaserWeld: Inputs from the wire feed system

 The signals described in this section can be found in the file \$config.dat in the directory R1\System. To adapt the values, the file must be edited.

| Parameter | Description/variable name | Data type |
|---------------|---------------------------|-----------|
| Wireheater Ok | LSWI_WireFeedHeatControl | BOOL |
| Wirefeed Ok | LSWI_WireFeedReady | BOOL |

10.3.3 LaserWeld: Process parameters

The specified ranges of values contain the values that will be accepted by the system. They do not, however, constitute a recommendation of which values are useful in practice.


 The variables described in this section can be found in the file Lsw_Main.dat in the directory R1\TP\LaserWeld. To display or change the values, select **Display > Variable > Single** from the main menu.


| Parameter | Description/variable name |
|--|---|
| Use wire controller | <ul style="list-style-type: none"> ■ TRUE, FALSE LSW_UseWireFeed |
| Use hot wire controller | <ul style="list-style-type: none"> ■ TRUE, FALSE LSW_HotWireOption |
| Enable/Disable velocity depending wirefeed | <p>Note: If this parameter has been changed, the user interface must be reinitialized.</p> <p>TRUE: The wire feed rate is regulated relative to the robot velocity.</p> LSW_UseWFDVelCtrlId |
| Reduced wirefeed value | <p>TRUE: The wire feed rate is reduced in the case of a start following a weld fault.</p> LSW_StaticRedWfdOption |
| Reduced wirefeed distance | <p>Distance for which the reduced wire feed rate in LSW_StaticRedWfdOption applies.</p> <p>Precondition: LSW_StaticRedWfdOption is ON.</p> <ul style="list-style-type: none"> ■ 0 ... 9 999 mm LSW_WfdDistanceMax |

| Parameter | Description/variable name |
|-----------------------------------|---|
| Wirefeed reduce value | Value by which the wire feed rate is decreased. The wire feed rate is increased until the distance specified in LSW_WfdDistanceMax has been covered. Precondition: LSW_StaticRedWfdOption is TRUE. ■ 0 ... 100 % LSW_ReducedLimitWfdValue |
| Wireheat delay | ■ -9 999 ... 0 ... 9 999 mm Positive value: Wire heater start delayed. Negative value: Wire heater start brought forward. LSW_WireHeatDelayConst |
| Trigger delay for wire controller | ■ 0.001 ... 9 999 s LSW_WFD_DELAY |
| Maximum wirefeed | ■ 0 ... 9 999 m/min LSW_WireFeedMaximum |
| Wirefeed minimum | ■ 0 ... 9 999 m/min LSW_WireFeedMinimum |
| Maximum wirefeed voltage | Maximum voltage for analog channel for wirefeed ■ 0 ... 9 999 LSW_WFD_AnalogMaxValue |
| Minimum wirefeed voltage | Minimum voltage for analog channel for wirefeed ■ 0 ... 9 999 LSW_WFD_AnalogMinValue |
| Maximum wireheat scaling | ■ 0 ... 100 % LSW_WireHeatMaximum |
| Minimum wireheat scaling | ■ 0 ... 100 % LSW_WireHeatMinimum |
| Maximum wireheat voltage | Maximum voltage for analog channel for wire heater ■ 0 ... 9 999 LSW_Heat_AnalogMaxValue |
| Wire heat voltage | Minimum voltage for analog channel for wire heater ■ 0 ... 9 999 LSW_Heat_AnalogMiniValue |

10.4 LaserCut configuration parameters

10.4.1 LaserCut: Outputs to the sensor

 Detailed information about the distance sensor and distance controller is contained in the PRECITEC documentation.

 The signals described in this section can be found in the file \$config.dat in the directory R1\System. To adapt the values, the file must be edited.

| Parameter | Description/variable name | Data type |
|------------------------------------|---|-----------|
| Workdistance 2* | LSCO_SnsrWorkdistance2 | BOOL |
| Workdistance 3* | LSCO_SnsrWorkdistance3 | BOOL |
| Enable extended range | Use increased workspace. LSCO_SnsrLargeRange | BOOL |
| Enable manual mode | LSCO_SnsrEnableManual | BOOL |
| Distance control On/Off | LSCO_SnsrAuto | BOOL |
| Move sensor into home position | LSCO_SnsrHome | BOOL |
| Run reference motion | LSCO_SnsrReference | BOOL |
| Move sensor up | LSCO_SnsrManualUp | BOOL |
| Move sensor down | LSCO_SnsrManualDown | BOOL |
| Enable slow motion mode | LSCO_SnsrSlowMotion | BOOL |
| Internal control data | Comprises the entire output range. LSCO_SnsrDataWord | Word |
| Analog channel working distance | LSCO_LscDistance | INT |
| Analog channel tip compensation | LSCO_LscTipComp | INT |
| Analog channel programmed position | LSCO_LscProgPos | INT |

10.4.2 LaserCut: Inputs from the sensor



Detailed information about the distance sensor and distance controller is contained in the PRECITEC documentation.



The signals described in this section can be found in the file \$config.dat in the directory R1\System. To adapt the values, the file must be edited.

| Parameter | Description/variable name | Data type |
|------------------------|---------------------------|-----------|
| Sensor is out of range | LSCI_SnsrOutOfRange | BOOL |
| Collision | LSCI_SnsrCollision | BOOL |
| Position reached | LSCI_SnsrPosReached | BOOL |
| Sensor error | LSCI_SnsrError | BOOL |
| Sensor reference error | LSCI_SnsrRefErr | BOOL |
| Sensor ready | LSCI_SnsrReady | BOOL |
| Monitor sensor cable | LSCI_SnsrCableCut | BOOL |

10.4.3 LaserCut: Process parameters

The specified ranges of values contain the values that will be accepted by the system. They do not, however, constitute a recommendation of which values are useful in practice.



The variables described in this section can be found in the file Lsc_Main.dat in the directory R1\TP\LaserCut. To display or change the values, select **Display > Variable > Single** from the main menu.

| Parameter | Description/variable name |
|------------------------------------|---|
| Cycflag sensor control | <ul style="list-style-type: none"> ■ 1 ... 32 LSR_CF_SensorCtrl |
| Timer number sensor status keys | <ul style="list-style-type: none"> ■ 1 ... 32 LSC_TC_PrecPLC |
| Analog distance | <p>Note: If this parameter has been changed, the user interface must be reinitialized.</p> <p>TRUE: The cutting distance in the inline form LsrCut Sensor is transferred as an analog value.</p> <p>FALSE: The cutting distance in the inline form LsrCut Sensor is transferred via a program number.</p> LSC_AnaCutDistance |
| Start velocity for pattern cutting | <ul style="list-style-type: none"> ■ 0.2 ... 9 999 % LSC_STRT_VEL |
| Distance scaling | <ul style="list-style-type: none"> ■ 1 ... 9 999 LSC_AnaCutScale |
| Programmed position | <p>“Home position” of the sensor. Refers to the zero position of the sensor.</p> <ul style="list-style-type: none"> ■ 3 ... 9 999 Unit: 1/10 mm <p>Precondition: The parameter LSC_AnaCutDistance is TRUE.</p> LSC_ProgPos |
| Maximum programmed position | <p>Limit value for the programmed position.</p> <ul style="list-style-type: none"> ■ 0 ... 300 Unit: 1/10 mm <p>Precondition: The parameter LSC_AnaCutDistance is TRUE.</p> LSC_MaxProgPos |
| Defined programmed Position | <ul style="list-style-type: none"> ■ 0 ... 300 Unit: 1/10 mm <p>Precondition: The parameter LSC_AnaCutDistance is TRUE.</p> LSC_DefProgPos |
| Tip compensation time 1 | <p>Limit value for the permissible contact duration during cutting</p> <ul style="list-style-type: none"> ■ 1 ... 9 999 ms LSC_TipComp1 |
| Tip compensation time 2 | <p>Limit value for the permissible contact duration during piercing</p> <ul style="list-style-type: none"> ■ 1 ... 9 999 ms LSC_TipComp2 |
| Gas change duration | <p>Time for the purging of the gas line on changing the gas after piercing.</p> <ul style="list-style-type: none"> ■ 1 ... 9 999 ms LSC_GasRinseTime |

11 KUKA Service

11.1 Requesting support

Introduction The KUKA Roboter GmbH documentation offers information on operation and provides assistance with troubleshooting. For further assistance, please contact your local KUKA subsidiary.

Information The following information is required for processing a support request:

- Model and serial number of the robot
- Model and serial number of the controller
- Model and serial number of the linear unit (if applicable)
- Model and serial number of the linear unit (if applicable)
- Version of the KUKA System Software
- Optional software or modifications
- Archive of the software
For KUKA System Software V8: instead of a conventional archive, generate the special data package for fault analysis (via **KrcDiag**).
- Application used
- Any external axes used
- Description of the problem, duration and frequency of the fault

11.2 KUKA Customer Support

Availability KUKA Customer Support is available in many countries. Please do not hesitate to contact us if you have any questions.

Argentina Ruben Costantini S.A. (Agency)
Luis Angel Huergo 13 20
Parque Industrial
2400 San Francisco (CBA)
Argentina
Tel. +54 3564 421033
Fax +54 3564 428877
ventas@costantini-sa.com

Australia Headland Machinery Pty. Ltd.
Victoria (Head Office & Showroom)
95 Highbury Road
Burwood
Victoria 31 25
Australia
Tel. +61 3 9244-3500
Fax +61 3 9244-3501
vic@headland.com.au
www.headland.com.au

| | |
|----------------|---|
| Belgium | KUKA Automatisering + Robots N.V. Centrum Zuid 1031 3530 Houthalen Belgium Tel. +32 11 516160 Fax +32 11 526794 info@kuka.be www.kuka.be |
| Brazil | KUKA Roboter do Brasil Ltda. Avenida Franz Liszt, 80 Parque Novo Mundo Jd. Guançã CEP 02151 900 São Paulo SP Brazil Tel. +55 11 69844900 Fax +55 11 62017883 info@kuka-roboter.com.br |
| Chile | Robotec S.A. (Agency) Santiago de Chile Chile Tel. +56 2 331-5951 Fax +56 2 331-5952 robotec@robotec.cl www.robotec.cl |
| China | KUKA Automation Equipment (Shanghai) Co., Ltd. Songjiang Industrial Zone No. 388 Minshen Road 201612 Shanghai China Tel. +86 21 6787-1808 Fax +86 21 6787-1805 info@kuka-sha.com.cn www.kuka.cn |
| Germany | KUKA Roboter GmbH Zugspitzstr. 140 86165 Augsburg Germany Tel. +49 821 797-4000 Fax +49 821 797-1616 info@kuka-roboter.de www.kuka-roboter.de |

| | |
|---------------|--|
| France | KUKA Automatismes + Robotique SAS Techvallée 6, Avenue du Parc 91140 Villebon S/Yvette France Tel. +33 1 6931660-0 Fax +33 1 6931660-1 commercial@kuka.fr www.kuka.fr |
| India | KUKA Robotics India Pvt. Ltd. Office Number-7, German Centre, Level 12, Building No. - 9B DLF Cyber City Phase III 122 002 Gurgaon Haryana India Tel. +91 124 4635774 Fax +91 124 4635773 info@kuka.in www.kuka.in |
| Italy | KUKA Roboter Italia S.p.A. Via Pavia 9/a - int.6 10098 Rivoli (TO) Italy Tel. +39 011 959-5013 Fax +39 011 959-5141 kuka@kuka.it www.kuka.it |
| Japan | KUKA Robotics Japan K.K. Daiba Garden City Building 1F 2-3-5 Daiba, Minato-ku Tokyo 135-0091 Japan Tel. +81 3 6380-7311 Fax +81 3 6380-7312 info@kuka.co.jp |
| Korea | KUKA Robotics Korea Co. Ltd. RIT Center 306, Gyeonggi Technopark 1271-11 Sa 3-dong, Sangnok-gu Ansan City, Gyeonggi Do 426-901 Korea Tel. +82 31 501-1451 Fax +82 31 501-1461 info@kukakorea.com |

| | |
|-----------------|---|
| Malaysia | KUKA Robot Automation Sdn Bhd South East Asia Regional Office No. 24, Jalan TPP 1/10 Taman Industri Puchong 47100 Puchong Selangor Malaysia Tel. +60 3 8061-0613 or -0614 Fax +60 3 8061-7386 info@kuka.com.my |
| Mexico | KUKA de Mexico S. de R.L. de C.V. Rio San Joaquin #339, Local 5 Colonia Pensil Sur C.P. 11490 Mexico D.F. Mexico Tel. +52 55 5203-8407 Fax +52 55 5203-8148 info@kuka.com.mx |
| Norway | KUKA Sveiseanlegg + Roboter Sentrumsvegen 5 2867 Hov Norway Tel. +47 61 18 91 30 Fax +47 61 18 62 00 info@kuka.no |
| Austria | KUKA Roboter Austria GmbH Vertriebsbüro Österreich Regensburger Strasse 9/1 4020 Linz Austria Tel. +43 732 784752 Fax +43 732 793880 office@kuka-roboter.at www.kuka-roboter.at |
| Poland | KUKA Roboter Austria GmbH Spółka z ograniczoną odpowiedzialnością Oddział w Polsce Ul. Porcelanowa 10 40-246 Katowice Poland Tel. +48 327 30 32 13 or -14 Fax +48 327 30 32 26 ServicePL@kuka-roboter.de |

Portugal KUKA Sistemas de Automatización S.A.
Rua do Alto da Guerra n° 50
Armazém 04
2910 011 Setúbal
Portugal
Tel. +351 265 729780
Fax +351 265 729782
kuka@mail.telepac.pt

Russia OOO KUKA Robotics Rus
Webnaja ul. 8A
107143 Moskau
Russia
Tel. +7 495 781-31-20
Fax +7 495 781-31-19
kuka-robotics.ru

Sweden KUKA Svetsanläggningar + Robotar AB
A. Odhners gata 15
421 30 Västra Frölunda
Sweden
Tel. +46 31 7266-200
Fax +46 31 7266-201
info@kuka.se

Switzerland KUKA Roboter Schweiz AG
Industriestr. 9
5432 Neuenhof
Switzerland
Tel. +41 44 74490-90
Fax +41 44 74490-91
info@kuka-roboter.ch
www.kuka-roboter.ch

Spain KUKA Robots IBÉRICA, S.A.
Pol. Industrial
Torrent de la Pastera
Carrer del Bages s/n
08800 Vilanova i la Geltrú (Barcelona)
Spain
Tel. +34 93 8142-353
Fax +34 93 8142-950
Comercial@kuka-e.com
www.kuka-e.com

| | |
|-----------------------|--|
| South Africa | Jendamark Automation LTD (Agency) 76a York Road North End 6000 Port Elizabeth South Africa Tel. +27 41 391 4700 Fax +27 41 373 3869 www.jendamark.co.za |
| Taiwan | KUKA Robot Automation Taiwan Co., Ltd. No. 249 Pujong Road Jungli City, Taoyuan County 320 Taiwan, R. O. C. Tel. +886 3 4331988 Fax +886 3 4331948 info@kuka.com.tw www.kuka.com.tw |
| Thailand | KUKA Robot Automation (M)SdnBhd Thailand Office c/o Maccall System Co. Ltd. 49/9-10 Soi Kingkaew 30 Kingkaew Road Tt. Rachatheva, A. Bangpli Samutprakarn 10540 Thailand Tel. +66 2 7502737 Fax +66 2 6612355 atika@ji-net.com www.kuka-roboter.de |
| Czech Republic | KUKA Roboter Austria GmbH Organisation Tschechien und Slowakei Sezemická 2757/2 193 00 Praha Horní Počernice Czech Republic Tel. +420 22 62 12 27 2 Fax +420 22 62 12 27 0 support@kuka.cz |
| Hungary | KUKA Robotics Hungaria Kft. Fő út 140 2335 Taksony Hungary Tel. +36 24 501609 Fax +36 24 477031 info@kuka-robotics.hu |

USA KUKA Robotics Corp.
22500 Key Drive
Clinton Township
48036
Michigan
USA
Tel. +1 866 8735852
Fax +1 586 5692087
info@kukarobotics.com
www.kukarobotics.com

UK KUKA Automation + Robotics
Hereward Rise
Halesowen
B62 8AN
UK
Tel. +44 121 585-0800
Fax +44 121 585-0900
sales@kuka.co.uk

Index

A

Appendix 67
Arc 51
Areas of application 9

C

Communication 9
Configuration 19
Cross Jet 8
CrossJet 16, 71, 72, 73
Cutting pattern, defining 47
Cyclical flags 67

D

Delay time 23
Distance sensor, switching 45
Documentation, industrial robot 7

E

Example programs 57

F

Functions, LaserTech 9

G

Gas postflow time 34, 53
Gas preflow time 32, 34, 52
Gas pressure 32, 33, 34, 52, 53, 75
Gas types, configuring 19
Gas, initializing 43
Gas, on/off 43
Geo motion data 48
Geometry data 48

I

Inputs 67
Installation 13
Installation, LaserTech 13
Interrupts 67
Introduction 7

K

Knowledge, required 7
KUKA Customer Support 81

L

Laser control 39
Laser cutting 47
Laser cutting, parameters 54
Laser focus 31
Laser functions 25
Laser power, drop time 37
Laser power, rise time 35, 54
Laser power, switching time 36
Laser program 8, 19
Laser test pulse 31
Laser, activating 25
Laser, deactivating 40

Laser, enabling 39
Laser, initializing 39
Laser, requesting 40
Light path (fiber) 70, 71, 73
Line 47
LSC_AnaCutDistance 45, 79
LSC_AnaCutScale 79
LSC_DefProgPos 79
LSC_GasRinseTime 79
LSC_MaxProgPos 79
LSC_ProgPos 79
LSC_SecDistance 45
LSC_SecInDly 45
LSC_STRT_VEL 79
LSC_TC_PrecPLC 68, 79
LSC_TipComp1 79
LSC_TipComp2 79
LSCI_SnsrCableCut 78
LSCI_SnsrCollision 78
LSCI_SnsrError 78
LSCI_SnsrOutOfRange 78
LSCI_SnsrPosReached 78
LSCI_SnsrReady 78
LSCI_SnsrRefErr 78
LSCO_LscDistance 67, 78
LSCO_LscProgPos 67, 78
LSCO_LscTipComp 67, 78
LSCO_SnsrAuto 78
LSCO_SnsrDataWord 78
LSCO_SnsrEnableManual 78
LSCO_SnsrHome 78
LSCO_SnsrLargeRange 78
LSCO_SnsrManualDown 78
LSCO_SnsrManualUp 78
LSCO_SnsrReference 78
LSCO_SnsrSlowMotion 78
LSCO_SnsrWorkdistance2 78
LSCO_SnsrWorkdistance3 78
LSR_CF_GasCtrl 69
LSR_CF_LaserCtrl 69
LSR_CF_MediaCtrl 69
LSR_CF_SensorCtrl 69, 79
LSR_CF_STEP 69
LSR_CrossJetOption 73
LSR_GasCheckPressure 75
Lsr_GasDlySwi 75
LSR_GasScale 74
Lsr_InitGasDly 75
LSR_InterrAntiCollission 68
LSR_InterruptDistSensor 68
LSR_InterruptLaserSafety 68
LSR_InterruptMedias 68
LSR_InterruptStepMon 68, 69
LSR_LsrFiberMirrorOption 73
LSR_MAX_POWER 75
LSR_PropGasValve 73
LSR_PulsTime 74
LSR_RampOption 23, 35, 36, 37, 54, 73

LSR_ShutterDelayConst 24, 74
 LSR_ShutterOff 24, 74
 LSR_ShutterOn 24, 74
 LSR_Stop_InspectionTime 24, 25, 75
 LSR_TC_PostGas 68
 LSR_TC_PreFlowGas 68
 LSR_TC_STEP 68
 LSR_TestDelay 74
 LSR_Timeout 74
 LSR_TimeToAvoidGasPress 75
 Lsr_UseAnaModPwr 73
 LSR_UseLaserPower 73
 LSR_UsePwrVelCtrlId 9, 35, 53, 73
 LSR_UseRootFlag 73
 LsrCutCircle 48
 LsrCutHex 48
 LsrCutRect 48
 LsrCutSlot 48
 LSRI_AntiCollisionDev 72
 LSRI_CrossJet 72
 LSRI_GasPressure 68, 72
 LSRI_LsrActive 71
 LSRI_LsrAssigned 70
 LSRI_LsrExternEnabled 71
 LSRI_LsrFailure 70
 LSRI_LsrFiberNo 71
 LSRI_LsrFiberSafetyCode 71
 LSRI_LsrInternFault 70
 LSRI_LsrKeyEnable 71
 LSRI_LsrPilotOn 70
 LSRI_LsrProgAbort 70
 LSRI_LsrProgActive 70
 LSRI_LsrProgEnd 70
 LSRI_LsrSet1 70
 LSRI_LsrSet2 70
 LSRI_LsrSet3 70
 LSRI_LsrShutterClosed 70
 LSRI_LsrStandby 70
 LSRI_LsrUserSafety 71
 LSRI_LsrWarnLampOn 70
 LSRI_UsrInput1 72
 LSRI_UsrInput2 72
 LSRO_AntiCollisionDev 71
 LSRO_ColdFor1Seam 71
 LSRO_ColdFor1Section 71
 LSRO_ColdForEver 71
 LSRO_CrossJet 71
 LSRO_Error_Bypass 72
 LSRO_Error_Cell 71
 LSRO_Error_Media 71
 LSRO_Error_Sensor 71
 LSRO_GasEnable 71
 LSRO_GasPressure 67, 71
 LSRO_LsrDataWord0 70
 LSRO_LsrDataWord3 70
 LSRO_LsrDataWord4 70
 LSRO_LsrExternControl 70
 LSRO_LsrFaultExtern 69
 LSRO_LsrFiber 70
 LSRO_LsrLaserNr 70
 LSRO_LsrOn 70
 LSRO_LsrOperationOff 70
 LSRO_LsrPilotOn 69
 LSRO_LsrPrgNrBCD1 70
 LSRO_LsrPrgNrBCD10 70
 LSRO_LsrPrgSetDual 70
 LSRO_LsrPwr 67, 70
 LSRO_LsrRequest 40, 69
 LSRO_LsrReset 69
 LSRO_LsrRmpDownEndVal 70
 LSRO_LsrRmpDownStartVal 70
 LSRO_LsrRmpUpEndVal 70
 LSRO_LsrRmpUpStartVal 70
 LSRO_LsrRobotNr 70
 LSRO_LsrStandby 70
 LSRO_LsrStartDynamic 70
 LSRO_LsrStartStatic 70
 LSRO_LsrStopProgram 70
 LSRO_LsrSync1 69
 LSRO_LsrSync2 69
 LSW_Heat_AnalogMaxValue 77
 LSW_Heat_AnalogMiniValue 77
 LSW_HotWireOption 76
 LSW_ReducedLimitWfdValue 77
 LSW_StaticRedWfdOption 76
 LSW_UseWFDVelCtrlId 76
 LSW_UseWireFeed 76
 LSW_WFD_AnalogMaxValue 77
 LSW_WFD_AnalogMinValue 77
 LSW_WFD_DELAY 77
 LSW_WfdDistanceMax 76
 LSW_WireFeedMaximum 77
 LSW_WireFeedMinimum 77
 LSW_WireHeatDelayConst 77
 LSW_WireHeatMaximum 77
 LSW_WireHeatMinimum 77
 LSWI_WireFeedHeatControl 76
 LSWI_WireFeedReady 76
 LSWO_ErrorWireFeeder 76
 LSWO_ErrorWireHeat 76
 LSWO_WireFeedChannel 67, 76
 LSWO_WireFeedForward 75
 LSWO_WireFeedHeatChan 67, 76
 LSWO_WireFeedHeater 76
 LSWO_WireFeedStart 75

M

Media control 43
 Menus 15
 Messages 61
 Minimum wire feed rate 32, 33

O

Operation 15
 Outputs 67

P

Pilot laser 21, 69, 70
 PreDelay 75
 Process gas 8
 Process, deactivating 28
 Process, switching 27

Product description 9
Programming 23
PwrScale 75

R

Ramp time 23
Ramp time, modification 22
Root gas 8

S

S_Int_Cycl 74
S_Int_Flag 72
Safety 11
Safety instructions 7
Sensor control 45
Sensor, settings 46
Service, KUKA Roboter 81
SIGNAL LSRO_LsrRampTime 70
Spline 23, 47
Standstill monitoring 64
Start-up 19
Status keys 15, 16
Step seams 29, 30
Support request 81
Switching points 25
System requirements 13

T

Target group 7
Terms used 8
Timers 67
Trademarks 8
Training 7

U

Uninstallation, LaserTech 14
Update, LaserTech 13

W

Warnings 7
Wire, cutting 44
Wirefeed 32, 33
Wirefeed delay 32, 33, 34

