


# KUKA

**KUKA System Technology**

KUKA Roboter GmbH

## **KUKA.LaserTech 3.1**

**For KUKA System Software 8.3**



Issued: 18.09.2013

Version: KST LaserTech 3.1 V1

© Copyright 2013

KUKA Roboter GmbH  
Zugspitzstraße 140  
D-86165 Augsburg  
Germany

This documentation or excerpts therefrom may not be reproduced or disclosed to third parties without the express permission of KUKA Roboter GmbH.

Other functions not described in this documentation may be operable in the controller. The user has no claims to these functions, however, in the case of a replacement or service work.

We have checked the content of this documentation for conformity with the hardware and software described. Nevertheless, discrepancies cannot be precluded, for which reason we are not able to guarantee total conformity. The information in this documentation is checked on a regular basis, however, and necessary corrections will be incorporated in the subsequent edition.

Subject to technical alterations without an effect on the function.

Translation of the original documentation

KIM-PS5-DOC

Publication:	Pub KST LaserTech 3.1 (PDF) en
Book structure:	KST LaserTech 3.1 V1.2
Version:	KST LaserTech 3.1 V1

## Contents

<b>1</b>	<b>Introduction</b>	7
1.1	Target group	7
1.2	Industrial robot documentation	7
1.3	Representation of warnings and notes	7
1.4	Terms used	8
1.5	Trademarks	8
<b>2</b>	<b>Product description</b>	9
2.1	LaserTech – overview	9
2.2	Laser power and path velocity	9
2.3	Intended use	10
<b>3</b>	<b>Safety</b>	13
<b>4</b>	<b>Installation</b>	15
4.1	System requirements	15
4.2	Installing or updating KUKA.LaserTech	15
4.3	Uninstalling LaserTech	16
<b>5</b>	<b>Operation</b>	17
5.1	Menus	17
5.2	Basic laser function status keys	17
5.3	LaserCut status keys	18
<b>6</b>	<b>Start-up and configuration</b>	21
6.1	Overview	21
6.2	Variables for configuration of LaserTech	21
6.3	Laser program	22
6.4	Configuring gas types for inline forms	23
6.5	Configuring the inputs/outputs for gases and other properties	24
6.6	Configuring the pilot laser	25
6.7	Modifying maximum values for ramp times	26
<b>7</b>	<b>Programming for user group “User” (inline forms)</b>	27
7.1	Programming with spline	27
7.2	Programming tips for KUKA.LaserTech	27
7.2.1	Defining delay times	28
7.3	Programming laser functions	29
7.3.1	Inline form “ <b>Activate process</b> ”	29
7.3.2	Inline form “ <b>Switch process</b> ”	31
7.3.3	Inline form “ <b>Deactivate process</b> ”	33
7.3.4	Inline form “ <b>Step seam</b> ”	35
7.3.5	Inline form “ <b>Laser test pulse</b> ”	36
7.3.6	Option window “Media setting” – activating laser welding	37
7.3.7	Option window “Media setting” – switching laser welding	38
7.3.8	Option window “Media setting” – deactivating laser welding	39
7.3.9	Option window “ <b>Laser data</b> ” – <b>Activate process/Step seam</b> (via time)	40
7.3.10	Option window “ <b>Laser data</b> ” – <b>Activate process/Step seam</b> (via distance)	41
7.3.11	Option window “ <b>Laser data</b> ” – <b>Switch process</b>	42

7.3.12	Option window “ <b>Laser data</b> ” – <b>Deactivate process</b> (via time) .....	42
7.3.13	Option window “ <b>Laser data</b> ” – <b>Deactivate process</b> (via distance) .....	43
7.3.14	Option window – user-defined data set .....	44
7.3.15	Option window “ <b>Step parameters</b> ” .....	44
7.3.16	Option window “ <b>Laser data</b> ” – “ <b>Laser test pulse</b> ” .....	45
7.4	Programming laser control .....	45
7.4.1	Inline form “ <b>Initialize laser</b> ” .....	45
7.4.2	Inline form “ <b>Enable laser</b> ” .....	46
7.4.3	Inline form “ <b>Laser off</b> ” .....	47
7.4.4	Inline form “ <b>Laser request</b> ” .....	47
7.4.5	Option window “Gas selection” – laser welding .....	48
7.4.6	Option window “Gas selection” – laser cutting .....	49
7.4.7	Option window “ <b>Laser network</b> ” – “ <b>Initialize laser</b> ” .....	49
7.5	Programming media control .....	50
7.5.1	Inline form “ <b>Switch gas</b> ” .....	50
7.5.2	Inline form “ <b>Initialize gas</b> ” .....	50
7.5.3	Inline form “ <b>Cut wire</b> ” .....	51
7.6	Programming sensor control .....	52
7.6.1	Inline form “ <b>Switch sensor</b> ” .....	52
7.6.2	Inline form “ <b>Sensor settings</b> ” .....	53
7.7	Programming laser cutting .....	54
7.7.1	Inline form “ <b>Rectangle</b> ”, “ <b>Slot</b> ”, “ <b>Hexagon</b> ”, “ <b>Circle</b> ” .....	54
7.7.2	Option windows “Geometry data” and “Geo motion data” .....	55
7.7.3	Option window: <b>Frames</b> .....	58
7.7.4	Option window “ <b>Media data</b> ” – activating laser cutting .....	59
7.7.5	Option window “ <b>Media data</b> ” – switching laser cutting .....	59
7.7.6	Option window “ <b>Media data</b> ” – deactivating laser cutting .....	60
7.7.7	Option window “ <b>Laser data</b> ” – <b>Rectangle, Slot, Hexagon, Circle</b> .....	60
7.7.8	Option window “ <b>Sensor parameters</b> ” and “ <b>Process parameters</b> ” .....	61
<b>8</b>	<b>Example programs</b> .....	<b>63</b>
8.1	Example program: step seam .....	63
8.2	Example program: gas and laser welding functions .....	64
8.3	Example program: set piercing and cutting data .....	65
8.4	Example program: piercing function .....	65
<b>9</b>	<b>Programming for system integrators</b> .....	<b>67</b>
9.1	Configuring user-defined applications .....	67
9.1.1	Changing list entries in the inline forms .....	67
9.1.2	Changing parameter names and units in the option window .....	68
9.2	Integration of user-defined functions .....	68
9.3	Interfaces for functional expansions .....	70
9.3.1	Interface to the laser process LSR_Tech_IFC .....	70
9.3.2	Interface to the laser control LSR_Tech_IFC .....	72
9.3.3	Interface to media LSR_Media_IFC .....	72
9.3.4	Interface to error handling LSR_ERR_IFC .....	73
<b>10</b>	<b>Messages</b> .....	<b>75</b>
10.1	Basic laser function messages .....	75

10.2	LaserCut messages .....	79
10.3	LaserWeld messages .....	79
<b>11</b>	<b>Appendix .....</b>	<b>81</b>
11.1	Configuring LaserTech .....	81
11.1.1	LaserTech: analog inputs/outputs, interrupts, timers and cyclical flags .....	81
11.1.2	LaserTech: signal outputs to the laser .....	82
11.1.3	LaserTech: signal inputs from the laser .....	83
11.1.4	LaserTech: signal outputs to the welding periphery .....	84
11.1.5	LaserTech: signal inputs from the welding periphery .....	85
11.1.6	LaserTech: system outputs and system flags .....	85
11.1.7	LaserTech: process options .....	86
11.1.8	LaserTech: process constants .....	88
11.2	Configuring LaserWeld .....	90
11.2.1	LaserWeld: analog inputs/outputs .....	90
11.2.2	LaserWeld: signal outputs to the wire feed system .....	90
11.2.3	LaserWeld: signal inputs from the wire feed system .....	91
11.2.4	LaserWeld: process constants .....	91
11.3	Configuring LaserCut .....	93
11.3.1	LaserCut: analog inputs/outputs .....	93
11.3.2	LaserCut: signal outputs to the sensor .....	93
11.3.3	LaserCut: signal inputs from the sensor .....	94
11.3.4	LaserCut: process constants .....	95
<b>12</b>	<b>KUKA Service .....</b>	<b>97</b>
12.1	Requesting support .....	97
12.2	KUKA Customer Support .....	97
	<b>Index .....</b>	<b>105</b>



# 1 Introduction

## 1.1 Target group

This documentation is aimed at users with the following knowledge and skills:

- Advanced KRL programming skills
- Advanced knowledge of the robot controller system
- Advanced knowledge of the laser controller systems
- Knowledge of the other peripheral controller systems (e.g. distance controller)
- Knowledge of field bus interfaces



For optimal use of our products, we recommend that our customers take part in a course of training at KUKA College. Information about the training program can be found at [www.kuka.com](http://www.kuka.com) or can be obtained directly from our subsidiaries.

## 1.2 Industrial robot documentation

The industrial robot documentation consists of the following parts:

- Documentation for the manipulator
- Documentation for the robot controller
- Operating and programming instructions for the control software
- Instructions for options and accessories
- Parts catalog on storage medium

Each of these sets of instructions is a separate document.

## 1.3 Representation of warnings and notes

### Safety

These warnings are relevant to safety and **must** be observed.



**DANGER** These warnings mean that it is certain or highly probable that death or severe injuries **will** occur, if no precautions are taken.



**WARNING** These warnings mean that death or severe injuries **may** occur, if no precautions are taken.



**CAUTION** These warnings mean that minor injuries **may** occur, if no precautions are taken.



**NOTICE** These warnings mean that damage to property **may** occur, if no precautions are taken.



These warnings contain references to safety-relevant information or general safety measures.  
These warnings do not refer to individual hazards or individual precautionary measures.

This warning draws attention to procedures which serve to prevent or remedy emergencies or malfunctions:

**SAFETY  
INSTRUCTIONS**

Procedures marked with this warning **must** be followed exactly.

**Notes**

These hints serve to make your work easier or contain references to further information.



Tip to make your work easier or reference to further information.

**1.4 Terms used**

Term	Description
CrossJet	Gas that keeps the lens of the laser free of dirt.
Laser program	Program executed in the laser controller.
Process gas	The process gas keeps the welding site free from oxygen, thereby protecting the seam against oxidation.
Root gas	Process gas that protects the seam against oxidation from beneath. Only relevant in the case of through-welding of the plate and if gas can be fed in from underneath.

**1.5 Trademarks**

**TruControl** is a trademark of Trumpf.




## 2 Product description

### 2.1 LaserTech – overview

#### Functions

LaserTech is an add-on technology package with the following functions:

- Configuration and programming of laser applications (standard LaserTech package)
- Configuration and programming of laser cutting applications (LaserCut)
- Configuration and programming of laser welding applications with/without filler wire (LaserWeld)
- Configuration and programming of up to 3 user-defined laser applications

 The backwards movement option is deactivated when working with this technology package.

#### Areas of application

- Laser cutting
- Laser welding
- LaserTech can be expanded for further user-defined applications, e.g. powder surfacing

KUKA.LaserTech supports the following systems:

- TRUMPF laser controllers
- PRECITEC distance controllers (for laser cutting)

For information about adaptation for systems from other manufacturers, please contact KUKA Customer Support. (>>> 12 "KUKA Service" Page 97)

#### Communication

The robot controller communicates with the laser controller via a field bus.

### 2.2 Laser power and path velocity

In LaserTech, a weld program is executed by default with a constant laser power. The variable LSR\_UsePwrVelCtrlId can be used to configure whether the laser power is regulated proportionally to the robot velocity. This means: if the programmed robot velocity is not reached, LaserTech reduces the laser power accordingly.

The proportionality is restricted by the upper and lower power limits of the laser. The lower power limit of the laser is always > 0, as the laser power cannot be regulated down to 0.




Fig. 2-1: Relationship between velocity and laser power

- 1 Laser power in watts
- 2 Upper laser power limit
- 3 Lower laser power limit
- 4 Velocity in m/s

## 2.3 Intended use

### Use

LaserTech is intended exclusively for industrial operation in an enclosed cell conforming to the applicable laser protection conditions and safety standards.

The system integrator must ensure that the robot system is installed and operated in an environment that is suitable for laser applications. In particular, it is important to consider the hazards which could arise from incorrect user programming and unintended activation of the laser, e.g. with the result that the laser hits the cell wall or fixture.

**WARNING** It must be ensured that no persons are present in the cell when the laser is enabled or active. Severe injuries may otherwise result.

Operation in accordance with the intended use also involves compliance with the start-up and configuration instructions in this documentation.

### Misuse

Any use or application deviating from the intended use is deemed to be impermissible misuse. The manufacturer cannot be held liable for any damage resulting from such use. The risk lies entirely with the user.

Examples of such misuse include:

- Bypassing of protective mechanisms such as the safety door and safety circuit of the laser
- Programming the application in a such a way that the enabled laser beam does not hit the intended area, e.g. the workpiece, but the cell wall or fixture.
- Program execution (T2, AUT, EXT) without a workpiece in the fixture. This can result in the laser beam directly hitting the fixture.
- Activation of the laser by setting inputs/outputs in test mode (T1, T2) with the safeguard closed.

- Use in non-industrial systems



### 3 Safety

This documentation contains safety instructions which refer specifically to the software described here.

The fundamental safety information for the industrial robot can be found in the “Safety” chapter of the Operating and Programming Instructions for System Integrators or the Operating and Programming Instructions for End Users.



The “Safety” chapter in the operating and programming instructions of the KUKA System Software (KSS) must be observed. Death to persons, severe injuries or considerable damage to property may otherwise result.



The safety standards must be observed when working with the laser. Injuries or damage to property may otherwise result. For further information and specification of the laser class, please refer to the documentation of the laser manufacturer.



The safety measures of the laser system must be observed when wiring the system. In particular the EMERGENCY STOP circuit and operator safety must be wired correctly before this software is used. Injuries or damage to property may otherwise result. The safety measures of the laser system can be found in the documentation of the laser manufacturer.




## 4 Installation

### 4.1 System requirements

- Hardware**
- KR C4
  - KUKA field bus cards (Interbus or PROFIBUS)
  - Specific components for the application
- Software**
- KUKA System Software 8.3

### 4.2 Installing or updating KUKA.LaserTech

 It is advisable to archive all relevant data before updating a software package.


- Preparation**
- Copy software from CD to KUKA USB stick.  
The software must be copied onto the stick with the file Setup.exe at the highest level (i.e. not in a folder).

**NOTICE** Recommendation: Use a KUKA stick. Data may be lost if any other stick is used.

- Precondition**
- “Expert” user group

- Procedure**
1. Connect the USB stick to the robot controller or smartPAD.
  2. In the main menu, select **Start-up > Additional software**.
  3. Press **New software**. The entry **LaserTech** must be displayed in the **Name** column and drive **E:\** or **K:\** in the **Path** column.  
If not, press **Refresh**.
  4. If the specified entries are now displayed, continue with step 5.  
If not, the drive from which the software is being installed must be configured first:
    - Press the **Configuration** button. A new window opens.
    - Select a line in the **Installation paths for options** area.  
**Note:** If the line already contains a path, this path will be overwritten.
    - Press **Browse**. The available drives are displayed.
    - Select **E:\**. (If stick connected to the robot controller.)  
Or select **K:\**. (If stick connected to the smartPAD.)
    - Press **Save**. The window closes again.

The drive only needs to be configured once and then remains saved for further installations.
  5. Mark the entry **LaserTech** and click on **Install**. Answer the request for confirmation with **Yes**.
  6. Confirm the reboot prompts with **OK**.
  7. Remove the stick.
  8. Reboot the robot controller.  
On rebooting, a reminder is displayed about installing the LaserWeld and LaserCut options. If the reminder should not be displayed again, select **No longer ask**.

 During installation of LaserTech, the LaserWeld and LaserCut options are copied to the directory D:\KUKA\_OPT. If required, the options must be installed separately from this directory.

**LOG file** A LOG file is created under C:\KRC\ROBOTER\LOG.

### 4.3 Uninstalling LaserTech



It is advisable to archive all relevant data before uninstalling a software package.

**Precondition** ■ “Expert” user group

**Procedure**

1. Select **Start-up > Install additional software** in the main menu. All additional programs installed are displayed.
2. Depending on which part of the technology package is to be uninstalled, select the corresponding entry:
  - LaserTech: select the entry **LaserTech**.
  - LaserWeld: select the entry **LaserWeld**.
  - LaserCut: select the entry **LaserCut**.
3. Press **Uninstall**. Reply to the request for confirmation with **Yes**. Uninstallation is prepared.
4. Reboot the robot controller. Uninstallation is resumed and completed.

**LOG file** A LOG file is created under C:\KRC\ROBOTER\LOG.



## 5 Operation

### 5.1 Menus

The following menus and commands are specific to this technology package:

Main menu:

- **Configuration > Status keys**
  - LaserTech
  - Laser Cut

Menu sequence **Commands > LaserTech**













- **Switching**
  - Activate process
  - Switch process
  - Deactivate process
  - Step seam
  - Laser test pulse
- **Control commands**
  - Initialize laser
  - Enable laser
  - Laser off
  - Laser request
- **Media control**
  - Switch gas
  - Initialize gas
  - Cut wire
- **Sensor control**
  - Switch sensor
  - Sensor settings
- **Cutting**
  - Rectangle
  - Slot
  - Hexagon
  - Circle

### 5.2 Basic laser function status keys

Select **Configuration > Status keys > LaserTech** in the main menu to display the status keys.

For safety reasons, the status keys are deactivated. To activate them, the enabling switch on the smartPAD must be pressed.

The status keys are not available in Automatic External mode.







	Off	On	Inactive	Description
Laser				<p>The status key "Laser off" is displayed: the program is executed without laser power.</p> <p>The status key "Laser on" is displayed: the program is executed with laser power.</p>
Pilot laser				<p>Pressing "Pilot laser off" switches the pilot laser on.</p> <p>Pressing "Pilot laser on" switches the pilot laser off.</p>
Gas				<p>Pressing "Gas off" activates the process gas, root gas and Cross-Jet.</p> <p>Releasing the status key stops the flow of gas.</p> <p><b>Note:</b> When process gas, root gas and CrossJet is activated, the high pressure of the emerging gas may result in injuries and in material damage to sensitive system components. Do not aim the gas at the body.</p>
Wire				<p>Pressing "Wire off" activates the wire feed.</p> <p>Releasing the status key stops the wire feed.</p> <p><b>Note:</b> Welding wire emerging from the wire feeder can cause injuries to hands, face and eyes. Be sure to maintain a safe distance.</p>





### 5.3 LaserCut status keys

Select **Configuration > Status keys > Laser Cut** in the main menu to display the status keys.

For safety reasons, the status keys are deactivated. To activate them, the enabling switch on the smartPAD must be pressed.

The status keys are not available in Automatic External mode.

	Off	On	Inactive	Description
Sensor				<p>Status key "Sensor off" is displayed: the sensor functions are inactive.</p> <p>Status key "Sensor on" is displayed: the sensor functions are active.</p>
Distance control				<p>Pressing "Distance control Off" switches distance control on.</p> <p>Pressing "Distance control On" switches distance control off.</p>

	Off	On	Inactive	Description
Reference run	—			Pressing “Reference run on” starts a reference run.
Sensor in position	—			Pressing “Sensor in position” moves the sensor to the “programmed position”.



## 6 Start-up and configuration

### 6.1 Overview

Step	Description
1	Install and prepare the laser controller; in particular: prepare the laser program. (>>> 6.3 "Laser program" Page 22)
2	Configure the field bus between the robot controller and the laser controller in WorkVisual.
3	Configure the inputs and outputs to integrate the required peripheral equipment. <ul style="list-style-type: none"> <li>■ Laser and other peripheral welding equipment (standard LaserTech package)</li> <li>■ Wire feed system (LaserWeld)</li> <li>■ Sensor system (LaserCut)</li> </ul> (>>> 6.2 "Variables for configuration of LaserTech" Page 21)
4	Calibrate the tool and base.
5	Configure gas types for inline forms. (>>> 6.4 "Configuring gas types for inline forms" Page 23)
6	Configure the inputs/outputs for gases and other properties. (>>> 6.5 "Configuring the inputs/outputs for gases and other properties" Page 24)
7	Configure the program number for the pilot laser. (>>> 6.6 "Configuring the pilot laser" Page 25)
8	If required: modify the maximum values for ramp times. (>>> 6.7 "Modifying maximum values for ramp times" Page 26)
9	If required: expand the technology for user-defined applications. (>>> 9.1 "Configuring user-defined applications" Page 67) (>>> 9.2 "Integration of user-defined functions" Page 68)

### 6.2 Variables for configuration of LaserTech



The variables for configuring LaserTech are described in the appendix.

Some of these variables, e.g. the process options, can be displayed and changed via the variable correction function.

To configure the inputs and outputs for interfacing with the peripheral equipment, the \$CONFIG.DAT file in the directory R1\System must be edited.

## Overview

Editor	
1	BASISTECH GLOBALS
2	AUTOEXT GLOBALS
3	LASERTECH GLOBALS
4	LASER OUTPUTS
5	LASER INPUTS
6	
7	INTEGRATION peripheri devices
8	
9	LASERWELD GLOBALS
10	LASERCUT GLOBALS
11	USER GLOBALS

Fig. 6-1: Folds in \$CONFIG.DAT

Line	Description
3 ... 7	<p>LASERTECH GLOBALS</p> <p>Here the inputs/outputs are configured which are used by the standard LaserTech package.</p> <ul style="list-style-type: none"> <li>■ LASER OUTPUTS (&gt;&gt;&gt; 11.1.2 "LaserTech: signal outputs to the laser" Page 82)</li> <li>■ LASER INPUTS (&gt;&gt;&gt; 11.1.3 "LaserTech: signal inputs from the laser" Page 83)</li> <li>■ INTEGRATION peripheri devices (&gt;&gt;&gt; 11.1.5 "LaserTech: signal inputs from the welding periphery" Page 85)</li> <li>■ (&gt;&gt;&gt; 11.1.4 "LaserTech: signal outputs to the welding periphery" Page 84)</li> </ul>
9	<p>LASERWELD GLOBALS</p> <p>Here the inputs/outputs are configured which are used by LaserWeld.</p> <ul style="list-style-type: none"> <li>■ OUTPUTS WIREFEEDER (&gt;&gt;&gt; 11.2.2 "LaserWeld: signal outputs to the wire feed system" Page 90)</li> <li>■ WIRE CONTROL --&gt; PLC (&gt;&gt;&gt; 11.2.2 "LaserWeld: signal outputs to the wire feed system" Page 90)</li> <li>■ INPUTS WIREFEEDER (&gt;&gt;&gt; 11.2.3 "LaserWeld: signal inputs from the wire feed system" Page 91)</li> </ul>
10	<p>LASERCUT GLOBALS</p> <p>Here the inputs/outputs are configured which are used by LaserCut.</p> <p>(&gt;&gt;&gt; 11.3.2 "LaserCut: signal outputs to the sensor" Page 93)</p> <p>(&gt;&gt;&gt; 11.3.3 "LaserCut: signal inputs from the sensor" Page 94)</p>

### 6.3 Laser program

On the laser controller there must be a laser program which can read in the parameters from an external controller (robot).



Fig. 6-2: Required laser program (example)

## 6.4 Configuring gas types for inline forms

**Description** In the file C:\KRC\TP\LaserTech\LIB\LsrTech.XML, the user defines how many types of which gas are to be available in the inline forms. The names displayed in the inline forms for the gases can also be changed.

A maximum of 12 types of gas can be configured.

**Precondition**

- "Expert" user group
- Windows interface (smartHMI is minimized).



Only the changes described in the procedure may be made in the file LsrTech.XML!

### Procedure

1. Open the file C:\KRC\TP\LaserTech\LIB\LsrTech.XML.
2. Find the section for gases in the file.
  - Process gases: section `ProcessGas`
  - Root gases: section `RootGas`
  - Cutting gases: section `CutGas`
3. To change the name of a gas, modify a value of `EnumValue Key`.
4. To add a gas, copy a line that starts with `EnumValue Key` and paste it after the other lines. Renumber the values of `KrlValue="..."` and `OrderID="..."`.
5. Close the file by means of the **Close** icon and answer the request for confirmation with **Yes**. The file is saved.

### Example

Excerpt from the `ProcessGas` section. The structure of the sections for the other gases is analogous.

```

...
<TechParam xsi:type="TechParamEnum" Name="ProcessGas" ...
  <EnumValues Max="12">
    <EnumValue Key="Gas1" KrlValue="1" OrderID="0"
VisibleStyle="Allways"/>
    <EnumValue Key="Gas2" KrlValue="2" OrderID="1"
VisibleStyle="Allways"/>
    <EnumValue Key="Gas3" KrlValue="3" OrderID="2"
VisibleStyle="Allways"/>
    <EnumValue Key="Gas4" KrlValue="4" OrderID="3"
VisibleStyle="Allways"/>
  </EnumValues>
</TechParam>
...

```

## 6.5 Configuring the inputs/outputs for gases and other properties

### Precondition

- “Expert” user group
- No program is selected.

### Procedure

1. Open the desired file.
  - Process gases: R1\TP\LaserTech\laser.dat  
Open the `Process Gas Settings` fold.
  - Cutting gases: R1\TP\LASERCUT\lsc\_main.dat  
Open the `Cut Gas Settings` fold.
  - Root gases: R1\TP\LaserTech\laser.dat  
Open the `Root Gas Settings` fold.
2. Edit the file.
3. Close the file by means of the **Close** icon and answer the request for confirmation with **Yes**. The file is saved.

### Description

Excerpt from the `Process Gas Settings` fold in the file `laser.dat`. The excerpt shows the default properties defined. The structure of the folds in the other files is analogous.

```

LSR_ProcGAS[1]={OUT_NR 1024,IN_NR 1025,ANA_GAS_OUT TRUE,
ANA_GAS_IN TRUE,ExtIf FALSE,ANA_MAX_VALUE 30.0,GAS_NAME[] "NONE"}

```

The configuration depends on whether a proportional gas valve is used.

### Without valve

LSR\_PropGasValve = FALSE

Element	Description
OUT_NR	Number of the digital output that is used to activate the gas
IN_NR	Number of the digital input that is used to indicate that the gas has been activated
ANA_GAS_OUT	Only FALSE meaningful. FALSE = this gas does not use a proportional gas valve.
ANA_GAS_IN	The currently measured gas pressure is returned to this analog channel.
ExtIf	TRUE = advanced monitoring. Not only IN_NR is polled, but also the actual analog value of the gas pressure.
ANA_MAX_VALUE	Maximum gas pressure. This value is irrelevant.
GAS_NAME[]	Name of the gas (default: “NONE”) Changing the name does not have any effect.



**With valve**

LSR\_PropGasValve = TRUE

Element	Description
OUT_NR	Number of the digital output that is used to activate the gas  <b>Note:</b> The number of the analog channel is defined via the variable LSRI_GasPressure
IN_NR	Number of the digital input that is used to indicate that the gas pressure is OK  <b>Note:</b> The number of the analog channel is defined via the variable LSRI_GasPressure
ANA_GAS_OUT	TRUE = this gas uses a proportional gas valve.  FALSE = this gas does not use a proportional gas valve.
ANA_GAS_IN	The currently measured gas pressure is returned to this analog channel.
ExtIf	TRUE = advanced monitoring. Not only IN_NR is polled, but also the actual analog value of the gas pressure.
ANA_MAX_VALUE	Maximum gas pressure transferred by the laser controller. If a higher value is set in the inline form, the lower value set here nonetheless applies.  Unit: bar. Value must be greater than 0.0.
GAS_NAME[]	Name of the gas (default: "NONE")  Changing the name does not have any effect.

## 6.6 Configuring the pilot laser

**Description** In the file R1\TP\LaserTech\laser.dat, the program number is defined that is to be selected internally when the pilot laser is switched on using the status key. The program number must be present in the laser controller.

**Precondition**

- "Expert" user group
- No program is selected.

**Procedure**

1. Open the file R1\TP\LaserTech\laser.dat.
2. Open the `Temporary Process Setting` fold. In the following declaration, specify the desired program number for the element `LSR_PRG`.

```
DECL GLOBAL LSR_PWR_T LSR_LsrPilotSet={LSR_MAX_PWR 2000,
LSR_MIN_PWR 1,LSR_PRG 20,LSR_RAISE_TIME 1,LSR_DROP_TIME 1}
```

In this example, laser program 20 is selected (`LSR_PRG 20`). In order to be able to use the pilot laser, there must be a program with the number 20 on the laser controller.



The correct fiber number must be entered in the laser program that is selected here. Otherwise it is possible that the pilot laser will not be visible.

3. Close the file by means of the **Close** icon and answer the request for confirmation with **Yes**. The file is saved.

## 6.7 Modifying maximum values for ramp times

<b>Description</b>	<p>The ramp time when switching on (Laser power rise time) is programmed in the option window <b>Laser data – Activate process</b>.</p> <p>(&gt;&gt;&gt; 7.3.9 "Option window "Laser data" – Activate process/Step seam (via time)" Page 40)</p> <p>The ramp time when switching off (Laser power drop time) is programmed in the option window <b>Laser data – Deactivate process</b>.</p> <p>(&gt;&gt;&gt; 7.3.12 "Option window "Laser data" – Deactivate process (via time)" Page 42)</p> <p>The maximum values that can be set in the option windows can be modified in the registry.</p>
<b>Precondition</b>	<ul style="list-style-type: none"><li>■ "Expert" user group</li><li>■ Windows interface (smartHMI is minimized).</li><li>■ Administrator privileges on the Windows user interface</li></ul>
<b>Procedure</b>	<ol style="list-style-type: none"><li>1. In the Windows Start menu, select <b>Run....</b></li><li>2. In the <b>Open</b> box, enter "regedit" and press <b>OK</b>. The <b>Registry editor</b> window opens.</li><li>3. Select the following folder under "HKEY_CURRENT_USER\Software\VB and VBA Program Settings\KUKATPLASER\" in the tree structure:<ul style="list-style-type: none"><li>■ LSR_DROP_TIME (for ramp time when switching off)</li><li>■ LSR_RAISE_TIME (for ramp time when switching on)</li></ul></li><li>4. Click on the parameter <b>Max</b> and select <b>Change</b>.</li><li>5. Enter the desired value and confirm it by pressing <b>OK</b>.</li><li>6. Reboot the robot controller with a cold restart.</li></ol>

## 7 Programming for user group "User" (inline forms)

### NOTICE

Following creation of a laser program or modification of laser and motion commands, the program sequence, the actual switching points of the laser and the periphery must be checked. Damage to the system may otherwise result.

### 7.1 Programming with spline

#### Overview

The overview shows which LaserTech commands can be used in spline blocks.

Command	Usable in spline block?
Activate process	Yes
Switch process	Yes
Deactivate process	Yes
Step seam	Yes
Laser test pulse	No
Initialize laser	No
Enable laser	Yes
Laser off	No
Laser request	No
Switch gas	Yes
Initialize gas	No
Cut wire	No
Switch sensor	Yes
Sensor settings	Yes
Rectangle, Slot, Hexagon, Circle	No

### 7.2 Programming tips for KUKA.LaserTech

#### Power ramps

Power ramps can be defined over time or over distance. Which of the two functionalities is available depends on whether the laser is switched on and off inside or outside of a spline block.

- Laser is switched on/off within a spline block:  
Power ramps are defined via distance, e.g. the length of the power rise on switching on the laser.
- Laser is switched on/off outside a spline block:  
Power ramps are defined via time, e.g. the rise time of the laser power on switching on the laser.

#### Delay times

(>>> 7.2.1 "Defining delay times" Page 28)

#### Standstill monitoring

If the robot is stationary and the laser power is active, the shutter automatically closes after a defined time. This time is defined via the variable LSR\_Stop\_InspectionTime. The purpose is to prevent the laser from burning through the material.

If welding is to be carried out for longer at a specific position, i.e. without robot motion, the value of LSR\_Stop\_InspectionTime must be increased.

(>>> 11.1.8 "LaserTech: process constants" Page 88)

**NOTICE** If the value of LSR\_Stop\_InspectionTime is changed or if the option is deactivated, this can result in damage to the system.

If a laser pulse is generated using the instruction **Laser test pulse**, standstill monitoring is not active.

- Switching points**
- Program switching points in phases in which the velocity is as constant as possible.
  - If a switching action is to be carried out before the taught point, the approximate positioning radius must be selected in such a way that the action is executed in the approximate positioning range of the point.
- Circles**
- To generate full circles, it is advisable not to teach the coordinates, but to calculate them.
  - If the KUKA.ExpertTech technology package is available, use the specification **CA** for the circular angle.

### 7.2.1 Defining delay times

#### Description

The delay times are defined using the following variables:

- Delay time when switching on = LSR\_ShutterDelayConst + LSR\_ShutterOn
- Delay time when switching off = LSR\_ShutterDelayConst + LSR\_ShutterOff
- Delay time when switching over = LSR\_ShutterDelayConst - LSR\_ShutterOn

(>>> 11.1.8 "LaserTech: process constants" Page 88)



These variables are only used to compensate for delay times. They must not be used to offset switching points.

**NOTICE** If laser programs are already present and the delay times are changed, this can cause the activation and deactivation points of the laser to be shifted so far that damage to the device or other system components can result. Check existing programs following a modification.

#### Procedure

1. Program the weld seams.
2. Determine the required delay times empirically.
3. Change the following variables in the variable correction function, in accordance with the determined times:
  - LSR\_ShutterDelayConst
  - LSR\_ShutterOn
  - LSR\_ShutterOff
4. For the other weld velocities, adapt the switching points by means of the Path specification in the inline forms.

#### Example 1

Required delay:

- When switching on: 80 ms
- When switching off: 50 ms
- When switching over: 20 ms

Define variables:

- LSR\_ShutterDelayConst = 50

- LSR\_ShutterOn = 30
- LSR\_ShutterOff = 0

**Example 2**

Required delay:

- When switching on: 80 ms
- When switching off: 50 ms
- When switching over: 0 ms

If the delay when switching over is to be 0 ms, LSR\_ShutterDelayConst and LSR\_ShutterOn must always have the same value.

Define variables:

- LSR\_ShutterDelayConst = 40
- LSR\_ShutterOn = 40
- LSR\_ShutterOff = 10

## 7.3 Programming laser functions

### 7.3.1 Inline form "Activate process"

**Call**

- Select the menu sequence **Commands > LaserTech > Switching > Activate process**.

**Description**

This instruction switches the laser on.




This instruction refers to the next motion instruction in the program. This motion instruction must be a CP motion. There must be no instructions triggering an advance run stop between the laser instruction and the motion instruction.

The CP motion to the laser activation position is generally approximated. In the case of exact positioning to the point, the laser is aimed at the point for longer than in the case of approximate positioning. This means that more energy is directed onto the point than is generally desirable.

If the CUT application is selected, the piercing and cutting data for laser cutting can optionally be defined.

If the piercing and cutting data are defined, the instruction calls a piercing function that implicitly activates the distance sensor. In this case, the instruction replaces the instruction **Switch sensor**.

(>>> 7.6.1 "Inline form "Switch sensor"" Page 52)



**Fig. 7-1: Inline form "Activate process" (with Weld)**




Fig. 7-2: Inline form “Activate process” (with Cut)




Fig. 7-3: Inline form “Activate process” (with UserSet)

Item	Description
1	<p>Selects an application.</p> <ul style="list-style-type: none"> <li>■ <b>[Empty box]</b>: Only displayed if LaserWeld is not installed.</li> <li>■ <b>WELD</b>: Laser welding (with wire feed)</li> <li>■ <b>CUT</b>: Laser cutting</li> <li>■ <b>USR_LSR, USR_TCH, USR_LMB</b>: Up to 3 user-defined applications possible (default entries)</li> </ul>
2	<p>Shifts the activation point of the laser.</p> <ul style="list-style-type: none"> <li>■ <b>-100 ... 100 mm</b></li> </ul> <p><b>Note:</b> If the activation point is shifted to the wrong point, this can result in damage to the device or other system components.</p>
3	<p>Name for the media data (name freely definable)</p> <p>Touch the arrow to edit the data. The corresponding option window is opened.</p> <ul style="list-style-type: none"> <li>■ For the applications <b>[Empty box]</b> and <b>WELD</b>: (&gt;&gt;&gt; 7.3.6 "Option window “Media setting” – activating laser welding" Page 37)</li> <li>■ For the application <b>CUT</b> and user-defined applications: (&gt;&gt;&gt; 7.7.4 "Option window “Media data” – activating laser cutting" Page 59)</li> </ul>
4	<p>Name for the laser data (name freely definable)</p> <p>Touch the arrow to edit the data. The corresponding option window is opened.</p> <ul style="list-style-type: none"> <li>■ If the instruction is outside a spline block: (&gt;&gt;&gt; 7.3.9 "Option window “Laser data” – Activate process/ Step seam (via time)" Page 40)</li> <li>■ If the instruction is within a spline block: (&gt;&gt;&gt; 7.3.10 "Option window “Laser data” – Activate process/ Step seam (via distance)" Page 41)</li> </ul>

Item	Description
5	Only relevant for <b>WELD</b> application: Use of filler wire <ul style="list-style-type: none"> <li>■ <b>Check box active:</b> Use filler wire.</li> <li>■ <b>Check box not active:</b> Do not use filler wire.</li> </ul>
6	Only relevant for the <b>CUT</b> application: Name for the piercing and cutting data (name freely definable) Touch the arrow to edit the data. The corresponding option window is opened. (>>> 7.7.8 "Option window "Sensor parameters" and "Process parameters"" Page 61) This box can be displayed or hidden using the <b>Add Cut</b> and <b>Rem Cut</b> buttons.
7	Only relevant for user-defined applications: Name for the user-defined data set (name freely definable) Touch the arrow to edit the data. The corresponding option window is opened. (>>> 7.3.14 "Option window – user-defined data set" Page 44)



If the gas is activated with the **Switch gas** instruction before the **Activate process** instruction and the setting "Continuous" is activated, the robot controller ignores the media data of the **Activate process** instruction ("Gas pressure" and "Gas preflow time").  
(>>> 7.5.1 "Inline form "Switch gas"" Page 50)  
If there is no preceding **Switch gas** instruction with the setting "Continuous", the gas is activated by the **Activate process** instruction.

### 7.3.2 Inline form "Switch process"

**Call**

- Select the menu sequence **Commands > LaserTech > Switching > Switch process**.

**Description**

This instruction is used to modify the weld parameters within a weld path. The monitoring functions of the laser and weld media remain active following this instruction. If the application WELD is selected, the wire is fed further.



This instruction refers to the next motion instruction in the program. This motion instruction must be a CP motion. There must be no instructions triggering an advance run stop between the laser instruction and the motion instruction.




Fig. 7-4: Inline form "Switch process" (with Weld)




Fig. 7-5: Inline form “Switch process” (with Cut)




Fig. 7-6: Inline form “Switch process” (with UserSet)

Item	Description
1	<p>Selects an application.</p> <ul style="list-style-type: none"> <li>■ <b>[Empty box]</b>: Only displayed if LaserWeld is not installed.</li> <li>■ <b>WELD</b>: Laser welding (with wire feed)</li> <li>■ <b>CUT</b>: Laser cutting</li> <li>■ <b>USR_LSR, USR_TCH, USR_LMB</b>: Up to 3 user-defined applications possible (default entries)</li> </ul>
2	<p>Shifts the switching point of the laser.</p> <ul style="list-style-type: none"> <li>■ <b>-100 ... 100 mm</b></li> </ul>
3	<p>Name for the media data (name freely definable)</p> <p>Touch the arrow to edit the data. The corresponding option window is opened.</p> <ul style="list-style-type: none"> <li>■ For the applications <b>[Empty box]</b> and <b>WELD</b>: (&gt;&gt;&gt; 7.3.7 "Option window “Media setting” – switching laser welding" Page 38)</li> <li>■ For the application <b>CUT</b> and user-defined applications: (&gt;&gt;&gt; 7.7.5 "Option window “Media data” – switching laser cutting" Page 59)</li> </ul> <p><b>Note:</b> This box is only displayed if velocity-dependent laser power is activated (LSR_UsePwrVelCtrlId = TRUE) or if filler wire is used for laser welding (<b>Wire</b> check box activated).</p>
4	<p>Name for the laser data (name freely definable)</p> <p>Touch the arrow to edit the data. The corresponding option window is opened.</p> <p>(&gt;&gt;&gt; 7.3.11 "Option window “Laser data” – Switch process" Page 42)</p>



Item	Description
5	Only relevant for <b>WELD</b> application: Use of filler wire <ul style="list-style-type: none"> <li>■ <b>Check box active:</b> Use filler wire.</li> <li>■ <b>Check box not active:</b> Do not use filler wire.</li> </ul>
6	Only relevant for user-defined applications: Name for the user-defined data set (name freely definable) Touch the arrow to edit the data. The corresponding option window is opened. (>>> 7.3.14 "Option window – user-defined data set" Page 44)



If the **Switch process** instruction is preceded by a **Switch gas** instruction with the setting "Continuous", the robot controller ignores the parameters in the media set of the **Switch process** instruction ("Gas pressure" and "Gas preflow time").  
(>>> 7.5.1 "Inline form "Switch gas"" Page 50)

### 7.3.3 Inline form "Deactivate process"

**Call** ■ Select the menu sequence **Commands > LaserTech > Switching > Deactivate process**.

**Description** This instruction switches off the laser power and terminates the laser program. The laser is not switched off.

If the gas has been activated earlier in the program with the **Switch gas** instruction and the setting "Continuous", the robot controller ignores the media data of the **Deactivate process** instruction ("Gas pressure" and "Gas postflow time").

The gas must be deactivated with the **Switch gas** instruction in such a case.

If there is no preceding **Switch gas** instruction with the setting "Continuous", the gas is deactivated by the **Deactivate process** instruction.



This instruction refers to the next motion instruction in the program. This motion instruction must be a CP motion. There must be no instructions triggering an advance run stop between the laser instruction and the motion instruction.




Fig. 7-7: Inline form "Deactivate process" (with Weld)




Fig. 7-8: Inline form “Deactivate process” (with Cut)




Fig. 7-9: Inline form “Deactivate process” (with UserSet)


Item	Description
1	<p>Selects an application.</p> <ul style="list-style-type: none"> <li>■ <b>[Empty box]:</b> Only displayed if LaserWeld is not installed.</li> <li>■ <b>WELD:</b> Laser welding (with wire feed)</li> <li>■ <b>CUT:</b> Laser cutting</li> <li>■ <b>USR_LSR, USR_TCH, USR_LMB:</b> Up to 3 user-defined applications possible (default entries)</li> </ul>
2	<p>Shifts the end point.</p> <ul style="list-style-type: none"> <li>■ <b>-100 ... 100 mm</b></li> </ul>
3	<p>Name for the media data (name freely definable)</p> <p>Touch the arrow to edit the data. The corresponding option window is opened.</p> <ul style="list-style-type: none"> <li>■ For the applications <b>[Empty box]</b> and <b>WELD:</b> (&gt;&gt;&gt; 7.3.8 "Option window “Media setting” – deactivating laser welding" Page 39)</li> <li>■ For the application <b>CUT</b> and user-defined applications: (&gt;&gt;&gt; 7.7.6 "Option window “Media data” – deactivating laser cutting" Page 60)</li> </ul>
4	<p>Name for the laser data (name freely definable)</p> <p>Touch the arrow to edit the data. The corresponding option window is opened.</p> <ul style="list-style-type: none"> <li>■ If the instruction is outside a spline block: (&gt;&gt;&gt; 7.3.12 "Option window “Laser data” – Deactivate process (via time)" Page 42)</li> <li>■ If the instruction is within a spline block: (&gt;&gt;&gt; 7.3.13 "Option window “Laser data” – Deactivate process (via distance)" Page 43)</li> </ul>

Item	Description
5	Only relevant for <b>WELD</b> application: Use of filler wire <ul style="list-style-type: none"> <li>■ <b>Check box active:</b> Use filler wire.</li> <li>■ <b>Check box not active:</b> Do not use filler wire.</li> </ul>
6	<ul style="list-style-type: none"> <li>■ <b>Check box active:</b> The laser is enabled.</li> <li>■ <b>Check box not active:</b> Not enabled.</li> </ul>
7	Only relevant for the <b>CUT</b> application: Distance sensor <ul style="list-style-type: none"> <li>■ <b>Off:</b> Distance sensor OFF</li> <li>■ <b>Hold:</b> The distance sensor remains in the current position.</li> <li>■ <b>PrPos:</b> The distance sensor goes to the programmed position.</li> </ul> This box can be displayed or hidden using the <b>Add Cut</b> and <b>Rem Cut</b> buttons.
8	Only relevant for user-defined applications: Name for the user-defined data set (name freely definable) Touch the arrow to edit the data. The corresponding option window is opened.  (>>> 7.3.14 "Option window – user-defined data set" Page 44)

#### 7.3.4 Inline form "Step seam"


**Call**                    ■ Select the menu sequence **Commands > LaserTech > Switching > Step seam**.


**Description**        This instruction performs a step seam. The instruction cannot be used with laser welding or laser cutting.

 This instruction refers to the next motion instruction in the program. This motion instruction must be a CP motion. There must be no instructions triggering an advance run stop between the laser instruction and the motion instruction.

The step seam is canceled in the following cases:

- **Activate process** instruction
- **Deactivate process** instruction
- Exact positioning
- A smooth transition is made from a CP motion to a PTP motion.

 Step seams are only possible without filler wire.

 Step seams are velocity-dependent. If the velocity is modified, the seam must then be checked and optimized.




Fig. 7-10: Inline form “Step seam”

Item	Description
1	Shifts the activation point of the laser. <ul style="list-style-type: none"> <li>■ -100 ... 100 mm</li> </ul>
2	Execution of the instruction is brought forward in time or delayed. <ul style="list-style-type: none"> <li>■ -100 ... 100 ms</li> </ul>
3	Name for the laser data (name freely definable) Touch the arrow to edit the data. The corresponding option window is opened. <ul style="list-style-type: none"> <li>■ If the instruction is outside a spline block:                              (&gt;&gt;&gt; 7.3.9 "Option window “Laser data” – Activate process/ Step seam (via time)" Page 40)</li> <li>■ If the instruction is within a spline block:                              (&gt;&gt;&gt; 7.3.10 "Option window “Laser data” – Activate process/ Step seam (via distance)" Page 41)</li> </ul>
4	Name for the step parameters (name freely definable) Touch the arrow to edit the data. The corresponding option window is opened. (>>> 7.3.15 "Option window “Step parameters”" Page 44)

7.3.5 Inline form “Laser test pulse”

**Call**

- Select the menu sequence **Commands > LaserTech > Switching > Laser test pulse**.

**Description** This instruction generates a laser pulse.  

- The laser pulse can be measured to test the laser power. (Precondition: T1 mode.)
- The laser pulse can be executed several times to determine the focus of the optics. (Precondition: operating mode T1 or T2.)

**NOTICE** Not all monitoring functions are active with this instruction. Incorrect use can cause material damage. The instruction may only be used by trained personnel.




Fig. 7-11: Inline form “Laser test pulse”

Item	Description
1	Select function. <ul style="list-style-type: none"> <li>■ <b>Test:</b> Test the laser power.</li> <li>■ <b>Focus:</b> Determine the focus of the optics.</li> </ul>
2	Name for the laser data (name freely definable) Touch the arrow to edit the data. The corresponding option window is opened. (>>> 7.3.16 "Option window "Laser data" – "Laser test pulse" Page 45)
3	Duration of laser pulse <ul style="list-style-type: none"> <li>■ <b>12 ... 20,000 ms</b></li> </ul>

### 7.3.6 Option window "Media setting" – activating laser welding




Fig. 7-12: Option window "Media setting: gas" – activating laser welding, without wire





Fig. 7-13: Option window "Media setting: wire" – activating laser welding, with wire

Item	Description
1	Gas pressure <ul style="list-style-type: none"> <li>■ 0 ... 10 bar</li> </ul> <b>Note:</b> This box is only displayed if the velocity-dependent laser power is activated (LSR_UsePwrVelCtrlId = TRUE).
2	Gas preflow time <ul style="list-style-type: none"> <li>■ 0 ... 25 s</li> </ul>
3	Wirefeed <ul style="list-style-type: none"> <li>■ 0 ... 25 m/min</li> </ul>
4	Minimum wire feed rate <ul style="list-style-type: none"> <li>■ 0 ... 15 m/min</li> </ul>
5	Wirefeed delay <ul style="list-style-type: none"> <li>■ -30 ... 30 mm</li> </ul>

### 7.3.7 Option window “Media setting” – switching laser welding

 The option window **Media setting: gas** is only available if the velocity-dependent laser power is activated (LSR\_UsePwrVelCtrlId = TRUE).




Fig. 7-14: Option window “Media setting: gas” – switching laser welding, without wire


 The option window **Media setting: wire** is only available if filler wire is being used for laser welding (**Wire** check box in the inline form **Switch process** is activated).


Fig. 7-15: Option window "Media setting: wire" – switching laser welding, with wire

Item	Description
1	Gas pressure ■ 0 ... 10 bar
2	Wirefeed ■ 0 ... 25 m/min
3	Minimum wire feed rate ■ 0 ... 15 m/min
4	Wirefeed delay ■ -30 ... 30 mm

### 7.3.8 Option window "Media setting" – deactivating laser welding

Fig. 7-16: Option window "Media setting: gas" – deactivating laser welding, without wire

**i** The option window **Media setting: wire** is only available if filler wire is being used for laser welding (**Wire** check box in the inline form **Deactivate process** is activated).




**Fig. 7-17: Option window “Media setting: wire” – deactivating laser welding, with wire**

Item	Description
1	Gas pressure <ul style="list-style-type: none"> <li>0 ... 10 bar</li> </ul> <b>Note:</b> This box is only displayed if the velocity-dependent laser power is activated (LSR_UsePwrVelCtrlId = TRUE).
2	Gas postflow time <ul style="list-style-type: none"> <li>0 ... 25 s</li> </ul>
3	Wirefeed delay <ul style="list-style-type: none"> <li>-30 ... 30 mm</li> </ul>

### 7.3.9 Option window “Laser data” – Activate process/Step seam (via time)

This option window is called via the inline forms **Activate process** and **Step seam**, if these are outside a spline block. In the case, the power ramp is defined via time.



**Fig. 7-18: Option window “Laser data” – Activate process (via time)**



Item	Description
1	Laser power at 100% velocity (maximum power) <ul style="list-style-type: none"> <li>60 ... 6,000 W</li> </ul>
2	Minimum power for velocity-dependent control of the laser power <ul style="list-style-type: none"> <li>60 ... 6,000 W</li> </ul> <p><b>Note:</b> This box is only displayed if the velocity-dependent laser power is activated (LSR_UsePwrVelCtrlId = TRUE).</p>
3	Laser program number <ul style="list-style-type: none"> <li>1 ... 200</li> </ul>
4	Laser power rise time Time that elapses after activation before the laser reaches full power <ul style="list-style-type: none"> <li>1 ... 2,000 ms</li> </ul> The maximum laser power rise time can be modified in the registry. (>>> 6.7 "Modifying maximum values for ramp times" Page 26)

### 7.3.10 Option window "Laser data" – Activate process/Step seam (via distance)

This option window is called via the inline forms **Activate process** and **Step seam**, if these are within a spline block. In the case, the power ramp is defined via distance.




Fig. 7-19: Option window "Laser data" – Activate process (via distance)

Item	Description
1	Laser power at 100% velocity (maximum power) <ul style="list-style-type: none"> <li>60 ... 6,000 W</li> </ul>
2	Minimum power for velocity-dependent control of the laser power <ul style="list-style-type: none"> <li>60 ... 6,000 W</li> </ul> <p><b>Note:</b> This box is only displayed if the velocity-dependent laser power is activated (LSR_UsePwrVelCtrlId = TRUE).</p>

Item	Description
3	Laser program number <ul style="list-style-type: none"> <li>1 ... 200</li> </ul>
4	Length of power rise Distance traveled after activation before the laser reaches full power <ul style="list-style-type: none"> <li>1 ... 2,000 mm</li> </ul>

7.3.11 Option window “Laser data” – Switch process




Fig. 7-20: Option window “Laser data” – Switch process

Item	Description
1	Laser power at 100% velocity <ul style="list-style-type: none"> <li>60 ... 6,000 W</li> </ul>
2	Minimum power for velocity-dependent control of the laser power <ul style="list-style-type: none"> <li>60 ... 6,000 W</li> </ul> <p><b>Note:</b> This box is only displayed if the velocity-dependent laser power is activated (LSR_UsePwrVelCtrlId = TRUE).</p>

7.3.12 Option window “Laser data” – Deactivate process (via time)

This option window is called via the inline form **Deactivate process**, if this is outside a spline block. In the case, the power ramp is defined via time.




Fig. 7-21: Option window "Laser data" – Deactivate process (via time)

Item	Description
1	Power limit during deactivation <ul style="list-style-type: none"> <li>■ 60 ... 6,000 W</li> </ul>
2	Laser power drop time Time taken after deactivation for the laser to decrease its power <ul style="list-style-type: none"> <li>■ 1 ... 2,000 ms</li> </ul> The maximum laser power drop time can be modified in the registry. (>>> 6.7 "Modifying maximum values for ramp times" Page 26)

### 7.3.13 Option window "Laser data" – Deactivate process (via distance)

This option window is called via the inline form **Deactivate process**, if this is within a spline block. In the case, the power ramp is defined via distance.




Fig. 7-22: Option window "Laser data" – Deactivate process (via distance)

Item	Description
1	Power limit during deactivation <ul style="list-style-type: none"> <li>60 ... 6,000 W</li> </ul>
2	Length of power fall Distance traveled after deactivation until the laser power is ramped down <ul style="list-style-type: none"> <li>1 ... 2,000 mm</li> </ul>

7.3.14 Option window – user-defined data set

Up to 12 user-defined parameters can be set in this option window.




Fig. 7-23: Option window – user-defined data set

Item	Description
1	Parameter value which can be used for additional user-specific functions The name of the parameter and the unit are defined by the user. (>>> 9.1.2 "Changing parameter names and units in the option window" Page 68)

7.3.15 Option window “Step parameters”




Fig. 7-24: Option window: Step parameters

Item	Description
1	Length of the step seam <ul style="list-style-type: none"> <li>■ 10 ... 10,000 mm</li> </ul>
2	Number of steps <ul style="list-style-type: none"> <li>■ 2 ... 500</li> </ul>
3	Length of a step <ul style="list-style-type: none"> <li>■ 2 ... 50 mm</li> </ul>

### 7.3.16 Option window "Laser data" – "Laser test pulse"




Fig. 7-25: Option window "Laser data" – "Laser test pulse"

Item	Description
1	Laser power for the laser pulse <ul style="list-style-type: none"> <li>■ 60 ... 6,000 W</li> </ul>
2	Laser program number <ul style="list-style-type: none"> <li>■ 1 ... 200</li> </ul>

## 7.4 Programming laser control

### 7.4.1 Inline form "Initialize laser"

**Call** ■ Select the menu sequence **Commands > LaserTech > Control commands > Initialize laser**.

**Description** This instruction initializes the laser. The first laser instruction in the KRL program must always be **Initialize laser**.

This instruction triggers an advance run stop.




Fig. 7-26: Inline form "Initialize laser"

Item	Description
1	<p>Selects an application.</p> <ul style="list-style-type: none"> <li>■ <b>[Empty box]</b>: Only displayed if LaserWeld is not installed.</li> <li>■ <b>WELD</b>: Laser welding (with wire feed)</li> <li>■ <b>CUT</b>: Laser cutting</li> <li>■ <b>USR_LSR, USR_TCH, USR_LMB</b>: Up to 3 user-defined applications possible (default entries)</li> </ul>
2	<p>Defines whether the laser is to be allocated to the robot during initialization. Only relevant if the robot belongs to a laser network.</p> <ul style="list-style-type: none"> <li>■ <b>True</b>: Laser is allocated to the robot during initialization.</li> <li>■ <b>False</b>: Laser is not allocated to a robot during initialization.</li> </ul>
3	<p>Name for the defined gas types (name freely definable)</p> <p>Touch the arrow to select the gas type. The corresponding option window is opened.</p> <ul style="list-style-type: none"> <li>■ For the application <b>WELD</b>: (&gt;&gt;&gt; 7.4.5 "Option window "Gas selection" – laser welding" Page 48)</li> <li>■ For the application <b>CUT</b>: (&gt;&gt;&gt; 7.4.6 "Option window "Gas selection" – laser cutting" Page 49)</li> </ul>
4	<p>Name for the defined lasers (name freely definable)</p> <p>Touch the arrow to select the laser. The corresponding option window is opened.</p> <p>(&gt;&gt;&gt; 7.4.7 "Option window "Laser network" – "Initialize laser" Page 49)</p>
5	<p>Only relevant for <b>WELD</b> application:</p> <p>Use of filler wire</p> <ul style="list-style-type: none"> <li>■ <b>Check box active</b>: Use filler wire.</li> <li>■ <b>Check box not active</b>: Do not use filler wire.</li> </ul>
6	<p>Only relevant for user-defined applications:</p> <p>Name for the user-defined data set (name freely definable)</p> <p>Touch the arrow to edit the data. The corresponding option window is opened.</p> <p>(&gt;&gt;&gt; 7.3.14 "Option window – user-defined data set" Page 44)</p>

#### 7.4.2 Inline form "Enable laser"

**Call**

- Select the menu sequence **Commands > LaserTech > Control commands > Enable laser**.

**Description**

This instruction can be used to enable the laser for use by other robots at the end of a path. It is only relevant if the robot belongs to a laser network.

The instruction has the following effects:

- The gas supply is shut off.
- The laser is enabled.



LSR Free

Fig. 7-27: Inline form "Enable laser"

#### 7.4.3 Inline form "Laser off"

**Call**

- Select the menu sequence **Commands > LaserTech > Control commands > Laser off**.

**Description** This instruction has the following effects:

- The laser is deactivated.
- The gas supply is shut off.
- The laser is enabled.

**NOTICE**

This instruction should only be used if the laser is to be deactivated for a prolonged period.



LSR Off

Fig. 7-28: Inline form "Laser off"

#### 7.4.4 Inline form "Laser request"

**Call**

- Select the menu sequence **Commands > LaserTech > Control commands > Laser request**.

**Description** This instruction requests the laser via the signal LSRO\_LsrRequest.

It is possible to program the robot controller to wait for the laser if the laser is allocated. To do so, use the instruction with **Allocate** (checkbox is activated).

The switching point for the instruction should be far enough before the next activation point to enable the robot to brake before the start of the seam to wait for allocation of the laser. Following allocation, the robot must be able to accelerate in order to reach the programmed velocity at the start of the seam. This is possible with the parameters **Path** and **Delay**.



This instruction refers to the next motion instruction in the program. This motion instruction must be a CP motion. There must be no instructions triggering an advance run stop between the laser instruction and the motion instruction.




Fig. 7-29: Inline form "Laser request"

Item	Description
1	The point at which the instruction is executed is shifted forwards or backwards. <ul style="list-style-type: none"> <li>■ <b>-2,000 ... 1,000 mm</b></li> </ul>
2	Execution of the instruction is brought forward in time or delayed. <ul style="list-style-type: none"> <li>■ <b>-2,000 ... 1,000 ms</b></li> </ul>
3	Laser Allocate <ul style="list-style-type: none"> <li>■ <b>Check box active:</b> The robot controller accesses the laser if it is not allocated. If the laser is allocated, the robot stops. The robot controller waits for the laser to be assigned to it.</li> <li>■ <b>Check box not active:</b> If the laser is allocated, the robot controller does not wait until the laser is assigned to it.</li> </ul>

7.4.5 Option window “Gas selection” – laser welding




Fig. 7-30: Option window “Gas selection” – laser welding

Item	Description
1	Select process gas. The range of values depends on how many gas types have been configured. (>>> 6.4 "Configuring gas types for inline forms" Page 23)
2	Select root gas. The range of values depends on how many gas types have been configured. (>>> 6.4 "Configuring gas types for inline forms" Page 23)



### 7.4.6 Option window "Gas selection" – laser cutting




Fig. 7-31: Option window "Gas selection" – laser cutting

Item	Description
1	Select cutting gas. The range of values depends on how many gas types have been configured. (>>> 6.4 "Configuring gas types for inline forms" Page 23)

### 7.4.7 Option window "Laser network" – "Initialize laser"




Fig. 7-32: Option window "Laser network" – "Initialize laser"


Item	Description
1	Select laser number. ■ 1 ... 15
2	Select the fiber number. ■ 1 ... 8
3	Select robot number. ■ 1 ... 6

## 7.5 Programming media control

### 7.5.1 Inline form “Switch gas”

**Call** ■ Select the menu sequence **Commands > LaserTech > Media control > Switch gas**.

**Description** This instruction switches the gas on or off.



**Fig. 7-33: Inline form “Switch gas”**


Item	Description
1	<p>Selects a gas.</p> <ul style="list-style-type: none"> <li>■ <b>Proc_Gas</b>: process gas</li> <li>■ <b>Root_Gas</b>: root gas</li> <li>■ <b>Cut_Gas</b>: cutting gas</li> <li>■ <b>CrossJet</b></li> <li>■ <b>All</b>: all gases</li> </ul> <p><b>Note:</b> It is not possible to activate all gases simultaneously. <b>All</b> can only be used to deactivate the gases simultaneously.</p>
2	<p>Switches the selected gas on or off.</p> <ul style="list-style-type: none"> <li>■ <b>ON</b>: Switches the gas on.</li> <li>■ <b>OFF</b>: Switches the gas off.</li> </ul> <p><b>Note:</b> The gas is only switched off if the laser is not active.</p>
3	<p>Gas pressure</p> <ul style="list-style-type: none"> <li>■ <b>0 ... 20 bar</b></li> </ul> <p>This box is only displayed if a proportional gas valve is used (LSR_PropGasValve = TRUE).</p>
4	<p>Only relevant for <b>ON</b>:</p> <ul style="list-style-type: none"> <li>■ <b>Continuous</b>: The instruction applies until the next <b>Switch gas</b> instruction is programmed. Until then, the gas parameters (gas pressure, gas preflow time, gas postflow time) for the <b>Activate process</b>, <b>Switch process</b> and <b>Deactivate process</b> instructions are ignored.</li> <li>■ <b>Once</b>: The gas parameters for the subsequent <b>Activate process</b>, <b>Switch process</b> and <b>Deactivate process</b> instructions in the program apply until a new gas is activated with the instruction <b>Switch gas</b>.</li> </ul>

### 7.5.2 Inline form “Initialize gas”

**Call** ■ Select the menu sequence **Commands > LaserTech > Media control > Initialize gas**.

**Description** This instruction is used to select the gases required for the process. The instruction must be used at least once in an application program. It must be placed before the **Initialize laser** instruction and before the first **Activate process** instruction.

Within a program, the instruction is used to change the type of gas. If there is a process gas active when the instruction is executed, the process gas is deactivated. The **Switch gas** instruction is then required to activate the gas.

 If the **Initialize gas** instruction is not used in a KRL program, the gas is automatically initialized with the **Initialize laser** instruction.




Fig. 7-34: Inline form "Initialize gas"

Item	Description
1	Selects an application. <ul style="list-style-type: none"> <li>■ <b>[Empty box]</b>: Only displayed if LaserWeld is not installed.</li> <li>■ <b>WELD</b>: Laser welding (with wire feed)</li> <li>■ <b>CUT</b>: Laser cutting</li> </ul>
2	Name for the defined gas types (name freely definable) Touch the arrow to select the gas type. The corresponding option window is opened. <ul style="list-style-type: none"> <li>■ For the application <b>WELD</b>: (&gt;&gt;&gt; 7.4.5 "Option window "Gas selection" – laser welding" Page 48)</li> <li>■ For the application <b>CUT</b>: (&gt;&gt;&gt; 7.4.6 "Option window "Gas selection" – laser cutting" Page 49)</li> </ul>

### 7.5.3 Inline form "Cut wire"

**Call** ■ Select the menu sequence **Commands > LaserTech > Media control > Cut wire**.

**Description** To cut the welding wire to length reliably using a cutting device, the wire can be advanced a certain distance using this instruction. (Check box **Cut** is not active.)




Fig. 7-35: Inline form "Cut wire" (without Cut)

This instruction is used to cut the wire with the laser. (Check box **Cut** is active.)




Fig. 7-36: Inline form "Cut wire" (with Cut)

Item	Description
1	Wire cutting with laser pulse <ul style="list-style-type: none"> <li>■ <b>Check box active:</b> Wire is cut with laser pulse.</li> <li>■ <b>Check box not active:</b> Wire is not cut with laser pulse.</li> </ul>
2	Velocity of the wire feed <ul style="list-style-type: none"> <li>■ <b>0 ... 25 m/min</b></li> </ul>
3	Duration of the wire feed <ul style="list-style-type: none"> <li>■ <b>100 ... 3,000 ms</b></li> </ul>
4	Laser program number <ul style="list-style-type: none"> <li>■ <b>1 ... 200</b></li> </ul> <p>This box is only displayed if the check box <b>Cut</b> is activated.</p>
5	Laser power for cutting the wire <ul style="list-style-type: none"> <li>■ <b>60 ... 60,000 W</b></li> </ul> <p>This box is only displayed if the check box <b>Cut</b> is activated.</p>
6	Wire feed rate <ul style="list-style-type: none"> <li>■ <b>0 ... 25 m/min</b></li> </ul>
7	Pulse duration for cutting the wire <ul style="list-style-type: none"> <li>■ <b>100 ... 3,000 ms</b></li> </ul>

## 7.6 Programming sensor control

### 7.6.1 Inline form "Switch sensor"

**Call** ■ Select the menu sequence **Commands > LaserTech > Sensor control > Switch sensor.**

#### Description

This command is used to define the settings for the distance sensor.

The cutting distance defined here can be transferred as an analog value or via a program number. This is set using the variable LSC\_AnaCutDistance.

- TRUE = cutting distance is transferred as an analog value.
- FALSE = cutting distance is transferred via a program number (default).

Procedure for InDLY > 0:

1. Tip compensation time 2 is taken into consideration.
2. Motion stop
3. The robot moves to the point specified by the value defined in LSC\_SecDistance.
4. The wait time defined in InDLY expires.
5. The cutting gas is switched. The distance defined in the inline form is set.
6. The wait time defined in LSC\_SecInDly expires.
7. The motion is resumed.

This instruction is also used to modify an existing cutting distance. In this case, LsrCutSensor = On, InDLY = 0 and the new distance are programmed.



Detailed information about the distance sensor and distance controller is contained in the PRECITEC documentation.




Fig. 7-37: Inline form "Switch sensor" (analog distance)




Fig. 7-38: Inline form "Switch sensor" (program-controlled distance)

Item	Description
1	Distance sensor <ul style="list-style-type: none"> <li>■ <b>On</b>: Distance sensor ON</li> <li>■ <b>Off</b>: Distance sensor OFF</li> <li>■ <b>Hold</b>: The distance sensor remains in the current position.</li> <li>■ <b>PrPos</b>: The distance sensor goes to the programmed position.</li> </ul>
2	Piercing position after the end point of the motion. <ul style="list-style-type: none"> <li>■ <b>0 ... 4,000 ms</b></li> </ul>
3	Cutting distance; unit: 1/10 mm <ul style="list-style-type: none"> <li>■ <b>1 ... 300</b></li> </ul> <p>This box is only displayed if the cutting distance is transferred as an analog value (LSC_AnaCutDistance = TRUE).</p>
4	Number of the program in the sensor controller that regulates the cutting distance <ul style="list-style-type: none"> <li>■ <b>1 ... 3</b></li> </ul> <p>This box is only displayed if the cutting distance is transferred via a program number (LSC_AnaCutDistance = TRUE).</p>

### 7.6.2 Inline form "Sensor settings"

**Call** ■ Select the menu sequence **Commands > LaserTech > Sensor control > Sensor settings**.

**Description** This instruction can be used to set the cutting and piercing data for laser cutting and call a piercing function. This piercing function implicitly switches the distance sensor on.



Fig. 7-39: Inline form "Sensor settings"

Item	Description
1	Name for the piercing and cutting data (name freely definable) Touch the arrow to edit the data. The corresponding option window is opened. (>>> 7.7.8 "Option window "Sensor parameters" and "Process parameters"" Page 61)

## 7.7 Programming laser cutting

### 7.7.1 Inline form "Rectangle", "Slot", "Hexagon", "Circle"

**Call** ■ Select the menu sequence **Commands > LaserTech > Cutting**.

The following menu items are available:

- **Rectangle**
- **Slot**
- **Hexagon**
- **Circle**

**Description**


This command defines which pattern will be cut. Optionally, the cutting and piercing data for laser cutting can be defined.

If the piercing and cutting data are defined, the instruction calls a piercing function that implicitly activates the distance sensor. In this case, the instruction replaces the instruction **Switch sensor**.

(>>> 7.6.1 "Inline form "Switch sensor"" Page 52)

Every cutting pattern is executed as a spline motion.

**NOTICE** These instructions execute a calculated motion based on the parameters set in the option window. Incorrectly set parameters can result in damage to the system. Always carry out a test tun after creating or modifying these instructions.

 To cut lines, a LIN motion command is used.




Fig. 7-40: Inline form "Rectangle"

Item	Description
1	<p>Selects a pattern.</p> <ul style="list-style-type: none"> <li>■ <b>LsrCutRect</b>: Rectangle</li> <li>■ <b>LsrCutSlot</b>: Slot</li> <li>■ <b>LsrCutHex</b>: Hexagon</li> <li>■ <b>LsrCutCircle</b>: Circle</li> </ul>
2	<p>Name for the geometry data (name freely definable)</p> <p>Touch the arrow to edit the data. The corresponding option window is opened.</p> <p>(&gt;&gt;&gt; 7.7.2 "Option windows "Geometry data" and "Geo motion data"" Page 55)</p>
3	<p>Name of the end point (name freely definable)</p> <p>Touch the arrow to edit the point data. The corresponding option window is opened.</p> <p>(&gt;&gt;&gt; 7.7.3 "Option window: Frames" Page 58)</p>
4	<p>Velocity</p> <ul style="list-style-type: none"> <li>■ <b>0.01 ... 10 m/min</b></li> </ul>
5	<p>Name for the media data (name freely definable)</p> <p>Touch the arrow to edit the data. The corresponding option window is opened.</p> <p>(&gt;&gt;&gt; 7.7.4 "Option window "Media data" – activating laser cutting" Page 59)</p>
6	<p>Name for the laser data (name freely definable)</p> <p>Touch the arrow to edit the data. The corresponding option window is opened.</p> <p>(&gt;&gt;&gt; 7.7.7 "Option window "Laser data" – Rectangle, Slot, Hexagon, Circle" Page 60)</p>
7	<p>Name for the piercing and cutting data (name freely definable)</p> <p>Touch the arrow to edit the data. The corresponding option window is opened.</p> <p>(&gt;&gt;&gt; 7.7.8 "Option window "Sensor parameters" and "Process parameters"" Page 61)</p> <p>This box can be displayed or hidden using the <b>Add Cut</b> and <b>Rem Cut</b> buttons.</p>

## 7.7.2 Option windows "Geometry data" and "Geo motion data"

### Description

This option window is called from the following inline forms:

- **Rectangle**
- **Slot**
- **Hexagon**
- **Circle**

The meaning of the boxes depends on the pattern selected in the inline form.




Fig. 7-41: Option window “Geometry data”




Fig. 7-42: Option window “Geo motion data”

Rectangle

Item	Description
1	Side length of 1st cut <ul style="list-style-type: none"> <li>Positive values</li> </ul>
2	Side length of 2nd cut <ul style="list-style-type: none"> <li>Positive values</li> </ul>
3	Orientation angle of the rectangle in the XY plane relative to the current base system <ul style="list-style-type: none"> <li>0° ... 360°</li> </ul>
4	Area within the rectangle where initial piercing takes place <ul style="list-style-type: none"> <li>1 ... 4</li> </ul>
5	Initial cutting direction <ul style="list-style-type: none"> <li>-1: to the left</li> <li>1: to the right</li> </ul>
6	Interval between laser switch-on and start of robot motion <ul style="list-style-type: none"> <li>0 ... 3000 ms</li> </ul>
7	Acceleration Refers to the maximum value specified in the machine data. The maximum value depends on the robot type and the selected operating mode.
8	Approximation distance



**Slot**

Item	Description
1	Length of the long side The value must be greater than the length of the short side.
2	Length of the short side The value must be less than the length of the long side.
3	Orientation angle of the slot in the XY plane relative to the current base system ■ <b>0° ... 360°</b>
4	Area within the slot where initial piercing takes place ■ <b>1 ... 4</b>
5	— — —
6	Interval between laser switch-on and start of robot motion ■ <b>0 ... 3000 ms</b>
7	Acceleration Refers to the maximum value specified in the machine data. The maximum value depends on the robot type and the selected operating mode.
8	Approximation distance

**Hexagon**

Item	Description
1	Side length of hexagon ■ Positive values
2	— — —
3	Orientation angle of the hexagon in the XY plane relative to the current base system ■ <b>0° ... 360°</b>
4	Area within the hexagon where initial piercing takes place ■ <b>1 ... 4</b>
5	Initial cutting direction ■ <b>-1:</b> to the left ■ <b>1:</b> to the right
6	Interval between laser switch-on and start of robot motion ■ <b>0 ... 3000 ms</b>
7	Acceleration Refers to the maximum value specified in the machine data. The maximum value depends on the robot type and the selected operating mode.
8	Approximation distance

**Circle**

Item	Description
1	Diameter of the circle ■ Positive values
2	Angle, if only an arc is being cut ■ Positive values
3	— — —
4	Area within the circle where initial piercing takes place ■ <b>1 ... 4</b>

Item	Description
5	Initial cutting direction <ul style="list-style-type: none"> <li>■ -1: to the left If an arc is cut , "-1" must be entered.</li> <li>■ 1: to the right</li> </ul>
6	Interval between laser switch-on and start of robot motion <ul style="list-style-type: none"> <li>■ 0 ... 3000 ms</li> </ul>
7	Acceleration Refers to the maximum value specified in the machine data. The maximum value depends on the robot type and the selected operating mode.
8	Approximation distance

7.7.3 Option window: Frames




Fig. 7-43: Option window: Frames

Item	Description
1	Tool selection. <ul style="list-style-type: none"> <li>■ [1] ... [16]</li> </ul> If <b>True</b> in the box <b>ExternalTCP</b> : workpiece selection.
2	Interpolation mode <ul style="list-style-type: none"> <li>■ <b>False</b>: The tool is mounted on the mounting flange.</li> <li>■ <b>True</b>: The tool is a fixed tool.</li> </ul>

### 7.7.4 Option window "Media data" – activating laser cutting




Fig. 7-44: Option window "Media data" – activating laser cutting

Item	Description
1	Gas pressure <ul style="list-style-type: none"> <li>■ 0 ... 10 bar</li> </ul> <b>Note:</b> This box is only displayed if the velocity-dependent laser power is activated (LSR_UsePwrVelCtrlId = TRUE).
2	Gas preflow time <ul style="list-style-type: none"> <li>■ 0 ... 25 s</li> </ul>

If the gas preflow time overlaps with the gas postflow time of the previous motion, the gas continues to flow without interruption.

### 7.7.5 Option window "Media data" – switching laser cutting

**i** This option window is only available if the velocity-dependent laser power is activated (LSR\_UsePwrVelCtrlId = TRUE).




Fig. 7-45: Option window "Media data" – switching laser cutting

Item	Description
1	Gas pressure <ul style="list-style-type: none"> <li>■ 0 ... 10 bar</li> </ul>

7.7.6 Option window “Media data” – deactivating laser cutting




Fig. 7-46: Option window “Media data” – deactivating laser cutting

Item	Description
1	Gas pressure <ul style="list-style-type: none"> <li>0 ... 10 bar</li> </ul> <b>Note:</b> This box is only displayed if the velocity-dependent laser power is activated (LSR_UsePwrVelCtrlId = TRUE).
2	Gas postflow time <ul style="list-style-type: none"> <li>0 ... 25 s</li> </ul>

If the gas preflow time overlaps with the gas postflow time of the previous motion, the gas continues to flow without interruption.

7.7.7 Option window “Laser data” – Rectangle, Slot, Hexagon, Circle




Fig. 7-47: Option window “Laser data” – Rectangle, Slot, Hexagon, Circle

Item	Description
1	Laser power at 100% velocity <ul style="list-style-type: none"> <li>60 ... 6,000 W</li> </ul>
2	Minimum power for velocity-dependent control of the laser power <ul style="list-style-type: none"> <li>60 ... 6,000 W</li> </ul> <b>Note:</b> This box is only displayed if the velocity-dependent laser power is activated (LSR_UsePwrVelCtrlId = TRUE).

Item	Description
3	Laser program number <ul style="list-style-type: none"> <li>■ 1 ... 200</li> </ul>
4	Laser power rise time Time that elapses after activation before the laser reaches full power <ul style="list-style-type: none"> <li>■ 1 ... 2,000 ms</li> </ul> The maximum laser power rise time can be modified in the registry. (>>> 6.7 "Modifying maximum values for ramp times" Page 26)

### 7.7.8 Option window "Sensor parameters" and "Process parameters"





Fig. 7-48: Option window: Sensor parameters

Item	Description
1	Piercing distance (TCP of the sensor – component); unit: 1/10 mm <ul style="list-style-type: none"> <li>■ 0 ... 300</li> </ul>
2	Cutting distance; unit: 1/10 mm <ul style="list-style-type: none"> <li>■ 0 ... 300</li> </ul>
3	Piercing time <ul style="list-style-type: none"> <li>■ 0 ... 3,000 ms</li> </ul>
4	Wait time after changing the cutting gas <ul style="list-style-type: none"> <li>■ 0 ... 3,000 ms</li> </ul>



**Fig. 7-49: Option window “Process parameters”**

Item	Description
5	Cutting gas number <ul style="list-style-type: none"> <li>■ 0 ... 30</li> </ul>
6	Cutting gas pressure during cutting <ul style="list-style-type: none"> <li>■ 0 ... 30 bar</li> </ul>
7	Laser power during cutting <ul style="list-style-type: none"> <li>■ 60 ... 6,000 W</li> </ul>

## 8 Example programs

### 8.1 Example program: step seam



The velocity of the laser must be kept constant until the switching point is reached. Otherwise it is possible that the laser may switch before or after the planned switching point.

#### Program

```

1 DEF step( )
2 INI
3 PTP HOME Vel= 100 % DEFAULT
4 PTP Start CONT Vel=100 % PDAT0 Tool[1] Base[0]
5 LSR WELD Allocation=True Gas: GasDef LSN: LSNDf
6 LIN P1 CONT Vel=0.2 m/s CPDAT1 Tool[1] Base[0]
7 GasSwi Proc_Gas ON
8 GasSwi CrossJet ON Haltend
9 LIN P2 CONT Vel=0.2 m/s CPDAT2 Tool[1] Base[0]
10 LSR StepOn Path=0 mm Dly=0 ms LSet=LS22 SSet=SP3
11 LIN P3 CONT Vel=0.1 m/s CPDAT3 Tool[1] Base[0]
12 LIN P4 CONT Vel=0.1 m/s CPDAT4 Tool[1] Base[0]
13 LSR WELD End Path=0 mm Min=100 W MSet=ME10 LSet=LS11 Release
14 LIN P5 CONT Vel=0.1 m/s CPDAT5 Tool[1] Base[0]
15 GasSwi All OFF
16 PTP HOME Vel= 100 % DEFAULT
17 END

```

#### Description

Line	Description
5	<p>Initializes the laser. The instruction carries out an implicit request. Light path and laser are selected.</p> <p>This instruction does not perform a reset.</p> <p>The robot motion is generally stopped due to handshake operations with the laser.</p>
7	The process gas is switched on.
8	<p>CrossJet is activated.</p> <p><b>Continuous:</b> until <code>GasSwi All OFF</code>, the gas parameters (pressure, gas preflow time, gas postflow time) for all <code>LaserOn</code>, <code>LaserSwi</code> and <code>LaserEnd</code> instructions are ignored.</p>
10	<p>The next motion instruction executes a step seam.</p> <p>The overall length of the step seam and the number and length of the steps are defined in the option window <b>Step parameters</b>.</p>
13	The laser power is switched off and the laser program terminated at the end point of the motion block LIN P5. The laser itself is not switched off.
15	All gases are deactivated.

## 8.2 Example program: gas and laser welding functions

### Program

```

1 DEF Gas ()
2 INI
3 PTP HOME Vel=100 % DEFAULT
4 PTP Start CONT Vel=100 % PDAT0 Tool[1] Base[0]
5 GasInit Gas: GasDef
6 LIN P0 CONT Vel=0.2 m/s CPDAT6 Tool[1] Base[0]
7 LSR INIT Allocation=True Gas: GasDef LSN: LSNDf
8 LIN P1 CONT Vel=0.2 m/s CPDAT1 Tool[1] Base[0]
9 GasSwi Proc_Gas ON Pressure 4 bar Nicht Haltend
10 GasSwi CrossJet ON Nicht Haltend
11 GasSwi Root_Gas ON Nicht Haltend
12 LIN P2 CONT Vel=0.1 m/s CPDAT2 Tool[1] Base[0]
13 LSR On Path=0 mm MSet=ME3 LSet=LS3
14 LIN P3 CONT Vel=0.1 m/s CPDAT3 Tool[1] Base[0]
15 LSR Switch Path=0 mm MSet=ME4 LSet=LS4
16 LIN P4 CONT Vel=0.1 m/s CPDAT4 Tool[1] Base[0]
17 LSR End Path=0 mm MSet=ME2 LSet=LS2 Release
18 LIN P5 CONT Vel=0.1 m/s CPDAT5 Tool[1] Base[0]
19 PTP HOME Vel= 100 % DEFAULT
20 END

```

### Description

Line	Description
5	<p>Initializes the gases. This instruction is used to initialize the process and root gases.</p> <p>If gases are switched on/off with the GasSwi instruction, they must be initialized before the laser is initialized.</p>
7	<p>Initializes the laser. The instruction carries out an implicit request. Light path and laser are selected.</p> <p>This instruction does not perform a reset.</p> <p>The robot motion is generally stopped due to handshake operations with the laser.</p>
9	The process gas is switched on.
10	CrossJet is activated.
11	The root gas is switched on.
13	<p>The instruction refers to the next motion instruction: the laser program is started at the end point of the motion block LIN P3.</p> <p>If the laser has not yet been requested, it is now requested implicitly by means of this instruction. This causes the motion to stop.</p>
15	Modification of the weld parameters. The instruction refers to the next motion instruction.
17	<p>The laser power is switched off and the laser program terminated at the end point of the motion block LIN P5. The laser itself is not switched off.</p> <p>The instruction switches the gas off, as a GasSwi ON instruction has been programmed with the setting "Once". It is not necessary to deactivate the gas with GasSwi OFF.</p> <p>The laser power is ramped down if a ramp time has been programmed.</p>



### 8.3 Example program: set piercing and cutting data

#### Program

```

1 DEF SetCut( )
2 INI
3 PTP HOME Vel=100 % DEFAULT
4 PTP Start CONT Vel=100 % PDAT0 Tool[1] Base[0]
5 LSR CUT Allocation=True Gas: GasDef LSN: LSNDef
6 PTP P1 CONT Vel=10 % PDAT1 Tool[2] Base[0]
7 LIN P2 CONT Vel=0.2 m/s CPDAT1 Tool[1] Base[0]
8 LsrCut InData: CS1
9 LsrCut Sensor=On InDLY=500 msec PgNo=1
10 LIN P3 CONT Vel=0.1 m/s CPDAT4 Tool[1] Base[0]
11 LIN P4 CONT Vel=0.1 m/s CPDAT5 Tool[1] Base[0]
12 LIN P5 CONT Vel=0.1 m/s CPDAT6 Tool[1] Base[0]
13 LsrCut Sensor=Hold InDLY=500 msec PgNo=1
14 LIN P6 CONT Vel=0.1 m/s CPDAT7 Tool[1] Base[0]
15 PTP HOME Vel= 100 % DEFAULT
16 END

```

#### Description

Line	Description
5	Initializes the laser. The instruction carries out an implicit request. Light path and laser are selected.  This instruction does not perform a reset.  The robot motion is generally stopped due to handshake operations with the laser.
8	The piercing and cutting data are set.
9	The distance sensor is switched on.  If InDLY > 0, piercing is carried out from a standstill.
13	The distance sensor remains in the current position.

### 8.4 Example program: piercing function

When the piercing function is called, the following piercing operation is executed:

1. The piercing data are set before the laser is switched on.
2. The robot waits at the start point of the cut (exact positioning).
3. The sensor is moved to the piercing distance.
4. Once the sensor has reached the piercing distance (LSCI\_SnsrPosReached = TRUE), it remains in this position.
5. After a wait time (=piercing time), the sensor is set to the cutting distance.
6. The laser power is reduced to approx. 1% of the maximum power.
7. The cutting gas is changed.
8. The robot starts the laser cutting.

#### Program

```

1 DEF Shape_einsteichen( )
2 INI
3 PTP HOME Vel=100 % DEFAULT
4 PTP Start CONT Vel=100 % PDAT0 Tool[1] Base[0]
5 LSR CUT Allocation=True Gas: GasDef LSN: LSNDef
6 LIN P6 CONT Vel=0.2 m/s CPDAT1 Tool[1] Base[0]
7 GasSwi Cut_Gas ON Nicht Haltend
8 GasSwi CrossJet ON Nicht Haltend
9 LIN P7 CONT Vel=0.2 m/s CPDAT2 Tool[1] Base[0]
10 LsrCutHex Shape=GP1 P12 Vel=1 m/min MSet=ME20 LSet=LS22
    InData=CS1
11 LIN P8 CONT Vel=0.1 m/s CPDAT3 Tool[1] Base[0]
12 LSR Free
13 PTP HOME Vel= 100 % DEFAULT
14 END

```

**Description**

Line	Description
5	<p>Initializes the laser. The instruction carries out an implicit request. Light path and laser are selected.</p> <p>This instruction does not perform a reset.</p> <p>The robot motion is generally stopped due to handshake operations with the laser.</p>
7	The cutting gas is switched on.
8	CrossJet is activated.
10	The piercing and cutting data are set. The piercing function is called and the distance sensor is switched on.
12	The laser is enabled.

## 9 Programming for system integrators

### 9.1 Configuring user-defined applications

- Description** LaserTech can be expanded for up to 3 user-defined applications. These applications can then be selected, in the same way as WELD and CUT, as list entries in the inline forms for initializing and switching the laser.
- In addition, a user-defined data set with up to 12 parameters can be created for each of these applications. This data set can then be selected in the inline forms for switching the laser and edited in an option window.
- Precondition**
- “Expert” user group
- Procedure**
1. In the main menu, select **Display > Variable > Single**.  
The **Variable display – Single** window is opened.
  2. Set the variable LSR\_USR\_TECH to TRUE. The use of user-defined applications is enabled.
  3. Assign one or more variables the values specified here in order to generate the desired list entries in the inline forms:
    - Assign TP\_USR\_ID the value #USR\_LSR. Generates the list entry USR\_LSR.
    - Assign TP\_TCH\_ID the value #USR\_TCH. Generates the list entry USR\_TCH.
    - Assign TP\_LMB\_ID the value #USR\_LMB. Generates the list entry USR\_LMB.
  4. Set the variable LSR\_USR\_PL to TRUE. The option window with the user-defined data set can be displayed and edited.
  5. To initialize the changes, reboot the robot controller with a cold restart.

#### 9.1.1 Changing list entries in the inline forms

- Description** The default list entries generated in the inline forms can be changed so that they match the user-defined application.
- Precondition**
- “Expert” user group
  - To edit the file on the robot controller: Windows interface (smartHMI is minimized)
- Procedure**
1. Open the file C:\KRC\DATA\TPLASER\_USR.KXR.
  2. Search for the key of the desired list entry, e.g. LSR\_LMD.
  3. In the line <text xml:lang="de-DEV">..., enter the German text to be displayed in the list entry.
  4. In the line <text xml:lang="en-DEV">..., enter the English text to be displayed in the list entry.
  5. Save the file.
  6. Reboot the robot controller with a cold restart (with the option **Reload files**).

**Example**

```

</uiText>
<uiText key="LSR_LMD">
  <text xml:lang="de-DEV">Test 1</text>
  <text xml:lang="en-DEV">test 1</text>
</uiText>
<uiText key="LSR_TCH">
  <text xml:lang="de-DEV">Test 2</text>
  <text xml:lang="en-DEV">test 2</text>
</uiText> <uiText key="LSR_USR">
  <text xml:lang="de-DEV">Test 3</text>
  <text xml:lang="en-DEV">test 3</text>
</uiText>

```

**9.1.2 Changing parameter names and units in the option window****Description**

The default parameter names and units generated in the option window can be changed so that they match the user-defined application.

**Precondition**

- "Expert" user group
- Windows interface (smartHMI is minimized).

**Procedure**

1. Open the file C:\KRC\DATA\TPLASER\_USR.KXR.
2. Search for the key of the desired parameter, e.g. Val1 for the parameter name or Val1\_U for the unit of the parameter.
3. In the line <text xml:lang="de-DEV">..., enter the German text or unit to be displayed in the list entry.
4. In the line <text xml:lang="en-DEV">..., enter the English text or unit to be displayed in the list entry.
5. Save the file.
6. Reboot the robot controller with a cold restart (with the option **Reload files**).

**Example**

```

<uiText key="Val1">
  <text xml:lang="de-DEV">Wert 1</text>
  <text xml:lang="en-DEV">Value 1</text>>
</uiText>
<uiText key="Val1_U">
  <text xml:lang="de-DEV">mm</text>
  <text xml:lang="en-DEV">mm</text>
</uiText>

```

**9.2 Integration of user-defined functions****Overview**

Within the LaserTech standard package, functions of different interfaces are called. In each case, this involves the transfer of a command as ENUM, an integer parameter and a function argument.

Interface	Call
LSR_Tech_IFC (>>> 9.3.1 "Interface to the laser process LSR_Tech_IFC" Page 70)	LSR_Tech_IFC(#CMD, x, y) Call defined in Lsr_Tech_IC.src
LSR_Lsr_IFC (>>> 9.3.2 "Interface to the laser control LSR_Tech_IFC" Page 72)	LSR_Lsr_IFC(#CMD, x, y) Call defined in LSR_Lsr_IC.src

Interface	Call
LSR_Media_IFC (>>> 9.3.3 "Interface to media LSR_Media_IFC" Page 72)	LSR_Media_IFC(#CMD, x, y) Call defined in Lsr_Media_IC.src
LSR_Err_IFC (>>> 9.3.4 "Interface to error handling LSR_ERR_IFC" Page 73)	LSR_Err_IFC(#CMD, x, y) Call defined in Lsr_Err_Ic.src

**Example**

By way of example, the interface function call is described here for the interface to the laser process LSR\_Tech\_IFC.

If only LaserTech is used, the file Lsr\_Tech\_IC.src has the following structure:

```

1 DEF Lsr_Tech_IC()
2 END
3 Global DEF LSR_Tech_IFC (Action :In, CallID :IN, Arg :IN)
4 ;*****
5 ;* Interface to the different laser technologies *
6 ;*
7 ;* Date: 02.2013
8 ;*
9 ;*****
10 DECL Tech_Interface Action
11 DECL INT CallID
12 DECL INT Arg
13 ;Fold Tech Interfaces
14 ;ENDFOLD (TechInterfaces)
15 END ; (LSR_TECH_IFC)

```

Line	Description
3	Declaration of the global subprogram LSR_Tech_IFC Interface to the laser process
10	Action currently being executed
11	If there are a number of tasks for one action, these are distinguished by the CallID.
12	Open parameter for user-defined expansion

If the LaserWeld or LaserCut option is used in addition, a fold is inserted during installation in which the TechHandle of the respective option is polled. If the TechHandle is then set in a higher-level function, the specific function for LaserWeld or LaserCut is called and executed.

```

1 DEF Lsr_Tech_IC()
2 END
3 ...
13 ;Fold Tech Interfaces
14 ;Fold Weld Interfaces
15 IF TechHandle == TP_Weld_ID THEN
16 LSW_TECH_IFC(Action, CallID, Arg)
17 ENDIF
18 ;ENDFOLD (WeldInterfaces)
19 ;ENDFOLD (TechInterfaces)
20 END ; (LSR_TECH_IFC)

```

Line	Description
15 ... 17	Polling the TechHandle of the LaserWeld option

To expand LaserTech with user-specific functions, a corresponding TechHandle must be programmed.

```

1 DEF Lsr_Tech_IC ()
2 END
...
13 ;Fold Tech Interfaces
14 ;Fold Weld Interfaces
15 IF TechHandle == TP_Weld_ID THEN
16   LSW_TECH_IFC(Action, CallID, Arg)
17 ENDIF
18 IF TechHandle == #LSR_LMD THEN
19   LSW_LMD_IFC(Action, CallID, Arg)
20 ENDIF
21 ;ENDFOLD (WeldInterfaces)
22 ;ENDFOLD (TechInterfaces)
23 END ; (LSR_TECH_IFC)

```

Line	Description
18 ... 20	Polling the TechHandle of an additional user-specific function
19	Within the subprogram LSW_LMD_IFC, which must be created separately, the user-specific function calls are programmed.  The name of the subprogram is freely selectable.

## 9.3 Interfaces for functional expansions

### 9.3.1 Interface to the laser process LSR\_Tech\_IFC

Action	CallID	Arg	Call	Description
Tech_ON	0	0	Isr_err_handler.src LSR_RESTART_LASER;262	Call if the restart option <i>Hot</i> is selected as the response in the dialog displayed after an error.
	1	0	Isr_MainFunc.src LSR_ON;613	At the start of the procedure
	2	0	Isr_MainFunc.src LSR_ON;634	Before setting the sync input (e.g. LSRI_LsrSet3)
	3	0	Isr_MainFunc.src LSR_ON;637	After setting Start static
	4	0	Isr_MainFunc.src LSR_ON;640	Activation not permitted, before ramping down the laser
	5	0	Isr_MainFunc.src LSR_ON;649	Activation not permitted, after enabling of the laser
	6	0	Isr_MainFunc.src LSR_ON;654	At the end of LaserOn
Tech_Pre_ON	0	0	Isr_MainFunc.src LSR_PRE_ON;526	At the start of the function
	1	0	Isr_MainFunc.src LSR_PRE_ON;541	At the end of the function

Action	CallID	Arg	Call	Description
Tech_Swi	1	0	Isr_MainFunc.src LSR_Swi;668	At the start of the function
	2	0	Isr_MainFunc.src LSR_Swi;702	After power change
	3	0	Isr_MainFunc.src LSR_Swi;731	After executing the switch action
	4	0	Isr_MainFunc.src LSR_Swi;733	At the end of the function
Tech_Pre_Swi	1	0	Isr_MainFunc.src LSR_Pre_Swi;554	At the start of the function
	2	0	Isr_MainFunc.src LSR_Pre_Swi;576	At the end of the function
Tech_Off	1	0	Isr_MainFunc.src LSR_Off;746	At the start of the function
	2	0	Isr_MainFunc.src LSR_Off; 762	As preparation for the next section with laser power
	3	0	Isr_MainFunc.src LSR_Off;770	At the end of the function
Tech_Pre_Off	1	0	Isr_MainFunc.src LSR_Pre_Swi;588	At the start of the function
	2	0	Isr_MainFunc.src LSR_Pre_Swi;598	At the end of the function
TECH_RELDEVICE	0	0	Isr_MainFunc.src LSR_PLC; 60	Monitoring of whether the robot interpreter is running
TECH_INIT	0	0	Isr_MainFunc.src LSR_INIT_LASER; 191	If Lsr_alloc = True, after enabling of the laser
TECH_INITNOALLOC	0	0	Isr_MainFunc.src LSR_INIT_LASER; 196	If Lsr_alloc = False, after enabling of the laser
TECH_INIT_SNSR	0	0	Isr_MainFunc.src LSR_INIT_LASER; 199	After complete initialization
TECH_RESET	0	0	Isr_MainFunc.src Lsr_Reset_Flags; 231	At the end of the function
TECH_RELDEVICE	0	0	Isr_MainFunc.src LSR_LASER_OFF; 287	After deactivation, before Standby is removed
TECH_INITPERI	0	0	Isr_MainFunc.src LSR_InitCheckPeripherals; 331	Before the gas check
TECH_NOMOTION	0	0	Isr_MainFunc.src LSR_StillstandControl; 331	If standstill monitoring triggered, after deactivation
TECH_PRE_STEP	1	0	Isr_MainFunc.src LSR_PRE_Step; 801	At the start of the function

### 9.3.2 Interface to the laser control LSR\_Tech\_IFC

Action	CallID	Arg	Call	Description
LSR_ON_RDY	0	0	lsr_TR_IFC.src LSR_ON_AND_READY; 150	At the end of the function
LSR_TECHSTOP	0	0	lsr_TR_IFC.src LSR_ANOUT_TECHSTOP; 579	At the end of the function, if power was activated
LSR_ISR_STOP	0	0	lsr_TR_IFC.src LSR_ANOUT_ISR_STOP; 591	At the start of the function, if power was activated
LSR_ISRRESTORE	0	0	lsr_TR_IFC.src LSR_ANOUT_ISR_RESTORE; 612	At the start of the function, if power was activated

### 9.3.3 Interface to media LSR\_Media\_IFC

Action	CallID	Arg	Call	Description
Tech_ON	1	fswi	Lsr_MediaFunc.src LSR_GAS_SWI;432	Switch on all gases, TechHandles #Tech and #Weld
	2	fswi	Lsr_MediaFunc.src LSR_GAS_SWI;434	Switch on all gases, all other TechHandles
	3	ipressure	Lsr_MediaFunc.src LSR_GAS_SWI;445	Switch root gas if Lsr_RootFlag = false
	4	ipressure	Lsr_MediaFunc.src LSR_GAS_SWI;451	Switch root gas if Lsr_RootFlag = false, second call
	5	ipressure	Lsr_MediaFunc.src LSR_GAS_SWI;454	Switch on cutting gas, before valves opened
	6	ipressure	Lsr_MediaFunc.src LSR_GAS_SWI;456	Switch on cutting gas, after valves opened
GAS_INIT	0	0.0	LSR_InitGas.src LSR_InitGas;44	After cycflag definition, TechHandle #CUT, #WELD
	11	0.0	LSR_InitGas.src LSR_InitGas;51	After cycflag definition, all other TechHandles
TECH_CHECK_GAS	0	0.0	lsr_MainFunc.src LSR_GAS_CHECK;104	If TechHandle #Weld or Lsr_usrootflag = true
	11	0.0	lsr_MainFunc.src LSR_GAS_CHECK;97	If TechHandle #Tech



## 9.3.4 Interface to error handling LSR\_ERR\_IFC

Action	CallID	Arg	Call	Description
ERR_SENSOR	0	0	lsr_err_handler.src LSR_RESTART_LASER; 202	Call if the restart option <i>Cold</i> is selected as the response in the dialog displayed after an error. This call is the last call in the branch.
	1	0	lsr_err_handler.src LSR_RESTART_LASER; 217	Call if the restart option <i>Seam cold</i> is selected as the response in the dialog displayed after an error. This call is the last call in the branch.
	2	0	lsr_err_handler.src LSR_RESTART_LASER; 236	Call if the restart option <i>Cold section</i> is selected as the response in the dialog displayed after an error. This call is the last call in the branch.
	3	0	lsr_err_handler.src LSR_RESTART_LASER; 236	Call if the restart option <i>Hot</i> is selected as the response in the dialog displayed after an error. This call is the first call in the branch.
	4	0	lsr_err_handler.src LSR_SENSOR_ERROR, 544	If the error is a sensor error, this call is made after deactivation of the laser.
ERR_LASER_SAFE TY	0	0	lsr_err_handler.src LSR_LASER_SAFETY(); 27	After the process has been deactivated, technology-specific actions may be executed here.
	1	0	lsr_err_handler.src LSR_LASER_SAFETY(); 68	After dialogs have been responded to and the cause of the error has been eliminated, technology-specific actions and further dialogs may be executed here.
ERR_GAS	0	0	lsr_err_handler.src LSR_MEDIA_ERROR();1 21	After all default handling strategies after a gas error have been carried out, a technology-specific code may be executed.
ERR_WIRE	0	0	lsr_err_handler.src LSR_MEDIA_ERROR();1 26	The call takes place after the technology-specific gas action and the user gas action.
ERR_MEDIA	0	0	lsr_err_handler.src LSR_RESTART_LASER; 239	Call if the restart option <i>Hot</i> is selected as the response in the dialog displayed after an error.

Action	CallID	Arg	Call	Description
ERR_RESTART	1	0	lsr_err_handler.src LSR_RESTART_LASER; 208	As preparation for the next seam with laser power.
	2	0	lsr_err_handler.src LSR_RESTART_LASER; 228	As preparation for the next section with laser power.
	3	0	lsr_err_handler.src LSR_RESTART_LASER; 250	Error handling is completed, the laser is ready to continue welding.
	4	0	lsr_err_handler.src LSR_RESTART_LASER; 259	Laser restart procedure
	5	0	lsr_err_handler.src LSR_RESTART_LASER; 274	Laser restart procedure failed.
ERR_SHUTDOWN	0	0	lsr_err_handler.src SHUT_DOWN_PROCES S; 341	In the event of an error, after termination of the process
	11	0	lsr_err_handler.src SHUT_DOWN_PROCES S; 355	In the event of an error, after the process has reached the end of the shut-down routine
ERR_LSR_INIT	0	0	lsr_err_handler.src LSR_ISR_INIT_LASER; 450	If an error was triggered, due to an interrupt, on starting re-initialization
	11	0	lsr_err_handler.src LSR_ISR_INIT_LASER; 457	If an error was triggered, due to an interrupt, on completing re-initialization

## 10 Messages

### 10.1 Basic laser function messages

Message	Description/remedy	Key
<i>Collision protection device triggered! Please move the robot clear in Test1 or Test2 mode</i>	A collision has occurred. <ul style="list-style-type: none"> <li>■ Move away from the collision in T1 or T2 mode.</li> <li>■ Resume program execution or re-set program and laser.</li> </ul>	CollisionDe- tected
<i>The laser shutter will be closed dur- ing block selection</i>	For safety reasons, use of the laser power is prevented during block selection.	LaserShutDown- AtBlockSelect
<i>Laser is still not activated: No LASER ON state</i>	Possible causes: <ul style="list-style-type: none"> <li>■ The laser is not switched on.</li> <li>■ The laser is currently being reset.</li> <li>■ The laser is in manual mode.</li> </ul>	NoLaserOnSta- tus
<i>No laser application possible without crossjet!</i>	<ul style="list-style-type: none"> <li>■ Activate CrossJet.</li> <li>■ Acknowledge the message.</li> <li>■ Resume or restart program.</li> </ul>	MissingCrossJet
<i>Block command failed.</i>	An error has occurred during execu- tion of a technology-specific instruc- tion.  Please contact the Service Depart- ment if this error recurs.	BlockCommand- Failed
<i>No valid inline form</i>	An error has occurred during execu- tion of a technology-specific instruc- tion.  Please contact the Service Depart- ment if this error recurs.	NoInlineForm
<i>Wrong value of \$PRO_I_O[] (\$CUS- TOM.DAT) or no submit routine selected</i>	<ul style="list-style-type: none"> <li>■ Deselect program.</li> <li>■ Deselect Submit.</li> <li>■ Change value, start Submit.</li> </ul>	WrongSubmitInt- erpreter
<i>Error message at laser system</i>	<ul style="list-style-type: none"> <li>■ Eliminate laser error.</li> <li>■ Acknowledge the message.</li> <li>■ Resume or restart program.</li> </ul>	ErrorAtLaser
<i>Continuing the process only sensible with correct operating mode and pre- vious override value!</i>	A collision has occurred. <ul style="list-style-type: none"> <li>■ Move away from the collision in T1 or T2 mode.</li> <li>■ Reset program and laser.</li> </ul>	CollisionCor- rectModeOpera- tion
<b>Internal error!</b>	An error has occurred during execu- tion of a technology-specific instruc- tion.  Please contact the Service Depart- ment if this error recurs.	InternalError
<i>No gas available! Please check gas equipment</i>	This error message is triggered by the process gas monitoring.	NoGasFlow

Message	Description/remedy	Key
<i>Laser is not available and shutter is closed</i>	Possible causes: <ul style="list-style-type: none"> <li>■ A required signal has not been generated or was not detected by the laser.</li> <li>■ Error in the laser controller</li> </ul>	NoLaserActive-AndShutter-Closed
<i>No feedback of the laser by external control</i>	The signal LSRI_LsrExternEnabled is not generated. Possible causes: <ul style="list-style-type: none"> <li>■ The laser is not switched on.</li> <li>■ The laser is currently being reset.</li> <li>■ The laser is in manual mode.</li> </ul>	NoExternMode-Possible
<i>Laser is still not in standby mode</i>	Possible causes: <ul style="list-style-type: none"> <li>■ A required signal has not been generated or was not detected by the laser.</li> <li>■ Error in the laser controller</li> </ul>	LaserStillNotIn-Standby
<i>Laser still not ready or not assigned</i>	The laser program cannot be started. Possible causes: <ul style="list-style-type: none"> <li>■ The laser is not switched on.</li> <li>■ The laser is currently being reset.</li> <li>■ The laser is in manual mode.</li> </ul>	LaserStill-NotReady
<i>Laser flags critical error to cell control</i>	An error has occurred in the laser periphery. Depending on the configuration, this may also be a robot error.	LsrExternError
<i>Laser still waiting for allocation</i>	The instruction LSR Allocate has been called. The laser is not free, however. This message is displayed during the wait time.	LaserWaiting-ForAllocation
<i>Laser error -&gt; Details on console of laser system</i>	Refer to message on the laser console.	DetailsToLsrErrorsOnConsole
<i>Laser error -&gt; Details on laser console ---&gt; Resumption of program after laser reset</i>	Refer to message on the laser console.	LsrErrorLookOn-Console
<i>Laser error has occurred</i>	<ul style="list-style-type: none"> <li>■ Eliminate laser error.</li> <li>■ Acknowledge the message.</li> <li>■ Resume or restart program.</li> </ul> Depending on the nature of the error, the message "ErrorAtLaser" may also be generated.	LaserErrorAvailable
<i>Invalid laser command -&gt; LASER INIT command necessary</i>	An invalid laser command has been initiated. A program reset is generally required.	LaserCommand-IncompatibleTo-Package

Message	Description/remedy	Key
<i>Laser program was canceled</i>	The laser signals the cancelation of an active program. Possible causes: <ul style="list-style-type: none"> <li>■ The signal LSRO_LsrReset is set during an active program.</li> <li>■ The signal LSRO_LsrStartStatic is reset before the signal LSRO_LsrStopProgram has been set.</li> </ul>	LsrProgramCancel
<i>Laser program could not be activated: Please check errors on laser console</i>	Possible causes: <ul style="list-style-type: none"> <li>■ A required signal has not been generated or was not detected by the laser.</li> <li>■ Error in the laser controller</li> </ul>	NotProgramActive
<i>Laser was switched to manual mode ---&gt; Resumption of process after laser reset</i>	Cause: Manual mode has been forced on the laser console.	LsrInManual-Mode
<i>Check media control!</i>	<ul style="list-style-type: none"> <li>■ Eliminate media error.</li> <li>■ Acknowledge the message.</li> <li>■ Resume or restart program.</li> </ul>	CheckMedia-Control
<i>Periphery not in a safe state</i>	<ul style="list-style-type: none"> <li>■ Check the safety equipment.</li> <li>■ Eliminate problem.</li> <li>■ Reset program and laser.</li> </ul>	LsrPeripheryNot-Safe
<i>Complete program will be continued without active process. Resumption with active process by executing LASER_INIT command</i>	Cause: Following an error, this option (= continue complete program without active process) has been selected as a response in a dialog window.	CompleteCold-Run
<i>Cold run selected</i>	Cause: The program is executed without laser power. The status key "Laser off" is displayed.  Remedy: Activate the laser using the status key.	NoLsrControl-ColdRun
<i>Program was aborted or external error signal active</i>	<ul style="list-style-type: none"> <li>■ Eliminate problem.</li> <li>■ Acknowledge the message.</li> <li>■ Resume or restart program.</li> </ul>	ProgAbortOrExt-Failure
<i>No process gas!</i>	<ul style="list-style-type: none"> <li>■ Activate process gas.</li> <li>■ Acknowledge the message.</li> <li>■ Resume or restart program.</li> </ul>	MissingProcess-Gas
<i>Please acknowledge errors on laser console first</i>	Laser errors cannot be reset from the robot.	LsrReceiptMessage
<i>Robot was stopped by an interpreter stop</i>	The robot interpreter has been stopped by: <ul style="list-style-type: none"> <li>■ STOP key</li> <li>■ EMERGENCY STOP</li> <li>■ Operator safety</li> <li>■ Operating mode change</li> <li>■ Releasing the enabling switch</li> </ul>	LsrInTechStop

Message	Description/remedy	Key
<i>Laser safety circuit is still open: Ensure laser safety before the robot program is resumed</i>	Possible causes: <ul style="list-style-type: none"> <li>■ The safety circuit is open.</li> <li>■ Light path settings in the laser do not match the requested light path.</li> </ul>	SikContactOpen
<i>Safety circuit open, shutter closed</i>	Possible causes: <ul style="list-style-type: none"> <li>■ The safety circuit is open.</li> <li>■ Light path settings in the laser do not match the requested light path.</li> </ul>	ShutterOpen
<i>Standstill monitoring: Laser was switched off because robot welded for too long at the same position</i>	If welding is to be carried out for longer at a specific position, i.e. without robot motion, the value of LSR_Stop_InspectionTime must be increased.	RobotStandStill
<i>Standstill monitoring: Laser has not been used for a long time and has just been shut down</i>	The interval after which the laser is deactivated can be increased in the configuration. (LSR_LaserStandbyDelay)	LaserStandStill
<i>Robot stopped ---&gt; Resumption of the process</i>	<ul style="list-style-type: none"> <li>■ Eliminate cause of the stop reaction.</li> <li>■ Answer the dialog and resume or restart the program.</li> </ul>	LsrRobotError
<i>Error of laser system ---&gt; Resumption of process possible after dialog and forced reset of laser</i>	Refer to message on the laser console.	CollectionErrorOfLaser
<i>Test commands only possible in operating mode Test1 or Test2!</i>	<ul style="list-style-type: none"> <li>■ Change operating mode.</li> <li>■ Restart the program.</li> </ul>	NoFocusPulsInAutomatic
<i>Invalid parameter list</i>	An error has occurred during execution of a technology-specific instruction.  Please contact the Service Department if this error recurs.	ParamListHandleUnknown
<i>Insufficient gas pressure! Please check gas equipment.</i>	<ul style="list-style-type: none"> <li>■ Eliminate problem.</li> <li>■ Reset program.</li> </ul>	NotEnoughGasPressure
<i>No root gas!</i>	<ul style="list-style-type: none"> <li>■ Activate root gas.</li> <li>■ Acknowledge the message.</li> <li>■ Resume or restart program.</li> </ul>	MissingRootGas
<i>Cell or laser safety error. Check safety equipment!</i>	<ul style="list-style-type: none"> <li>■ Eliminate problem.</li> <li>■ Acknowledge the message.</li> <li>■ Resume or restart program.</li> </ul>	LsrCellOrSafetyError
<i>Gas pressure too low. The current program will be aborted. Please check gas !!!</i>	<ul style="list-style-type: none"> <li>■ Correct the gas pressure.</li> <li>■ Acknowledge the message.</li> <li>■ Resume or restart program.</li> </ul>	LastPartToLessGas
<i>Laser allocation denied</i>	Possible causes: <ul style="list-style-type: none"> <li>■ The laser is allocated to a different station.</li> <li>■ The laser is in manual mode.</li> <li>■ An error has occurred.</li> </ul>	LaserAllocationAvoided

## 10.2 LaserCut messages

Message	Description/remedy	Key
<i>Error in user-defined sensor code!</i>	An error has occurred within the user-defined function so that the return value $\neq 0$ .  Remedy: Eliminate the error and ensure that the return value = 0.	ErrorInUserDef-SnsrProc
<i>Function not implemented!</i>	A non-implemented function has been called. Please inform the Service Department.	NOT_IMPLEMENTED
<i>Initialization of user-defined sensor code failed!</i>	An error has occurred within the user-defined function so that the return value $\neq 0$ .  Remedy: Eliminate the error and ensure that the return value = 0.	InitOfUserDef-SensorFailed
<i>Programmed position not reached</i>	<ul style="list-style-type: none"> <li>■ Reset the sensor using the sensor controller.</li> <li>■ Reset program.</li> </ul>	NoProgPos
<i>Sensor error</i>	Eliminate the sensor controller error and acknowledge the message.	SnsrError
<i>Sensor cable interrupted!</i>	<ul style="list-style-type: none"> <li>■ Eliminate problem.</li> <li>■ Reset program.</li> </ul>	SnsrCableError
<i>Collision monitoring</i>	The distance sensor signals a collision. Eliminate the sensor controller error and acknowledge the message.	SnsrCollision
<i>Use of a reserved sensor type!</i>	An attempt has been made to initialize a reserved sensor type within a user-defined function.	UseOfReserved-SnsrType

## 10.3 LaserWeld messages

Message	Description/remedy	Key
<i>Wire or wirefeeder not available</i>	<ul style="list-style-type: none"> <li>■ Check wire feed system.</li> <li>■ Check configuration for the wire feed system in the robot controller.</li> </ul>	WireFeeder-NotReady
<i>Please acknowledge errors of the wirefeed unit</i>	<ul style="list-style-type: none"> <li>■ Acknowledge message on wire feed system.</li> <li>■ Acknowledge this message on the robot controller.</li> </ul>	WfdReceiptMessage
<i>Please acknowledge errors on the wire heater unit</i>	<ul style="list-style-type: none"> <li>■ Acknowledge message on the welding wire heater.</li> <li>■ Acknowledge this message on the robot controller.</li> </ul>	AcknWfdHeat-Message
<i>Wire heater error</i>	<ul style="list-style-type: none"> <li>■ Eliminate error in the wire heater.</li> <li>■ Acknowledge the message.</li> </ul>	WireFeedHeat-Problem





## 11 Appendix

### 11.1 Configuring LaserTech

#### 11.1.1 LaserTech: analog inputs/outputs, interrupts, timers and cyclical flags



The numbers for inputs/outputs, interrupts, timers and cyclical flags must only be assigned once in the entire robot controller.

#### NOTICE

Incorrect configuration of the internal analog channels can result in the laser working with incorrect parameters. Damage to the system may result.

#### Analog outputs

Outputs 1 to 32 are available.

Output	Description	Default
LSRO_LsrPwr	Analog channel for the laser power	2
LSRO_GasPressure	Analog channel for gas pressure	4

#### Analog inputs

Inputs 1 to 32 are available.

Output	Description	Default
LSRI_GasPressure	Analog channel for gas pressure	4

#### Interrupts

#### NOTICE

If the priority of the interrupts is changed, this may result in a double assignment. Furthermore, the interrupts for the LaserTech monitoring functions may receive a priority that is so low that they are processed too late. This can cause damage to the system.

Interrupts 1 to 39 are available.

Interrupt	Description	Default
LSR_InterrAntiCollission	Interrupt number for the anticollision monitoring	7
LSR_InterruptLaserSafety	Interrupt number for the laser safety. The error states of the laser are monitored.	8
LSR_InterruptDistSensor	Interrupt number for the distance sensor	9
LSR_InterruptMedias	Interrupt number for the media controller.	10
LSR_InterruptStepMon	Interrupt number for the step seam monitoring	11
LSR_AnoutCheck	Interrupt number for monitoring of the laser power on analog channel LSRO_LsrPwr	12
LSR_InterruptUsrTech	Only relevant if user-defined applications are used and these require a separate interrupt  Interrupt number for monitoring a user-specific function	30

#### Timer

Timers 1 to 32 are available.

Timer	Description	Default
LSR_TC_PostGas	Timer number for the gas postflow time	15
LSR_TC_PreFlowGas	Timer number for the gas preflow time	16

Timer	Description	Default
LSR_TC_STEP	Timer number for the step function	17
LSR_TC_Check	Timer number for internal timeouts, e.g. gas monitoring or checkback signals of the laser	18


### Cycflags


**NOTICE** If the number of cyclical flags is changed, this may result in a double assignment. Furthermore, the numbers of the cyclical flags for the LaserTech monitoring functions may be overwritten. This can cause damage to the system.

Cycflags 1 to 32 are available.

Cycflag	Description	Default
LSR_CF_GasCtrl	Cycflag number for the gas controller	13
LSR_CF_STEPCTRL	Cycflag number for the step seam monitoring	28
LSR_CF_STEP	Cycflag number for the step controller	29
LSR_CF_LaserCtrl	Cycflag number for the laser monitoring	30
LSR_CF_AnoutCheck	Cycflag number for monitoring of the laser power on analog channel LSRO_LsrPwr	31
LSR_CF_MediaCtrl	Cycflag number for the media monitoring	32
LSR_CF_UsrTech	Only relevant if user-defined applications are used and these require a separate interrupt  Cycflag number for monitoring a user-specific function	27

#### 11.1.2 LaserTech: signal outputs to the laser

 Detailed information about the laser controller is contained in the TRUMPF documentation.

 The signals described in this section can be found in the file ...R1\System\CONFIG.DAT. To adapt the values, the file must be edited.

### LASERTECH GLOBALS


#### LASER OUTPUTS


Signal	Description	Type	\$OUT[]
LSRO_LsrRequest	Request laser.	BOOL	97
LSRO_LsrPilotOn	Switch pilot laser on.	BOOL	98
LSRO_LsrSync1	Synchronize laser with robot (1). Query whether laser is ready.  <b>Note:</b> By default, the robot controller uses LSRO_LsrSync1 for the query.	BOOL	103
LSRO_LsrSync2	Synchronize laser with robot (2). Query whether laser is ready.	BOOL	102
LSRO_LsrFaultExtern	Robot fault (fault that is external to the laser controller)	BOOL	104
LSRO_LsrReset	Reset laser.	BOOL	105
LSRO_LsrStopProgram	Stop laser program.	BOOL	106
LSRO_LsrStartDynamic	Laser program start dynamic	BOOL	107
LSRO_LsrStartStatic	Laser program start static	BOOL	108

Signal	Description	Type	\$OUT[]
LSRO_LsrStandby	Set laser to standby.	BOOL	109
LSRO_LsrOn	Switch laser on.	BOOL	110
LSRO_LsrOperationOff	Disable laser console.	BOOL	111
LSRO_LsrExternControl	Enable external control.	BOOL	112
LSRO_LsrPrgNrBCD10	BCD code program number upper bits*	4 bits	117 ... 120
LSRO_LsrPrgNrBCD1	BCD code program number lower bits*	4 bits	113 ... 116
LSRO_LsrPrgSetDual	Laser program number binary coded*	Byte	113 ... 120
LSRO_LsrFiber	Light path number	Byte	121 ... 128
LSRO_LsrLaserNr	Laser number	Byte	129 ... 136
LSRO_LsrRobotNr	Robot number	Byte	137 ... 144
LSRO_LsrDataWord0	Laser data word 0	Word	97 ... 112
LSRO_LsrPwr	Analog channel for the laser power \$ANOUT[2]	INT	—
LSRO_LsrDataWord3	Laser data word 3	Word	113 ... 128
LSRO_LsrDataWord4	Laser data word 4	Word	193 ... 208
LSRO_LsrRampTime	Ramp length	Word	145 ... 160
LSRO_LsrRmpUpStartVal	Ramp start value (ramp up)	Word	257 ... 272
LSRO_LsrRmpUpEndVal	Ramp end value (ramp up)	Word	273 ... 288
LSRO_LsrRmpDownStartVal	Ramp start value (ramp down)	Word	289 ... 304
LSRO_LsrRmpDownEndVal	Ramp end value (ramp down)	Word	305 ... 320

\* Whether program numbers are transferred as BCD coded or binary coded values depends on the variable LSR\_MPI\_Interface (>>> 11.1.7 "LaserTech: process options" Page 86).

### 11.1.3 LaserTech: signal inputs from the laser

 Detailed information about the laser controller is contained in the TRUMPF documentation.


 The signals described in this section can be found in the file ...R1\System\CONFIG.DAT. To adapt the values, the file must be edited.

**LASERTECH  
GLOBALS**

LASER INPUTS

Signal	Description	Type	\$IN[]
LSRI_LsrWarnLampOn	Laser warning lamps are on.	BOOL	97
LSRI_LsrPilotOn	Pilot laser is on.	BOOL	98
LSRI_LsrAssigned	Laser is assigned.	BOOL	100
LSRI_LsrInternFault	Internal laser fault	BOOL	101
LSRI_LsrFailure	Laser monitoring message The robot stops.	BOOL	102
LSRI_LsrShutterClosed	Shutter is closed.	BOOL	103
LSRI_LsrSet3	Sync input 3 <b>Note:</b> By default, the robot controller polls sync input 3.	BOOL	106
LSRI_LsrSet2	Sync input 2	BOOL	105
LSRI_LsrSet1	Sync input 1	BOOL	104
LSRI_LsrProgAbort	Laser program canceled.	BOOL	107
LSRI_LsrProgEnd	End of laser program.	BOOL	108
LSRI_LsrProgActive	Program is active.	BOOL	109
LSRI_LsrStandby	Laser is in standby.	BOOL	110
LSRI_LsrActive	Laser is active.	BOOL	111
LSRI_LsrExternEnabled	External control is enabled.	BOOL	112
LSRI_LsrFiberNo	Enabled light path number	Word	145 ... 160
LSRI_LsrFiberSafetyCode	Light path number via safety box	Word	161 ... 176

#### 11.1.4 LaserTech: signal outputs to the welding periphery

 The signals described in this section can be found in the file ...R1\System\\$\_CONFIG.DAT. To adapt the values, the file must be edited.


### LASERTECH GLOBALS

#### INTEGRATION peripheri devices

Signal	Description	Type	\$OUT[]
LSRO_Error_Cell	Cell error (flag to PLC)	BOOL	501
LSRO_Error_Media	Media error (flag to PLC)	BOOL	501
LSRO_AntiCollissionDev	Collision monitoring (flag to PLC)	BOOL	502
LSRO_Error_Sensor	Sensor error (flag to PLC)	BOOL	503
LSRO_ColdFor1Section	The next seam section is executed without power (flag to PLC)  A section is defined as what comes between the instructions <b>Activate process</b> , <b>Switch process</b> and <b>Deactivate process</b> .	BOOL	504
LSRO_ColdFor1Seam	The next seam is executed without power (flag to PLC).  A seam is defined as what comes between the instructions <b>Activate process</b> and <b>Deactivate process</b> .	BOOL	505

Signal	Description	Type	\$OUT[]
LSRO_ColdForEver	Without power until the next laser initialization (flag to PLC)	BOOL	506
LSRO_ColdApplication	The complete program is executed without power (flag to PLC).	BOOL	507
LSRO_CrossJet	Activate/deactivate CrossJet.	BOOL	515
LSRO_GasPressure	Only relevant if a proportional gas valve is used (LSR_PropGasValve = TRUE).  Number of the analog channel for the gas pressure \$ANOUT[4]	INT	—
LSRO_GasEnable	Only relevant if a proportional gas valve is used (LSR_PropGasValve = TRUE).  Output enable the selected gas  <b>Note:</b> Normally used with an additional main valve.	BOOL	72

### 11.1.5 LaserTech: signal inputs from the welding periphery


 The signals described in this section can be found in the file ...R1\System\CONFIG.DAT. To adapt the values, the file must be edited.

## LASERTECH GLOBALS

INTEGRATION peripheri devices


Signal	Description	Type	\$IN[]
LSRI_AntiCollisionDev	This input can be used for collision monitoring.	BOOL	1025
LSRI_UsrInput1	These user-specific inputs can be used to integrate customer signals into the process monitoring in order to stop the process in the event of a fault.	BOOL	1025
LSRI_UsrInput2		BOOL	1025
LSRI_CrossJet	Checkback CrossJet OK	BOOL	1025
LSRI_GasPressure	Only relevant if a proportional gas valve is used (LSR_PropGasValve = TRUE).  Number of the analog channel for the gas pressure \$ANIN[4]	INT	—

### 11.1.6 LaserTech: system outputs and system flags

 The variables described in this section can be found in the file Laser.dat in the directory R1\TP\LaserTech. To display or change the values, select **Display > Variable > Single** from the main menu.

Variable	Description
S_Int_Flag	<p>Submit watchdog</p> <p>This digital output can be used together with the variable S_Int_Cycl to monitor whether the submit interpreter is running cyclically. The monitoring only works usefully if this output is continuously TRUE. To achieve this, the value of S_Int_Cycl must be a little higher than the cycle time of the SPS.SUB program.</p> <p>(&gt;&gt;&gt; 11.1.8 "LaserTech: process constants" Page 88)</p> <p>Default: <b>765</b></p>
LSRO_Error_Bypass	<p>Masking of digital input events</p> <p>If an interrupt is activated while the condition for this interrupt is met, e.g. because the corresponding cycflag is true, then the interrupt cannot trigger. The output LSRO_Error_Bypass is used to set the cycflag via a pulse instruction to ensure that the condition is not met at the point in time at which the interrupt is activated. At the end of the pulse, the interrupt can react.</p> <p>This digital output is used internally during monitoring of the process. The output may only be used once.</p> <p>Default: <b>601</b></p>
AnoutBypass	<p>Masking of analog input events (functionality as with LSRO_Error_Bypass)</p> <p>This digital output is used internally during monitoring of the process. The output may only be used once.</p> <p>Default: <b>602</b></p>
LSR_UserErrorFLAG	<p>To allow other installed options to interrupt the laser process, this variable can be set to FALSE. The interrupt is then triggered and the process terminated.</p>

### 11.1.7 LaserTech: process options

 The variables described in this section can be found in the file Laser.dat in the directory R1\TP\LaserTech. To display or change the values, select **Display > Variable > Single** from the main menu.

Variable	Description
LSR_MPI_Interface	<p>Coding of the program number</p> <p>TRUE = Program number is transferred as a binary-coded value, i.e. as an 8-bit binary number (00 ... 255).</p> <p>FALSE = Program number is transferred as a BCD-coded value, i.e. 4 bits for the units and 4 bits for the tens of the program number (00 ... 99).</p> <p>Default: TRUE</p>
LSR_CrossJetOption	<p>Activate/deactivate CrossJet.</p> <p>TRUE = CrossJet is activated on initialization of the laser and deactivated at the end of the program.</p> <p>FALSE = CrossJet is activated and deactivated via the inline forms <b>Activate process</b>, <b>Deactivate process</b> and <b>Switch gas</b>.</p> <p>Default: FALSE</p>

Variable	Description
LSR_UsePwrVelCtrlId	<p>Activate/deactivate the velocity-dependent laser power.</p> <p>TRUE = Laser power is dependent on the robot velocity.</p> <p>FALSE = Laser power remains constant at the value entered in the inline form.</p> <p>Default: FALSE</p>
LSR_LsrFiberMirroringOption	<p>Activate/deactivate mirroring of the light path number.</p> <p>TRUE = The laser fiber number mirrored by the laser controller is evaluated.</p> <p>FALSE = The laser fiber number mirrored by the laser controller is not evaluated.</p> <p>Default: FALSE</p>
LSR_UseGas	<p>Use gas when executing the program.</p> <p>TRUE = The programs are executed with gas.</p> <p>FALSE = The programs are executed without gas. This is suitable, for example, for test purposes where no gas is desired.</p> <p>Default: TRUE</p> <p><b>Note:</b> Gases selected in the inline form <b>Switch gas</b> are nonetheless activated if LSR_UseGas = FALSE.</p>
LSR_NoProc	<p>Do not use gas when executing the program without laser power.</p> <p>TRUE = Gas is not activated when executing the program without laser power.</p> <p>FALSE = Gas is activated when executing the program without laser power.</p> <p>Default: TRUE</p>
LSR_PropGasValve	<p>Only relevant if process or cutting gases are used, not relevant for root gases and CrossJet.</p> <p>Use proportional gas valve.</p> <p>TRUE = The gas pressure can be defined in the inline form <b>Switch gas</b>.</p> <p>FALSE = The gas pressure cannot be defined in the inline form <b>Switch gas</b>.</p> <p>Default: FALSE</p> <p>The value of this variable also influences which properties can be defined for the gases.</p> <p>(&gt;&gt;&gt; 6.5 "Configuring the inputs/outputs for gases and other properties" Page 24)</p> <p><b>Note:</b> If this variable is modified, the robot controller must be rebooted with a cold start.</p>

Variable	Description
LSR_MIN_STBY	<p>Reduce the standby power.</p> <p>TRUE = The standby power is automatically reduced to 1% of the maximum power. A precondition is that a laser is being used for which the minimum standby power can actually be reduced to 1%.</p> <p>FALSE = The standby power is automatically reduced to 10% of the maximum power.</p> <p>Default: TRUE</p> <p><b>Note:</b> If this variable is TRUE, no ramps can be executed.</p>
LSR_UseRootFlag	<p>Use root gas (precondition: LaserWeld is installed).</p> <p>TRUE = Root gas can be selected in the inline form <b>Initialize gas</b> without the <b>WELD</b> application being selected.</p> <p>The weld operation can then be programmed with LaserTech instructions; LaserWeld instructions are not required in the KRL program.</p> <p>FALSE = Root gas can only be selected in the inline form <b>Initialize gas</b> if the <b>WELD</b> application is selected.</p> <p>Default: FALSE</p> <p><b>Note:</b> If this variable is modified, the robot controller must be rebooted with a cold start.</p>

### 11.1.8 LaserTech: process constants

The specified ranges of values contain the values that will be accepted by the system. They do not, however, constitute a recommendation of which values are useful in practice.



The variables described in this section can be found in the file Laser.dat in the directory R1\TP\LaserTech. To display or change the values, select **Display > Variable > Single** from the main menu.

Variable	Description
LSR_PulsTime	<p>Pulse duration for the reset signal to acknowledge a laser fault.</p> <p>■ <b>0 ... 9,999 s</b></p> <p>Default: <b>0.1 s</b></p>
LSR_Timeout	<p>Maximum wait time for a response from the laser during initialization</p> <p>■ <b>0 ... 9,999 s</b></p> <p>Default: <b>5 s</b></p>
LSR_ShutterDelayConst	<p>Shutter delay of the laser (= delay time for starting the laser switching actions before the taught point).</p> <p>■ <b>-10,000 ms ... +9,999 ms</b></p> <p>The value must be determined empirically.</p> <p>Default: <b>30 ms</b></p>
LSR_ShutterOff	<p>Delay time at end of welding, additional to LSR_ShutterDelayConst</p> <p>This value is added to the laser shutter delay LSR_ShutterDelayConst if the laser is deactivated with the instruction <b>Deactivate process</b>.</p> <p>■ <b>-10,000 ms ... +9,999 ms</b></p> <p>Default: <b>0 ms</b></p>



Variable	Description
LSR_ShutterOn	<p>Delay time at start of welding, additional to LSR_ShutterDelayConst</p> <p>This value is added to the laser shutter delay LSR_ShutterDelayConst if the laser is activated with the instruction <b>Activate process</b>.</p> <ul style="list-style-type: none"> <li>■ <b>-10,000 ms ... +9,999 ms</b></li> </ul> <p>Default: <b>0 ms</b></p>
LSR_TestDelay	<p>Only relevant if the instruction <b>Laser test pulse</b> is used to test the laser power or to determine the focus of the optics.</p> <p>Interval between activating the shielding gas and switching on the laser</p> <ul style="list-style-type: none"> <li>■ <b>0 ... 9,999 ms</b></li> </ul> <p>Default: <b>0 ms</b></p>
LSR_GasScale	<p>Scaling factor for the gas pressure</p> <ul style="list-style-type: none"> <li>■ <b>1 ... 65,535</b></li> </ul> <p>Default: <b>65,535</b></p>
S_Int_Cycl	<p>Submit watchdog pulse duration</p> <p>This variable can be used together with the output S_Int_Flag to monitor whether the submit interpreter is running cyclically. The monitoring only works usefully if the output S_Int_Flag is continuously TRUE. To achieve this, the value of S_Int_Cycl must be a little higher than the cycle time of the SPS.SUB program.</p> <ul style="list-style-type: none"> <li>■ <b>1 ... 9,999 ms</b></li> </ul> <p>Default: <b>0.048 ms</b></p>
LSR_InitGasDly	<p>Delay with which the gas is initialized</p> <ul style="list-style-type: none"> <li>■ <b>-2,000 ms ... +2,000 ms</b></li> </ul> <p>Default: <b>20 ms</b></p>
LSR_GasCheckPressure	<p>Only relevant if a proportional gas valve is used (LSR_PropGasValve = TRUE).</p> <p>Gas pressure used when checking the process or cutting gases during initialization. The range of values depends on the valve used.</p> <p>Default: <b>10 bar</b></p>
LSR_GasDlySwi	<p>Delay on triggering the instruction <b>Switch gas</b>. The gas is activated or deactivated after a delay.</p> <ul style="list-style-type: none"> <li>■ <b>-2,000 ms ... +2,000 ms</b></li> </ul> <p>Default: <b>20 ms</b></p>
LSR_TimeToAvoidGasPress	<p>Wait time for the robot controller in order to eliminate the back-pressure in the gas line. Corresponds to the gas preflow time on switching on the laser when the laser is restarted after a fault.</p> <ul style="list-style-type: none"> <li>■ <b>0 ... 9,999 s</b></li> </ul> <p><b>Note:</b> This wait time is not taken into account in the instruction <b>Laser test pulse</b>.</p>

Variable	Description
LSR_Stop_Inspection Time	Standstill monitoring at active laser If the robot is stationary and the laser power is active, the laser is deactivated after the time defined. ■ 0 ... 9,999 ms Default: 400 ms
PreDelay	Time difference between setting the laser parameters and starting the laser program ■ 0 ... 9,999 ms Default: 0 ms

## 11.2 Configuring LaserWeld

### 11.2.1 LaserWeld: analog inputs/outputs


<b>NOTICE</b>	Incorrect configuration of the internal analog channels can result in the laser working with incorrect parameters. Damage to the system may result.
---------------	---

#### Analog outputs

Outputs 1 to 32 are available.

Output	Description	Default
LSWO_WireFeedHeatChan	Analog channel for the wire heater	8
LSWO_WireFeedChannel	Analog channel for the wirefeeder	9

### 11.2.2 LaserWeld: signal outputs to the wire feed system

	The signals described in this section can be found in the file ...R1\System\\$CONFIG.DAT. To adapt the values, the file must be edited.
---	---

## LASERWELD

### GLOBALS

#### OUTPUTS WIREFEEDER

Signal	Description	Type	\$OUT[]
LSWO_WireFeedForward	Manual wire feed via status key enabled/disabled	BOOL	301
LSWO_WireFeedStart	Wire feed enabled/disabled	BOOL	302
LSWO_WireFeedChannel	Analog channel for the wire feed \$ANOUT[9]	INT	—
LSWO_WireFeedHeatChan	Analog channel for the wire heater \$ANOUT[8]	INT	—
LSWO_WireFeedHeater	Wire heater enabled/disabled	BOOL	304


## LASERWELD

### GLOBALS

#### WIRE CONTROL --> PLC

Signal	Description	Type	\$OUT[]
LSWO_ErrorWireFeeder	Wire feeder error (flag to PLC)	BOOL	315
LSWO_ErrorWireHeat	Wire heater error (flag to PLC)	BOOL	316

### 11.2.3 LaserWeld: signal inputs from the wire feed system

 The signals described in this section can be found in the file ...R1\System\$\CONFIG.DAT. To adapt the values, the file must be edited.

## LASERWELD

### GLOBALS

#### INPUTS WIREFEEDER

Signal	Description	Type	\$IN[]
LSWI_WireFeedHeatControl	Wire heater ready	BOOL	1025
LSWI_WireFeedReady	Wire feeder ready	BOOL	1025

### 11.2.4 LaserWeld: process constants

The specified ranges of values contain the values that will be accepted by the system. They do not, however, constitute a recommendation of which values are useful in practice.

 The variables described in this section can be found in the file Lsw\_Main.dat in the directory R1\TP\LaserWeld. To display or change the values, select **Display > Variable > Single** from the main menu.


Variable	Description
LSW_UseWireFeed	Use wire controller. TRUE = Wire controller is used. FALSE = Wire controller is not used. Default: TRUE
LSW_HotWireOption	Use hot wire controller (optional). TRUE = Option is used. FALSE = Option is not used. Default: FALSE
LSW_UseWFDVelCtrl	Activate/deactivate velocity-dependent wire feed. TRUE = Wire feed rate is dependent on the robot velocity. FALSE = Wire feed rate remains constant (at the value entered in the inline form). <b>Note:</b> If this variable is modified, the robot controller must be rebooted with a cold start.

Variable	Description
LSW_StaticRedWfdOption	<p>Reduced wire feed rate after welding error (optional)</p> <p>TRUE = The wire feed rate is reduced in the case of a start following a weld fault.</p> <p>FALSE = No reduced wire feed rate in the case of a start following a weld fault</p> <p>Default: FALSE</p>
LSW_WfdDistanceMax	<p>Distance for which the reduced wire feed rate applies when the option LSW_StaticRedWfdOption is TRUE</p> <ul style="list-style-type: none"> <li>■ 0 ... 9,999 mm</li> </ul> <p>Default: 5 mm</p>
LSW_ReducedLimitWfdValue	<p>Factor by which the wire feed rate is reduced when the option LSW_StaticRedWfdOption is TRUE. The wire feed rate is increased again when the distance specified in LSW_WfdDistanceMax has been covered.</p> <ul style="list-style-type: none"> <li>■ 0 ... 100 %</li> </ul> <p>Default: 30 %</p>
LSW_WireHeatDelayConst	<p>Switch on wire heater after or before the start of the laser.</p> <ul style="list-style-type: none"> <li>■ -9,999 ... 0.001 mm: Wire heater start delayed.</li> <li>■ 0.001 ... 9,999 mm: Wire heater start brought forward.</li> </ul> <p>Default: 0 mm</p>
LSW_WFD_DELAY	<p>Wire feed trigger delay (set in the option window <b>Media setting: wire</b>).</p> <ul style="list-style-type: none"> <li>■ 0.001 ... 9,999 s</li> </ul> <p>Default: 0 s</p>
LSW_WireFeedMaximum	<p>Maximum value for wire feed, which can be set in the option window <b>Media setting: wire</b></p> <ul style="list-style-type: none"> <li>■ 0 ... 9,999 m/min</li> </ul> <p>Default: 25 m/min</p>
LSW_WireFeedMinimum	<p>Minimum value for wire feed, which can be set in the option window <b>Media setting: wire</b></p> <ul style="list-style-type: none"> <li>■ 0 ... 9,999 m/min</li> </ul> <p>Default: 0 m/min</p>
LSW_WireHeatMaximum	<p>Maximum wire temperature</p> <ul style="list-style-type: none"> <li>■ 0 ... 100 %</li> </ul> <p>Default: 100 %</p>
LSW_WireHeatMinimum	<p>Minimum wire temperature</p> <ul style="list-style-type: none"> <li>■ 0 ... 100 %</li> </ul> <p>Default: 0 %</p>
LSW_WFD_AnalogMinValue	<p>Scaling factor for the minimum wire feed on the analog channel \$ANOUT[9]</p> <ul style="list-style-type: none"> <li>■ 0.0 ... 1.0</li> </ul> <p>Default: 0.0</p>
LSW_WFD_AnalogMaxValue	<p>Scaling factor for the maximum wire feed on the analog channel \$ANOUT[9]</p> <ul style="list-style-type: none"> <li>■ 0.0 ... 1.0</li> </ul> <p>Default: 1.0</p>

Variable	Description
LSW_Heat_AnalogMinValue	Scaling factor for the minimum voltage on the analog channel for the wire heater \$ANOUT[8] <ul style="list-style-type: none"> <li>■ 0.0 ... 1.0</li> </ul> Default: 0.0
LSW_WFD_AnalogMaxValue	Scaling factor for the maximum voltage on the analog channel for the wire heater \$ANOUT[8] <ul style="list-style-type: none"> <li>■ 0.0 ... 1.0</li> </ul> Default: 1.0

## 11.3 Configuring LaserCut

### 11.3.1 LaserCut: analog inputs/outputs

 The numbers for inputs/outputs, interrupts, timers and cyclical flags must only be assigned once in the entire robot controller.

**NOTICE** Incorrect configuration of the internal analog channels can result in the laser working with incorrect parameters. Damage to the system may result.

#### Analog outputs

Outputs 1 to 32 are available.

Output	Description	Default
LSCO_LscDistance	Analog channel for the working distance of the sensor	5
LSCO_LscTipComp	Analog channel for tip compensation of sensor	6
LSCO_LscProgPos	Analog channel for the programmed position of sensor	7

**Timer** Timers 1 to 32 are available.

Timer	Description	Default
LSC_TC_PrecPLC	Timer number for the sensor status keys	19


#### Cycflags

**NOTICE** If the number of cyclical flags is changed, this may result in a double assignment. Furthermore, the numbers of the cyclical flags for the LaserTech monitoring functions may be overwritten. This can cause damage to the system.

Cycflags 1 to 32 are available.

Cycflag	Description	Default
LSR_CF_GasCtrl	Cycflag number for the sensor monitoring	13

### 11.3.2 LaserCut: signal outputs to the sensor

 Detailed information about the distance sensor and distance controller is contained in the PRECITEC documentation.



The signals described in this section can be found in the file ...R1\System\CONFIG.DAT. To adapt the values, the file must be edited.

## LASERCUT GLOBALS

Signal	Description	Type	\$OUT[]
LSCO_SnsrWorkdistance2	Workdistance 2*	BOOL	219
LSCO_SnsrWorkdistance3	Workdistance 3*	BOOL	220
LSCO_SnsrLargeRange	Use extended measuring range.	BOOL	221
LSCO_SnsrEnableManual	Enable/disable manual mode of the sensor.	BOOL	217
LSCO_SnsrAuto	Enable/disable manual mode of the sensor.	BOOL	218
LSCO_SnsrHome	Move sensor to programmed position.	BOOL	222
LSCO_SnsrReference	Execute reference run.	BOOL	999
LSCO_SnsrManualUp	Move sensor up.	BOOL	223
LSCO_SnsrManualDown	Move sensor down.	BOOL	224
LSCO_SnsrSlowMotion	Enable slow motion mode.	BOOL	225
LSCO_SnsrDataWord	Internal word for sensor control. Comprises the entire output range.	Word	201 ... 232
LSCO_LscDistance	Analog channel for the working distance of the sensor \$ANOUT[5]	INT	—
LSCO_LscDistance	Analog channel for tip compensation of the sensor \$ANOUT[6]	INT	—
LSCO_LscProgPos	Analog channel for the programmed position of the sensor \$ANOUT[7]	INT	—

### 11.3.3 LaserCut: signal inputs from the sensor



Detailed information about the distance sensor and distance controller is contained in the PRECITEC documentation.



The signals described in this section can be found in the file ...R1\System\CONFIG.DAT. To adapt the values, the file must be edited.

## LASERCUT GLOBALS

Signal	Description	Type	\$IN[]
LSCI_SnsrOutOfRange	Sensor is outside of the measuring range.	BOOL	213
LSCI_SnsrCollision	Sensor collision detection	BOOL	214
LSCI_SnsrPosReached	Sensor position reached	BOOL	215
LSCI_SnsrNoError	No sensor error	BOOL	216
LSCI_SnsrReady	Sensor is ready.	BOOL	217
LSCI_SnsrRefErr	Sensor reference error	BOOL	443
LSCI_SnsrCableCut	Monitoring of the sensor cable (cable break)	BOOL	1024

### 11.3.4 LaserCut: process constants

The specified ranges of values contain the values that will be accepted by the system. They do not, however, constitute a recommendation of which values are useful in practice.



The variables described in this section can be found in the file Lsc\_Main.dat in the directory R1\TP\LaserCut. To display or change the values, select **Display > Variable > Single** from the main menu.

Variable	Description
LSC_AnaCutDistance	<p>The cutting distance set in the inline form <b>Switch sensor</b> is transferred as an analog value. (Unit: 1/10 mm)</p> <p>TRUE = Cutting distance is transferred as an analog value. FALSE = Cutting distance is transferred via a program number.</p> <p>Default: FALSE</p> <p><b>Note:</b> If this variable is modified, the robot controller must be rebooted with a cold start.</p>
LSC_AnaCutScale	<p>Only relevant if the cutting distance is transferred as an analog value (LSC_AnaCutDistance = TRUE)</p> <p>Scaling of the cutting distance</p> <p>Default: <b>1/655.35</b></p>
LSC_ProgPos	<p>Only relevant if the cutting distance is transferred as an analog value (LSC_AnaCutDistance = TRUE)</p> <p>Programmed position of the sensor (= home position of the sensor). Refers to the zero position of the sensor.</p> <ul style="list-style-type: none"> <li>■ <b>3 ... 9,999</b> Unit: 1/10 mm</li> </ul> <p>Default: <b>60</b></p>
LSC_DefProgPos	<p>Only relevant if the cutting distance is transferred as an analog value (LSC_AnaCutDistance = TRUE)</p> <p>Programmed position of the sensor on start of control</p> <ul style="list-style-type: none"> <li>■ <b>0 ... 300</b> Unit: 1/10 mm</li> </ul> <p>Default: <b>150</b></p>
LSC_MaxProgPos	<p>Only relevant if the cutting distance is transferred as an analog value (LSC_AnaCutDistance = TRUE)</p> <p>Maximum programmed position of the sensor</p> <ul style="list-style-type: none"> <li>■ <b>0 ... 300</b> Unit: 1/10 mm</li> </ul> <p>Default: <b>300</b></p>
LSC_TipComp1	<p>Maximum permissible contact duration during cutting (tip compensation time 1)</p> <ul style="list-style-type: none"> <li>■ <b>1 ... 9,999 ms</b></li> </ul> <p>Default: <b>250 ms</b></p>

Variable	Description
LSC_TipComp2	Maximum permissible contact duration during piercing (tip compensation time 2) <ul style="list-style-type: none"><li>■ 1 ... 9,999 ms</li></ul> Default: <b>250 ms</b>
LSC_GasRinseTime	Gas flow time during gas change after piercing <ul style="list-style-type: none"><li>■ 1 ... 9,999 ms</li></ul> Default: <b>2000 ms</b>



## 12 KUKA Service

### 12.1 Requesting support

**Introduction** This documentation provides information on operation and operator control, and provides assistance with troubleshooting. For further assistance, please contact your local KUKA subsidiary.

**Information** The following information is required for processing a support request:

- Model and serial number of the manipulator
- Model and serial number of the controller
- Model and serial number of the linear unit (if present)
- Model and serial number of the energy supply system (if present)
- Version of the control software
- Optional software or modifications
- Archive of the software
- Application used
- External axes used
- Description of the problem, duration and frequency of the fault

### 12.2 KUKA Customer Support

**Availability** KUKA Customer Support is available in many countries. Please do not hesitate to contact us if you have any questions.

**Argentina** Ruben Costantini S.A. (Agency)  
Luis Angel Huergo 13 20  
Parque Industrial  
2400 San Francisco (CBA)  
Argentina  
Tel. +54 3564 421033  
Fax +54 3564 428877  
ventas@costantini-sa.com

**Australia** Headland Machinery Pty. Ltd.  
Victoria (Head Office & Showroom)  
95 Highbury Road  
Burwood  
Victoria 31 25  
Australia  
Tel. +61 3 9244-3500  
Fax +61 3 9244-3501  
vic@headland.com.au  
www.headland.com.au

<b>Belgium</b>	KUKA Automatisering + Robots N.V. Centrum Zuid 1031 3530 Houthalen Belgium Tel. +32 11 516160 Fax +32 11 526794 info@kuka.be www.kuka.be
<b>Brazil</b>	KUKA Roboter do Brasil Ltda. Travessa Claudio Armando, nº 171 Bloco 5 - Galpões 51/52 Bairro Assunção CEP 09861-7630 São Bernardo do Campo - SP Brazil Tel. +55 11 4942-8299 Fax +55 11 2201-7883 info@kuka-roboter.com.br www.kuka-roboter.com.br
<b>Chile</b>	Robotec S.A. (Agency) Santiago de Chile Chile Tel. +56 2 331-5951 Fax +56 2 331-5952 robotec@robotec.cl www.robotec.cl
<b>China</b>	KUKA Robotics China Co.,Ltd. Songjiang Industrial Zone No. 388 Minshen Road 201612 Shanghai China Tel. +86 21 6787-1888 Fax +86 21 6787-1803 www.kuka-robotics.cn
<b>Germany</b>	KUKA Roboter GmbH Zugspitzstr. 140 86165 Augsburg Germany Tel. +49 821 797-4000 Fax +49 821 797-1616 info@kuka-roboter.de www.kuka-roboter.de

**France** KUKA Automatismes + Robotique SAS  
Techvallée  
6, Avenue du Parc  
91140 Villebon S/Yvette  
France  
Tel. +33 1 6931660-0  
Fax +33 1 6931660-1  
commercial@kuka.fr  
www.kuka.fr

**India** KUKA Robotics India Pvt. Ltd.  
Office Number-7, German Centre,  
Level 12, Building No. - 9B  
DLF Cyber City Phase III  
122 002 Gurgaon  
Haryana  
India  
Tel. +91 124 4635774  
Fax +91 124 4635773  
info@kuka.in  
www.kuka.in

**Italy** KUKA Roboter Italia S.p.A.  
Via Pavia 9/a - int.6  
10098 Rivoli (TO)  
Italy  
Tel. +39 011 959-5013  
Fax +39 011 959-5141  
kuka@kuka.it  
www.kuka.it

**Japan** KUKA Robotics Japan K.K.  
YBP Technical Center  
134 Godo-cho, Hodogaya-ku  
Yokohama, Kanagawa  
240 0005  
Japan  
Tel. +81 45 744 7691  
Fax +81 45 744 7696  
info@kuka.co.jp

**Canada** KUKA Robotics Canada Ltd.  
6710 Maritz Drive - Unit 4  
Mississauga  
L5W 0A1  
Ontario  
Canada  
Tel. +1 905 670-8600  
Fax +1 905 670-8604  
info@kukarobotics.com  
www.kuka-robotics.com/canada

<b>Korea</b>	KUKA Robotics Korea Co. Ltd. RIT Center 306, Gyeonggi Technopark 1271-11 Sa 3-dong, Sangnok-gu Ansan City, Gyeonggi Do 426-901 Korea Tel. +82 31 501-1451 Fax +82 31 501-1461 info@kukakorea.com
<b>Malaysia</b>	KUKA Robot Automation Sdn Bhd South East Asia Regional Office No. 24, Jalan TPP 1/10 Taman Industri Puchong 47100 Puchong Selangor Malaysia Tel. +60 3 8061-0613 or -0614 Fax +60 3 8061-7386 info@kuka.com.my
<b>Mexico</b>	KUKA de México S. de R.L. de C.V. Progreso #8 Col. Centro Industrial Puente de Vigas Tlalnepantla de Baz 54020 Estado de México Mexico Tel. +52 55 5203-8407 Fax +52 55 5203-8148 info@kuka.com.mx www.kuka-robotics.com/mexico
<b>Norway</b>	KUKA Sveiseanlegg + Roboter Sentrumsvegen 5 2867 Hov Norway Tel. +47 61 18 91 30 Fax +47 61 18 62 00 info@kuka.no
<b>Austria</b>	KUKA Roboter Austria GmbH Vertriebsbüro Österreich Regensburger Strasse 9/1 4020 Linz Austria Tel. +43 732 784752 Fax +43 732 793880 office@kuka-roboter.at www.kuka-roboter.at

**Poland** KUKA Roboter Austria GmbH  
Spółka z ograniczoną odpowiedzialnością  
Oddział w Polsce  
Ul. Porcelanowa 10  
40-246 Katowice  
Poland  
Tel. +48 327 30 32 13 or -14  
Fax +48 327 30 32 26  
ServicePL@kuka-roboter.de

**Portugal** KUKA Sistemas de Automatización S.A.  
Rua do Alto da Guerra n° 50  
Armazém 04  
2910 011 Setúbal  
Portugal  
Tel. +351 265 729780  
Fax +351 265 729782  
kuka@mail.telepac.pt

**Russia** OOO KUKA Robotics Rus  
Webnaja ul. 8A  
107143 Moskau  
Russia  
Tel. +7 495 781-31-20  
Fax +7 495 781-31-19  
kuka-robotics.ru

**Sweden** KUKA Svetsanläggningar + Robotar AB  
A. Odhners gata 15  
421 30 Västra Frölunda  
Sweden  
Tel. +46 31 7266-200  
Fax +46 31 7266-201  
info@kuka.se

**Switzerland** KUKA Roboter Schweiz AG  
Industriestr. 9  
5432 Neuenhof  
Switzerland  
Tel. +41 44 74490-90  
Fax +41 44 74490-91  
info@kuka-roboter.ch  
www.kuka-roboter.ch

<b>Spain</b>	KUKA Robots IBÉRICA, S.A. Pol. Industrial Torrent de la Pastera Carrer del Bages s/n 08800 Vilanova i la Geltrú (Barcelona) Spain Tel. +34 93 8142-353 Fax +34 93 8142-950 Comercial@kuka-e.com www.kuka-e.com
<b>South Africa</b>	Jendamark Automation LTD (Agency) 76a York Road North End 6000 Port Elizabeth South Africa Tel. +27 41 391 4700 Fax +27 41 373 3869 www.jendamark.co.za
<b>Taiwan</b>	KUKA Robot Automation Taiwan Co., Ltd. No. 249 Pujong Road Jungli City, Taoyuan County 320 Taiwan, R. O. C. Tel. +886 3 4331988 Fax +886 3 4331948 info@kuka.com.tw www.kuka.com.tw
<b>Thailand</b>	KUKA Robot Automation (M)SdnBhd Thailand Office c/o Maccall System Co. Ltd. 49/9-10 Soi Kingkaew 30 Kingkaew Road Tt. Rachatheva, A. Bangpli Samutprakarn 10540 Thailand Tel. +66 2 7502737 Fax +66 2 6612355 atika@ji-net.com www.kuka-roboter.de
<b>Czech Republic</b>	KUKA Roboter Austria GmbH Organisation Tschechien und Slowakei Sezemická 2757/2 193 00 Praha Horní Počernice Czech Republic Tel. +420 22 62 12 27 2 Fax +420 22 62 12 27 0 support@kuka.cz

**Hungary** KUKA Robotics Hungaria Kft.  
Fö út 140  
2335 Taksony  
Hungary  
Tel. +36 24 501609  
Fax +36 24 477031  
info@kuka-robotics.hu

**USA** KUKA Robotics Corporation  
51870 Shelby Parkway  
Shelby Township  
48315-1787  
Michigan  
USA  
Tel. +1 866 873-5852  
Fax +1 866 329-5852  
info@kukarobotics.com  
www.kukarobotics.com

**UK** KUKA Automation + Robotics  
Hereward Rise  
Halesowen  
B62 8AN  
UK  
Tel. +44 121 585-0800  
Fax +44 121 585-0900  
sales@kuka.co.uk





## Index

### A

Analog inputs/outputs, LaserCut 93  
Analog inputs/outputs, LaserTech 81  
Analog inputs/outputs, LaserWeld 90  
AnoutBypass 86  
Appendix 81  
Arc 58  
Areas of application 9

### C

Communication 9  
Configuration 21  
CrossJet 8, 18, 85, 86  
Cutting pattern, defining 54  
Cyclical flags, LaserCut 93  
Cyclical flags, LaserTech 81

### D

Delay times, defining 28  
Distance sensor, switching 52  
Documentation, industrial robot 7

### E

Example programs 63

### F

Functions 9

### G

Gas postflow time 40, 60  
Gas preflow time 38, 59  
Gas pressure 38, 39, 40, 59, 60, 89  
Gas types, configuring 23  
Gas, initializing 50  
Gas, on/off 50  
Geo motion data 55  
Geometry data 55

### H

Hardware 15

### I

Inline forms 27  
Inputs from the laser 83  
Inputs from the sensor 94  
Inputs from the welding periphery 85  
Installation 15  
Installation, LaserTech 15  
Intended use 10  
Interfaces, for functional expansions 70  
Interrupts, LaserTech 81  
Introduction 7

### K

Knowledge, required 7  
KUKA Customer Support 97

### L

Laser control 45  
Laser cutting 54  
Laser cutting, parameters 61  
Laser focus 36  
Laser functions 29  
Laser power, drop time 43  
Laser power, ramp length 42, 44  
Laser power, rise time 41, 61  
Laser program 8, 22  
Laser test pulse 36  
Laser, activating 29  
Laser, deactivating 47  
Laser, enabling 46  
Laser, initializing 45  
Laser, requesting 47  
LaserCut, analog inputs/outputs 93  
LaserCut, process constants 95  
LaserCut, timer 93  
LaserTech, analog inputs/outputs 81  
LaserTech, cyclical flags 81  
LaserTech, Interrupts 81  
LaserTech, overview 9  
LaserTech, process constants 88  
LaserTech, Timer 81  
LaserWeld, analog inputs/outputs 90  
LaserWeld, process constants 91  
Light path 83, 84, 87  
Line 54  
LSC\_AnaCutDistance 52, 95  
LSC\_AnaCutScale 95  
LSC\_DefProgPos 95  
LSC\_GasRinseTime 96  
LSC\_MaxProgPos 95  
LSC\_ProgPos 95  
LSC\_SecDistance 52  
LSC\_SecInDly 52  
LSC\_TC\_PrecPLC 93  
LSC\_TipComp1 95  
LSC\_TipComp2 96  
LSCI\_SnsrCableCut 94  
LSCI\_SnsrCollision 94  
LSCI\_SnsrNoError 94  
LSCI\_SnsrOutOfRange 94  
LSCI\_SnsrPosReached 94  
LSCI\_SnsrReady 94  
LSCI\_SnsrRefErr 94  
LSCO\_LscDistance 93, 94  
LSCO\_LscProgPos 93, 94  
LSCO\_LscTipComp 93  
LSCO\_SnsrAuto 94  
LSCO\_SnsrDataWord 94  
LSCO\_SnsrEnableManual 94  
LSCO\_SnsrHome 94  
LSCO\_SnsrLargeRange 94  
LSCO\_SnsrManualDown 94  
LSCO\_SnsrManualUp 94  
LSCO\_SnsrReference 94

LSCO\_SnsrSlowMotion 94  
 LSCO\_SnsrWorkdistance2 94  
 LSCO\_SnsrWorkdistance3 94  
 LSR\_AnoutCheck 81  
 LSR\_CF\_AnoutCheck 82  
 LSR\_CF\_GasCtrl 82, 93  
 LSR\_CF\_LaserCtrl 82  
 LSR\_CF\_MediaCtrl 82  
 LSR\_CF\_STEP 82  
 LSR\_CF\_STEPCTRL 82  
 LSR\_CF\_UsrTech 82  
 LSR\_CrossJetOption 86  
 LSR\_GasCheckPressure 89  
 LSR\_GasDlySwi 89  
 LSR\_GasScale 89  
 LSR\_InitGasDly 89  
 LSR\_InterrAntiCollission 81  
 LSR\_InterruptDistSensor 81  
 LSR\_InterruptLaserSafety 81  
 LSR\_InterruptMedias 81  
 LSR\_InterruptStepMon 81  
 LSR\_InterruptUsrTech 81  
 LSR\_LsrFiberMirrorOption 87  
 LSR\_MIN\_STBY 88  
 LSR\_MPI\_Interface 86  
 LSR\_NoProc 87  
 LSR\_PropGasValve 24, 25, 87  
 LSR\_PulsTime 88  
 LSR\_ShutterDelayConst 28, 88  
 LSR\_ShutterOff 28, 88  
 LSR\_ShutterOn 28, 89  
 LSR\_Stop\_InspectionTime 27, 90  
 LSR\_TC\_Check 82  
 LSR\_TC\_PostGas 81  
 LSR\_TC\_PreFlowGas 81  
 LSR\_TC\_STEP 82  
 LSR\_TestDelay 89  
 LSR\_Timeout 88  
 LSR\_TimeToAvoidGasPress 89  
 LSR\_UseGas 87  
 LSR\_UsePwrVelCtrlId 9, 41, 60, 87  
 LSR\_UserErrorFLAG 86  
 LSR\_UseRootFlag 88  
 LsrCutCircle 55  
 LsrCutHex 55  
 LsrCutRect 55  
 LsrCutSlot 55  
 LSRI\_AntiCollissionDev 85  
 LSRI\_CrossJet 85  
 LSRI\_GasPressure 25, 81, 85  
 LSRI\_LsrActive 84  
 LSRI\_LsrAssigned 84  
 LSRI\_LsrExternEnabled 84  
 LSRI\_LsrFailure 84  
 LSRI\_LsrFiberNo 84  
 LSRI\_LsrFiberSafetyCode 84  
 LSRI\_LsrInternFault 84  
 LSRI\_LsrPilotOn 84  
 LSRI\_LsrProgAbort 84  
 LSRI\_LsrProgActive 84  
 LSRI\_LsrProgEnd 84  
 LSRI\_LsrSet1 84  
 LSRI\_LsrSet2 84  
 LSRI\_LsrSet3 84  
 LSRI\_LsrShutterClosed 84  
 LSRI\_LsrStandby 84  
 LSRI\_LsrWarnLampOn 84  
 LSRI\_UsrInput1 85  
 LSRI\_UsrInput2 85  
 LSRO\_AntiCollissionDev 84  
 LSRO\_ColdApplication 85  
 LSRO\_ColdFor1Seam 84  
 LSRO\_ColdFor1Section 84  
 LSRO\_ColdForEver 85  
 LSRO\_CrossJet 85  
 LSRO\_Error\_Bypass 86  
 LSRO\_Error\_Cell 84  
 LSRO\_Error\_Media 84  
 LSRO\_Error\_Sensor 84  
 LSRO\_GasEnable 85  
 LSRO\_GasPressure 81, 85  
 LSRO\_LsrDataWord0 83  
 LSRO\_LsrDataWord3 83  
 LSRO\_LsrDataWord4 83  
 LSRO\_LsrExternControl 83  
 LSRO\_LsrFaultExtern 82  
 LSRO\_LsrFiber 83  
 LSRO\_LsrLaserNr 83  
 LSRO\_LsrOn 83  
 LSRO\_LsrOperationOff 83  
 LSRO\_LsrPilotOn 82  
 LSRO\_LsrPrgNrBCD1 83  
 LSRO\_LsrPrgNrBCD10 83  
 LSRO\_LsrPrgSetDual 83  
 LSRO\_LsrPwr 81, 83  
 LSRO\_LsrRampTime 83  
 LSRO\_LsrRequest 47, 82  
 LSRO\_LsrReset 82  
 LSRO\_LsrRmpDownEndVal 83  
 LSRO\_LsrRmpDownStartVal 83  
 LSRO\_LsrRmpUpEndVal 83  
 LSRO\_LsrRmpUpStartVal 83  
 LSRO\_LsrRobotNr 83  
 LSRO\_LsrStandby 83  
 LSRO\_LsrStartDynamic 82  
 LSRO\_LsrStartStatic 82  
 LSRO\_LsrStopProgram 82  
 LSRO\_LsrSync1 82  
 LSRO\_LsrSync2 82  
 LSW\_Heat\_AnalogMinValue 93  
 LSW\_HotWireOption 91  
 LSW\_ReducedLimitWfdValue 92  
 LSW\_StaticRedWfdOption 92  
 LSW\_UseWFDVelCtrlId 91  
 LSW\_UseWireFeed 91  
 LSW\_WFD\_AnalogMaxValue 92, 93  
 LSW\_WFD\_AnalogMinValue 92  
 LSW\_WFD\_DELAY 92  
 LSW\_WfdDistanceMax 92  
 LSW\_WireFeedMaximum 92  
 LSW\_WireFeedMinimum 92  
 LSW\_WireHeatDelayConst 92

LSW\_WireHeatMaximum 92  
LSW\_WireHeatMinimum 92  
LSWI\_WireFeedHeatControl 91  
LSWI\_WireFeedReady 91  
LSWO\_ErrorWireFeeder 91  
LSWO\_ErrorWireHeat 91  
LSWO\_WireFeedChannel 90  
LSWO\_WireFeedForward 90  
LSWO\_WireFeedHeatChan 90  
LSWO\_WireFeedHeater 90  
LSWO\_WireFeedStart 90

## M

Media control 50  
Menus 17  
Messages 75  
Minimum wire feed rate 38, 39

## O

Operation 17  
Outputs to the laser 82  
Outputs to the sensor 93  
Outputs to the welding periphery 84  
Outputs to the wire feed system 90

## P

Pilot laser 82, 84  
Pilot laser, configuration 25  
Power ramps 27  
PreDelay 90  
Process constants, LaserCut 95  
Process constants, LaserTech 88  
Process constants, LaserWeld 91  
Process gas 8  
Process options 86  
Process, deactivating 33  
Process, switching 31  
Product description 9  
Programming tips 27  
Programming, inline forms 27  
Programming, system integrators 67  
Programming, User 27  
Proportional gas valve 24, 87

## R

Ramp time, modification 26  
Root gas 8

## S

S\_Int\_Cycl 89  
S\_Int\_Flag 86  
Safety 13  
Safety instructions 7  
Sensor control 52  
Sensor, settings 53  
Service, KUKA Roboter 97  
Single (menu item) 67  
Software 15  
Spline 27, 54  
Standstill monitoring 78  
Start-up 21

Status keys 17, 18  
Step seams 35  
Support request 97  
Switching points 28  
System flags 85  
System outputs 85  
System requirements 15

## T

Target group 7  
Terms used 8  
Timer, LaserCut 93  
Timer, LaserTech 81  
Trademarks 8  
Training 7

## U

Uninstallation, LaserTech 16  
Update, LaserTech 15  
Use, intended 10

## W

Warnings 7  
Watchdog, output 86  
Wire, cutting 51  
Wirefeed 38, 39  
Wirefeed delay 38, 39, 40



