


KUKA.PLC Multiprog 5-35 4.1

For KUKA System Software 8.2 and 8.3



Issued: 08.11.2012

Version: KST PLC Multiprog 4.1 V2 en (PDF)

© Copyright 2012

KUKA Roboter GmbH
Zugspitzstraße 140
D-86165 Augsburg
Germany

This documentation or excerpts therefrom may not be reproduced or disclosed to third parties without the express permission of KUKA Roboter GmbH.

Other functions not described in this documentation may be operable in the controller. The user has no claims to these functions, however, in the case of a replacement or service work.

We have checked the content of this documentation for conformity with the hardware and software described. Nevertheless, discrepancies cannot be precluded, for which reason we are not able to guarantee total conformity. The information in this documentation is checked on a regular basis, however, and necessary corrections will be incorporated in the subsequent edition.

Subject to technical alterations without an effect on the function.

Translation of the original documentation

KIM-PS5-DOC

| | |
|----------------|------------------------------------|
| Publication: | Pub KST PLC Multiprog 4.1 (PDF) en |
| Bookstructure: | KST PLC Multiprog 4.1 V2.1 |
| Version: | KST PLC Multiprog 4.1 V2 en (PDF) |

Contents

| | | |
|----------|--|-----------|
| 1 | Introduction | 5 |
| 1.1 | Target group | 5 |
| 1.2 | Industrial robot documentation | 5 |
| 1.3 | Representation of warnings and notes | 5 |
| 1.4 | Trademarks | 6 |
| 1.5 | Terms used | 6 |
| 2 | Product description | 9 |
| 2.1 | Overview of KUKA.PLC Multiprog 5-35 | 9 |
| 3 | Safety | 11 |
| 3.1 | Safety measures for “single point of control” | 11 |
| 4 | Installation | 15 |
| 4.1 | System requirements | 15 |
| 4.2 | Installing KUKA.PLC Multiprog 5-35 | 15 |
| 4.3 | Uninstalling KUKA.PLC Multiprog 5-35 | 15 |
| 5 | Operation | 17 |
| 6 | Configuration | 19 |
| 6.1 | Overview | 19 |
| 6.2 | Opening a Multiprog project in WorkVisual | 19 |
| 6.3 | Importing a Multiprog project into WorkVisual | 20 |
| 6.4 | Mapping Multiprog variables | 20 |
| 7 | Programming | 23 |
| 8 | Libraries | 25 |
| 8.1 | ExtensionLibV8 library | 25 |
| 8.1.1 | Accessing robot controller signals | 25 |
| 8.1.1.1 | Reading KR C signals | 25 |
| 8.1.1.2 | Writing KR C signals | 26 |
| 8.1.2 | Saving retentive data using a program | 26 |
| 8.1.3 | Provide CPU computing time | 27 |
| 8.2 | KrcLibV8 library | 27 |
| 8.2.1 | Stopping the robot | 27 |
| 8.2.2 | Canceling the robot stop | 28 |
| 8.2.3 | Reading the current actual position values of axes A1 to A12 | 28 |
| 8.2.4 | Reading the current position of the base origin | 29 |
| 8.2.5 | Reading the current override value of the robot controller | 30 |
| 8.2.6 | Setting the current override value of the robot controller | 30 |
| 8.2.7 | Reading the current actual values of the robot position | 31 |
| 8.2.8 | Reading robot controller variables (Integer-type) | 31 |
| 8.2.9 | Writing to robot controller variables (Integer-type) | 32 |
| 8.2.10 | Reading robot controller variables (REAL-type) | 32 |
| 8.2.11 | Writing to robot controller variables (REAL-type) | 32 |
| 8.2.12 | Reading the current position of the tool origin | 33 |
| 8.2.13 | Reading the current operating mode | 33 |

| | | |
|-----------|---|-----------|
| 8.2.14 | Reading the current state of the submit and robot interpreters | 34 |
| 8.2.15 | Reading the interpolation mode of the robot | 34 |
| 8.2.16 | Displaying notification messages | 35 |
| 8.2.17 | Displaying status messages | 35 |
| 8.2.18 | Clearing a status message | 36 |
| 8.2.19 | Clearing all status messages | 36 |
| 8.2.20 | Converting the message number of the ISG core into plain text and displaying it | 37 |
| 8.2.21 | Displaying/clearing status messages (simplified) | 37 |
| 8.2.22 | Reading the current state of the drives | 38 |
| 8.2.23 | Reading the current state of the robot brakes | 38 |
| 8.2.24 | Displaying/clearing messages | 39 |
| 8.3 | KrcExVarLib library | 42 |
| 8.3.1 | Reading a value from an array | 42 |
| 8.3.2 | Writing a value to an array | 42 |
| 8.3.3 | Reading multiple values from an array | 43 |
| 8.3.4 | Writing multiple values to an array | 44 |
| 8.4 | AutoExtLib library | 44 |
| 8.4.1 | Operating the Automatic External interface (KR C) | 45 |
| 8.4.2 | Operating the Automatic External interface (VKR C) | 47 |
| 9 | Diagnosis | 49 |
| 9.1 | Global variables | 49 |
| 10 | KUKA Service | 51 |
| 10.1 | Requesting support | 51 |
| 10.2 | KUKA Customer Support | 51 |
| | Index | 59 |

1 Introduction

1.1 Target group

This documentation is aimed at users with the following knowledge and skills:

- Advanced KRL programming skills
- Advanced PLC programming skills
- Advanced knowledge of the robot controller system



For optimal use of our products, we recommend that our customers take part in a course of training at KUKA College. Information about the training program can be found at www.kuka.com or can be obtained directly from our subsidiaries.

1.2 Industrial robot documentation

The industrial robot documentation consists of the following parts:

- Documentation for the manipulator
- Documentation for the robot controller
- Operating and programming instructions for the KUKA System Software
- Documentation relating to options and accessories
- Parts catalog on storage medium

Each of these sets of instructions is a separate document.

1.3 Representation of warnings and notes

Safety

These warnings are relevant to safety and **must** be observed.



These warnings mean that it is certain or highly probable that death or severe injuries **will** occur, if no precautions are taken.



These warnings mean that death or severe injuries **may** occur, if no precautions are taken.



These warnings mean that minor injuries **may** occur, if no precautions are taken.



These warnings mean that damage to property **may** occur, if no precautions are taken.



These warnings contain references to safety-relevant information or general safety measures.
These warnings do not refer to individual hazards or individual precautionary measures.

This warning draws attention to procedures which serve to prevent or remedy emergencies or malfunctions:



Procedures marked with this warning **must** be followed exactly.

Notes

These hints serve to make your work easier or contain references to further information.



Tip to make your work easier or reference to further information.

1.4 Trademarks

ProConOS and **MULTIPROG** are trademarks of KW-Software GmbH.

VxWorks is a trademark of Wind River Systems Inc.

Windows and **Windows XP** are trademarks of Microsoft Corporation.

1.5 Terms used

| Term | Description |
|-------------------------|--|
| Exception | Exceptional treatment for a specific event. |
| KLI | KUKA Line Interface: Connection to Ethernet network |
| KUKA.PLC Multiprog 5-35 | Soft PLC for use in the robot controller. |
| ProConOS | Software that serves as a runtime system to execute PLC applications. |
| WorkVisual | Software that serves as an offline engineering system for the software of KR C4-controlled robot systems. |
| SPOC | Single Point of Control |
| Retentive data | Data that are retained even when the PLC is reset. |
| Time slice | Allocated time slot in which an application takes over the CPU processing time. |
| Watchdog | Function that monitors the max. allocated processing/response time. |
| Notification message | A message that is for information purposes only and does not interrupt program execution. It does not require acknowledgement. A notification message may contain general information, for example, or confirm an operator action. A notification message can only be deleted using the buttons OK and Confirm all . |

| Term | Description |
|----------------|--|
| Status message | A message that signals a status. It is generally for information purposes only, but may also interrupt program execution. The message is automatically deleted when the status that triggered it is no longer applicable. A status message cannot be deleted by the user via the smartHMI. |
| PDD | Process Data Directory Mechanism for exchanging process data |

2 Product description

2.1 Overview of KUKA.PLC Multiprog 5-35

- Description** KUKA.PLC Multiprog 5-35 is a technology package with the following functions:
- It extends the range of possible solutions for automation tasks already provided by KRL (KUKA Robot Language). KUKA.PLC Multiprog 5-35 thus represents an expanded development environment for PLC applications.
 - KUKA.PLC Multiprog 5-35 is installed on a standard laptop/PC. In this case, the laptop/PC can be used as a development environment for PLC applications, which can subsequently be executed on the robot controller.
- Required components**
- **ProConOS runtime system:** KUKA.PLC Multiprog 5-35 uses the ProConOS runtime system to execute PLC applications. ProConOS must be installed on the robot controller and requires the real-time operating system VxWorks. ProConOS is compatible with the IEC standard 61131-3, and thus employs standardized syntax and semantics. ProConOS can be configured by means of an initialization file, and can be adapted flexibly to the requirements of the robot system.




Fig. 2-1: Configuration overview

| Item | Description |
|------|--|
| 1 | KR C4: <ul style="list-style-type: none"> ■ Windows operating system ■ VxWorks real-time operating system ■ ProConOS runtime system |
| 2 | Connection: KLI |
| 3 | External PC/laptop: <ul style="list-style-type: none"> ■ Windows operating system ■ MULTIPROG PLC development environment ■ WorkVisual offline engineering system |

3 Safety

This documentation contains safety instructions which refer specifically to the software described here.

The fundamental safety information for the industrial robot can be found in the “Safety” chapter of the Operating and Programming Instructions for System Integrators or the Operating and Programming Instructions for End Users.



The “Safety” chapter in the operating and programming instructions must be observed. Death to persons, severe injuries or considerable damage to property may otherwise result.



WARNING Signal states can be changed by downloading the Multi-prog project, via the control dialog in Multiprog or by transferring them out of WorkVisual. It must be ensured that potentially hazardous signals (e.g. the opening/closing of a gun) can only be executed if AUT or AUT EXT mode is set and the safety gate is closed. For this, the signals must be mapped accordingly by means of the variable **bSPOC_UserSafetyActive**.

The variable **bSPOC_UserSafetyActive** corresponds to the negation of the variable **\$USER_SAF**.

The following table describes which state the variable **bSPOC_UserSafetyActive** assumes with regard to operator safety, enabling switch and the set operating mode (AUT, EXT, T1, T2, KRF).

| Operator safety | Enabling switch | AUT / EXT | T1 / KRF | T2 |
|-----------------|-----------------|-----------|----------|-------|
| inactive | not pressed | TRUE | TRUE | TRUE |
| | pressed | TRUE | FALSE | FALSE |
| active | not pressed | FALSE | TRUE | TRUE |
| | pressed | FALSE | FALSE | FALSE |



If the variable **bSPOC_UserSafetyActive** has the TRUE state, the safety measures for “single point of control” must be taken into account.



If operator safety is implemented in the form of a safety gate, then inactive operator safety means an open safety gate and active operator safety a closed safety gate.

3.1 Safety measures for “single point of control”

Overview

If certain components in the industrial robot are operated, safety measures must be taken to ensure complete implementation of the principle of “single point of control” (SPOC).

Components:

- Submit interpreter
- PLC
- OPC Server
- Remote control tools
- Tools for configuration of bus systems with online functionality
- KUKA.RobotSensorInterface
- External keyboard/mouse



The implementation of additional safety measures may be required. This must be clarified for each specific application; this is the responsibility of the system integrator, programmer or user of the system.

Since only the system integrator knows the safe states of actuators in the periphery of the robot controller, it is his task to set these actuators to a safe state, e.g. in the event of an EMERGENCY STOP.

T1, T2

In the test modes, the components referred to above (with the exception of the external keyboard/mouse) may only access the industrial robot if the following signal has the following state:

| Signal | State required for SPOC |
|------------------------|-------------------------|
| bSPOC_UserSafetyActive | FALSE |

Submit interpreter, PLC

If motions, (e.g. drives or grippers) are controlled with the submit interpreter or the PLC via the I/O system, and if they are not safeguarded by other means, then this control will take effect even in T1 and T2 modes or while an EMERGENCY STOP is active.

If variables that affect the robot motion (e.g. override) are modified with the submit interpreter or the PLC, this takes effect even in T1 and T2 modes or while an EMERGENCY STOP is active.

Safety measures:

- In the test modes, the system variable \$OV_PRO must not be written to by the submit interpreter or the PLC.
- Do not modify safety-relevant signals and variables (e.g. operating mode, EMERGENCY STOP, safety gate contact) via the submit interpreter or PLC.

If modifications are nonetheless required, all safety-relevant signals and variables must be linked in such a way that they cannot be set to a dangerous state by the submit interpreter or PLC.

OPC server, remote control tools

These components can be used with write access to modify programs, outputs or other parameters of the robot controller, without this being noticed by any persons located inside the system.

Safety measures:

- KUKA stipulates that these components are to be used exclusively for diagnosis and visualization.
Programs, outputs or other parameters of the robot controller must not be modified using these components.
- If these components are used, outputs that could cause a hazard must be determined in a risk assessment. These outputs must be designed in such a way that they cannot be set without being enabled. This can be done using an external enabling device, for example.

Tools for configuration of bus systems

If these components have an online functionality, they can be used with write access to modify programs, outputs or other parameters of the robot controller, without this being noticed by any persons located inside the system.

- WorkVisual from KUKA
- Tools from other manufacturers

Safety measures:

- In the test modes, programs, outputs or other parameters of the robot controller must not be modified using these components.

**External
keyboard/mouse**

These components can be used to modify programs, outputs or other parameters of the robot controller, without this being noticed by any persons located inside the system.

Safety measures:


- Only use one operator console at each robot controller.
- If the KCP is being used for work inside the system, remove any keyboard and mouse from the robot controller beforehand.

4 Installation

4.1 System requirements

Overview


- Standard laptop/PC
 - WorkVisual 2.4 or higher
The requirements for installation of WorkVisual are contained in the WorkVisual documentation.
- Network connections (network switch, network cable, 100 Mbit network card)


 Information about the supported Windows versions can be found in the Multiprog online help.

4.2 Installing KUKA.PLC Multiprog 5-35

Precondition


- Local administrator rights
- Software on CD/DVD or USB stick

 It is advisable to archive all relevant data before updating a software package.


 If an older version of KUKA.PLC Multiprog is installed, this must be uninstalled prior to installation of KUKA.PLC Multiprog 5-35.

Procedure

1. Place the CD/DVD in the CD/DVD drive or plug the USB stick into the laptop/PC.
2. Select the drive in Windows Explorer.
3. Start the program Setup.exe in the directory 00193181;xx; KUKA.PLC Multiprog 5-35 4.1; V__41KPM_xxxx. KUKA.PLC Multiprog 5-35 is installed.
4. Remove CD/DVD from the drive or unplug USB stick.

 Further information is contained in the relevant manufacturer documentation.

4.3 Uninstalling KUKA.PLC Multiprog 5-35

 It is advisable to archive all relevant data before updating or uninstalling a software package.


Precondition

- Local administrator rights

Procedure

1. In the Windows Start menu, select **Settings > Control Panel > Software**, and delete the entry **MULTIPROG 5.35 [...]**.
2. Reply to the request for confirmation with **Yes**. KUKA.PLC Multiprog 5-35 is uninstalled.


5 Operation


 Information about operating Multiprog can be found in the Multiprog online help.

6 Configuration

6.1 Overview

| Step | Description |
|------|--|
| 1 | <ul style="list-style-type: none"> ■ Open Multiprog project in WorkVisual. (>>> 6.2 "Opening a Multiprog project in WorkVisual" Page 19) or ■ Import Multiprog project into WorkVisual. (>>> 6.3 "Importing a Multiprog project into WorkVisual" Page 20) |
| 2 | Map Multiprog variables. (>>> 6.4 "Mapping Multiprog variables" Page 20) |


 Additional information about procedures in WorkVisual is contained in the WorkVisual documentation.

 Multiprog variables can be generated, edited and deleted in Multiprog. Further information about this can be found in the Multiprog on-line help.


6.2 Opening a Multiprog project in WorkVisual

- Precondition**
- Multiprog is not open.
 - A project is open in WorkVisual.
 - The robot controller is added.

- Procedure**
1. Right-click on the robot controller on the **Hardware** tab in the **Project structure** window and select **Add...** in the context menu.
 2. A window opens. Select the element **PROCONOS 4-1** and confirm with **Add**.
The element **PROCONOS 4-1** is added to the tree structure of the robot controller beneath the **Options** folder.
 3. Set the robot controller as the active controller.
 4. Select the menu sequence **Editors > Option packages > PLC editor**.
 5. Only if the PLC editor is being started for the first time: a selection window containing templates opens. Select the desired template and confirm with **OK**.

 Further information about the templates can be found in the documentation "Compatibility of Multiprog/ProConOS". This documentation can be found on the ProConOS CD.


Multiprog is opened and a connection to WorkVisual is established. In WorkVisual, the information from the Multiprog project is displayed in the **PLC** tab in the **I/O Mapping** window.

 Multiprog can be closed again via the menu sequence **Editors > Option packages > PLC editor**.

6.3 Importing a Multiprog project into WorkVisual

- Precondition**
- A project is open in WorkVisual.
 - The robot controller is added.


- Procedure**
1. Select the menu sequence **File > Import / Export**.
The **Import/Export Wizard** window is opened.
 2. Select **Import Multiprog project** and click on **Next >**.
 3. Click on **Browse...** and specify a directory.
 4. Select the file to be imported and confirm with **Open**.
 5. Select the robot controller into which the project is to be imported.

 Only robot controllers that have not been set as the active controller can be selected.

6. Click on **Finish**.
The project is imported.

6.4 Mapping Multiprog variables

Description Multiprog variables can be mapped to KRC variables and field bus signals.

 Before mapping is carried out, variables in Multiprog are input and output variables. Only when it is mapped is a variable defined as either an input variable or an output variable.

Variables with the following data types can be mapped to one another:

| IEC data type | KRC data type | Remark |
|---------------|-------------------------|---|
| DINT | INT/ENUM | |
| BOOL | BOOL | |
| REAL | REAL | |
| BYTE | CHAR | |
| STRING | CHAR[] | The array limits are checked during reading or writing. In case of doubt, the maximum permissible length is read/written and any remaining characters are simply cut off. |
| DINT array | INT array or ENUM array | The number of elements must match exactly. |
| REAL array | REAL array | The number of elements must match exactly. |
| BOOL array | BOOL array | |
| KRL_FRAME | FRAME | KRL_Frame is a newly introduced data type in Multiprog, in the folder "Data types". |
| KRL_POS | POS | KRL_POS is a newly introduced data type in Multiprog, in the folder "Data types". |
| KRL_E3POS | E3POS | KRL_E3POS is a newly introduced data type in Multiprog, in the folder "Data types". |
| KRL_E6POS | E6POS | KRL_E6POS is a newly introduced data type in Multiprog, in the folder "Data types". |

| IEC data type | KRC data type | Remark |
|---------------|---------------|--|
| AXIS | AXIS | AXIS is an existing data type in Multiprog. |
| KRL_E3AXIS | E3AXIS | KRL_E3AXIS is a newly introduced data type in Multiprog, in the folder "Data types". |
| KRL_E6AXIS | E6AXIS | KRL_E6AXIS is a newly introduced data type in Multiprog, in the folder "Data types". |



By splitting KRC variables, it is possible to map sub-elements of arrays and structures.

Precondition

- The Multiprog project has been opened in WorkVisual or imported.

Procedure

1. Select the element **Global_Variables** on the **PLC** tab in the right-hand half of the **I/O Mapping** window.
The variables are displayed in the bottom area of the **I/O Mapping** window.
2. Select the variables/signals to be mapped and click on the **Connect** button.
The variables/signals are now mapped.
3. In the case of KRC variables, the direction of the mapping can be changed:
 - a. Right-click on the mapped variables.
 - b. Select **Change mapping direction**.


7 Programming



Information about programming Multiprog can be found in the Multiprog online help.

8 Libraries

8.1 ExtensionLibV8 library


 The file functions in the ExtensionLibV8 library available in earlier versions of Multiprog have been replaced with the file functions from the ProConOS library. Further information about the ProConOS library can be found in the Multiprog online help.


8.1.1 Accessing robot controller signals

Description The function blocks KrcSignalRead and KrcSignalWrite allow the inputs and outputs of the robot controller to be accessed symbolically. This enables I/O assignment without a PLC project and without Multiprog. The assignment between the symbol and the I/O address is made by means of a robot controller signal declaration.

8.1.1.1 Reading KR C signals

Description The function block KrcSignalRead allows KR C signals to be read symbolically.

 It is not possible to read inputs and outputs of the KR C that are mapped to an I/O driver.

 The function block can only be used in conjunction with communication I/Os or globally defined signal variables. The signals must not be mapped to a field bus signal.




Fig. 8-1: KrcSignalRead function block symbol

| Parameter | Data type | Description |
|------------|-----------|---|
| SignalName | STRING | Name of the signal that is to be read Note: The name must be written in upper-case characters both on the robot controller and in the Multiprog project; otherwise it will not be recognized. |
| Value | ANY | Read value. Although the parameter appears as an input, the read value is written to the linked variable. |
| Error | INT | Error codes: see the error code table |


| Error code | Description |
|------------|--|
| 0 | Successful |
| -2 | Signal not found |
| -3 | Incorrect signal type |
| -4 | Unsupported representation width of the signal |


| Error code | Description |
|------------|--|
| -5 | Internal initialization error |
| -6 | Buffer too small |
| -10 | Signal not in I/O range of the KR C |
| -12 | System I/O. Output assigned to the robot controller. |
| -13 | Input/output is mapped to a field bus in the KRC |

8.1.1.2 Writing KR C signals

Description

The function block KrcSignalWrite allows KR C signals to be written symbolically.

 It is not possible to write to inputs and outputs of the KR C that are mapped to an I/O driver.

 The function block can only be used in conjunction with communication I/Os or globally defined signal variables. The signals must not be mapped to a field bus signal.




Fig. 8-2: KrcSignalWrite function block symbol

| Parameter | Data type | Description |
|------------|-----------|--|
| SignalName | STRING | Name of the signal that is to be written Note: The name must be written in upper-case characters both on the robot controller and in the Multiprog project; otherwise the name will not be recognized. |
| Value | ANY | Value to be written |
| Error | INT | Error codes: see the error code table |

| Error code | Description |
|------------|--|
| 0 | Successful |
| -2 | Signal not found |
| -3 | Signal mapped to I/O driver in the KR C |
| -4 | Unsupported representation width of the signal |
| -5 | Internal initialization error |
| -6 | Not a SPOC-safe state |
| -10 | Signal not in I/O range of the KR C |
| -12 | System I/O. Output assigned to the robot controller. |
| -13 | Input/output is mapped to a field bus in the KRC |

8.1.2 Saving retentive data using a program

Description

The function block SaveRetain can be used to save retentive data via PLC programs.

i Due to the time required for saving data (several hundred ms), this function block should be executed in the SPG2 stop task, or in a task which is not monitored by the watchdog.




Fig. 8-3: SaveRetain function block symbol

| Parameter | Data type | I/O | Description |
|-----------|-----------|-----|---|
| Enable | BOOL | IN | A rising edge at this input activates the functionality of the function module. |
| Success | BOOL | OUT | FALSE: An error occurred when saving the retentive data. TRUE: The retentive data were saved successfully. |

8.1.3 Provide CPU computing time

Description The function block PlcSleep can be used to provide CPU computing time to lower-priority tasks of the lower-level operating system.

NOTICE This function can adversely affect the real-time behavior of the robot system and result in damage to the robot. The parameter may only be used in consultation with KUKA Roboter GmbH.




Fig. 8-4: PlcSleep function block symbol

| Parameter | Data type | I/O | Description |
|-----------|-----------|-----|---|
| SleepTime | INT | IN | CPU computing time (in ms) which is to be provided. |

8.2 KrcLibV8 library

Description This library carries out read and write access to robot data. During installation, the library is inserted as a project library in Multiprog.

8.2.1 Stopping the robot

Description The function block RobStop can be used to stop the robot in one of 2 ways: path-maintaining braking or ramp stop.




Fig. 8-5: RobStop function block symbol

| Parameter | Data type | I/O | Description |
|-----------|-----------|-----|---|
| Value | SINT | IN | 1: Ramp stop |
| | | | 2: Path-maintaining braking |
| Enable | BOOL | IN | Trigger for execution of the stop (rising edge) |
| Status | SINT | OUT | 0: Execution successful |
| | | | -1: Execution failed |

8.2.2 Canceling the robot stop

Description

The function block RobStopRel can be used to reset the messages that stopped the robot with the function block RobStop.




Fig. 8-6: RobStopRel function block symbol

| Parameter | Data type | I/O | Description |
|-----------|-----------|-----|--|
| Enable | BOOL | IN | Trigger for resetting the messages (rising edge) |

8.2.3 Reading the current actual position values of axes A1 to A12

Description

The function block ReadAxisAct_Md can be used to read by means of the variable \$**AXIS_ACT** the current actual robot position values of axes A1 to A12.




Fig. 8-7: Function block system ReadAxisAct_Md

| Parameter | Data type | I/O | Element | Description |
|-----------|-----------|-----|----------------|---|
| Mode | BYTE | IN | Mode 0x01 | RdAXIS_ACT_MES() |
| | | | Mode 0x02 | RdAXIS_ACT() |
| | | | Mode 0x03 | RdAXIS_ACT_FLT_KRL_Units() |
| | | | Mode 0x04 | RdAXIS_ACT_FLT() |
| | | | Mode 0x11 | RdAXIS_ACT_MES() [Modulo-Calc.] |
| | | | Mode 0x12 | RdAXIS_ACT() [Modulo-Calc.] |
| | | | Mode 0x13 | RdAXIS_ACT_FLT_KRL_Units() [Modulo-Calc.] |
| | | | Mode 0x14 | RdAXIS_ACT_FLT() [Modulo-Calc.] |
| A1 | REAL | OUT | \$AXIS_ACT.A1 | Angle A1 |
| A2 | REAL | OUT | \$AXIS_ACT.A2 | Angle A2 |
| A3 | REAL | OUT | \$AXIS_ACT.A3 | Angle A3 |
| A4 | REAL | OUT | \$AXIS_ACT.A4 | Angle A4 |
| A5 | REAL | OUT | \$AXIS_ACT.A5 | Angle A5 |
| A6 | REAL | OUT | \$AXIS_ACT.A6 | Angle A6 |
| A7 | REAL | OUT | \$AXIS_ACT.A7 | Angle A7 |
| A8 | REAL | OUT | \$AXIS_ACT.A8 | Angle A8 |
| A9 | REAL | OUT | \$AXIS_ACT.A9 | Angle A9 |
| A10 | REAL | OUT | \$AXIS_ACT.A10 | Angle A10 |
| A11 | REAL | OUT | \$AXIS_ACT.A11 | Angle A11 |
| A12 | REAL | OUT | \$AXIS_ACT.A12 | Angle A12 |

8.2.4 Reading the current position of the base origin

Description The function block ReadBaseAct can be used to read, by means of the variable **\$BASE_ACT**, the current position of the base origin.




Fig. 8-8: ReadBaseAct function block symbol

| Parameter | Data type | I/O | Element | Description |
|-----------|-----------|-----|--------------|---|
| X | REAL | OUT | \$ACT_BASE.X | X coordinate |
| Y | REAL | OUT | \$ACT_BASE.Y | Y coordinate |
| Z | REAL | OUT | \$ACT_BASE.Z | Z coordinate |
| A | REAL | OUT | \$ACT_BASE.A | Orientation A |
| B | REAL | OUT | \$ACT_BASE.B | Orientation B |
| C | REAL | OUT | \$ACT_BASE.C | Orientation C |
| bValid | BOOL | OUT | - | TRUE: base coordinates are valid. FALSE: base coordinates are not valid. |

8.2.5 Reading the current override value of the robot controller

Description

The function block ReadOvPro can be used to read, by means of the variable \$OV_PRO, the current override value of the robot controller.




Fig. 8-9: ReadOvPro function block symbol

| Parameter | Description | Range of values |
|-----------|---|-----------------|
| \$OV_PRO | The return value is the override value. | 0...100 |

8.2.6 Setting the current override value of the robot controller

Description

The function block WriteOvPro can be used to set, by means of the variable \$OV_PRO, the current override value of the robot controller.

The input parameter is the override value within a value range from 0 to 100.

| | |
|----------|---|
| i | The variable can only be written if AUT or AUT EXT mode is set and the safety gate is closed. |
|----------|---|




Fig. 8-10: WriteOvPro function block symbol

8.2.7 Reading the current actual values of the robot position

Description

The function block ReadPosAct_Md can be used to read, by means of the variable **\$POS_ACT**, the current actual values of the robot position.

NOTICE

This function can adversely affect the real-time behavior of the robot system and result in damage to the robot. To prevent this, the actual position should be read by a task that is processed a maximum of once every 12 ms.




Fig. 8-11: ReadPosAct_Md function block symbol

| Parameter | Data type | I/O | Description |
|-----------|-----------|-----|---|
| Mode | BYTE | IN | Mode = 1: \$Pos_Act in BASE Mode = 2: \$Pos_Act in WORLD |
| X | REAL | OUT | X coordinate |
| Y | REAL | OUT | Y coordinate |
| Z | REAL | OUT | Z coordinate |
| A | REAL | OUT | Orientation A |
| B | REAL | OUT | Orientation B |
| C | REAL | OUT | Orientation C |

8.2.8 Reading robot controller variables (Integer-type)

Description

The function block ReadSenInt can be used to read 20 Integer-type variables of the robot controller which are available for KRL programming. These variables must contain freely available integer values. The variables are contained in the array **\$SEN_PINT[]**.




Fig. 8-12: ReadSenInt function block symbol

| Parameter | Data type | I/O | Description |
|-----------------|-----------|-----|--|
| Index | BYTE | IN | Index of the robot controller variables from 1 to 20 |
| Function result | DINT | OUT | Value of variable |

8.2.9 Writing to robot controller variables (Integer-type)

Description The function block WriteSenInt can be used to write to 20 Integer-type variables of the robot controller which are available for KRL programming. These variables must contain freely available integer values. The variables are contained in the array \$SEN_PINT[].




Fig. 8-13: WriteSenInt function block symbol

| Parameter | Data type | I/O | Description |
|-----------------|-----------|-----|--|
| Index | BYTE | IN | Index of the robot controller variables from 1 to 20 |
| Function result | DINT | OUT | Value of variable |

8.2.10 Reading robot controller variables (REAL-type)

Description The function block ReadSenReal can be used to read 20 REAL-type variables of the robot controller which are available for KRL programming. These variables must contain freely available real values. The variables are contained in the array \$SEN_PREA[].




Fig. 8-14: ReadSenReal function block symbol

| Parameter | Data type | I/O | Description |
|-----------------|-----------|-----|--|
| Index | BYTE | IN | Index of the robot controller variables from 1 to 20 |
| Function result | REAL | OUT | Value of variable |

8.2.11 Writing to robot controller variables (REAL-type)

Description The function block WriteSenReal can be used to write to 20 REAL-type variables of the robot controller which are available for KRL programming. These variables must contain freely available real values. The variables are contained in the array \$SEN_PREA[].




Fig. 8-15: WriteSenReal function block symbol

| Parameter | Data type | I/O | Description |
|-----------------|-----------|-----|--|
| Index | BYTE | IN | Index of the robot controller variables from 1 to 20 |
| Function result | REAL | IN | Value of variable |

8.2.12 Reading the current position of the tool origin

Description The function block ReadToolAct can be used to read, by means of the variable **\$POS_TOOL**, the current position of the tool origin.




Fig. 8-16: ReadToolAct function block symbol

| Parameter | Data type | I/O | Element | Description |
|-----------|-----------|-----|--------------|--|
| X | REAL | OUT | \$ACT_BASE.X | X coordinate |
| Y | REAL | OUT | \$ACT_BASE.Y | Y coordinate |
| Z | REAL | OUT | \$ACT_BASE.Z | Z coordinate |
| A | REAL | OUT | \$ACT_BASE.A | Orientation A |
| B | REAL | OUT | \$ACT_BASE.B | Orientation B |
| C | REAL | OUT | \$ACT_BASE.C | Orientation C |
| bValid | BOOL | OUT | - | TRUE: tool present. FALSE: no tool present. |

8.2.13 Reading the current operating mode

Description The function block ReadModeOp can be used to read, by means of the variable **\$MODE_OP**, the current operating mode.




Fig. 8-17: ReadModeOp function block symbol

| Parameter | Data type | I/O | Description |
|--------------|-----------|-----|-------------|
| Return value | BYTE | OUT | 1: T1 |
| | | | 2: T2 |
| | | | 3: AUT |
| | | | 4: EXT |
| | | | 5: Invalid |

8.2.14 Reading the current state of the submit and robot interpreters

Description

The function block ReadProState can be used to read, by means of the variable **\$PRO_STATE**, the current state of the submit and robot interpreters.




Fig. 8-18: ReadProState function block symbol

| Parameter | Data type | I/O | Description |
|--------------|-----------|-----|---|
| Index | BYTE | IN | 0: Submit interpreter |
| | | | 1: Robot interpreter |
| Return value | BYTE | OUT | 0: Invalid index |
| | | | 1: No program selected |
| | | | 2: Program selected but not yet started |
| | | | 3: Program is being executed |
| | | | 4: Program stopped |
| | | | 5: Program has been completely executed |

8.2.15 Reading the interpolation mode of the robot

Description

The function block ReadIpoMode has the following characteristics:

- The return value of the variable **\$IPO_MODE_C** is the valid interpolation mode in the robot main run.
- If the robot is stopped and then jogged manually, the value of **\$IPO_MODE_C** remains set to the last valid program mode value.
- If the variable **\$IPO_MODE** is modified by the user while the robot is stopped in program interpolation mode, the variable **\$IPO_MODE_C** also assumes the modified value. If the program interpolator is restarted, the system implicitly switches back to the value that was previously valid in the interpolator.
- In the case of command motions in the interrupt, **\$IPO_MODE_C** is set to the value of **\$IPO_MODE** that is valid in the interrupt level.
- When a program is deselected, the last valid interpolation mode in the interpolator remains set.




Fig. 8-19: ReadIpoMode function block symbol

| Parameter | Data type | I/O | Description |
|--------------|-----------|-----|-------------|
| Return value | BYTE | OUT | 1: #BASE |
| | | | 2: #TCP |

8.2.16 Displaying notification messages

Description The function block DisplayKCPNotifyMsg can be used to display notification messages to the user in the PLC application.




Fig. 8-20: DisplayKCPNotifyMsg function block symbol

| Parameter | Data type | I/O | Description |
|-----------|-----------|-----|---|
| Msg | STRING | IN | Notification message to be displayed (max. 44 characters) |
| Enable | BOOL | IN | Trigger to start displaying message (rising edge) |

8.2.17 Displaying status messages

Description The function block DisplayKCPStatusMsg can be used to display status messages to the user in the PLC application. The function returns an unambiguous message handle. The message handle can be used to have the specific status message cleared by the PLC program.



This function should not be used to generate cyclical messages. Otherwise there is a risk that individual messages can no longer be displayed, or that the robot controller message buffer will overflow.



If an identical status message is generated repeatedly, without being cleared first, the system stops the program that is causing this after the 10th identical message.




Fig. 8-21: DisplayKCPStatusMsg function block symbol

| Parameter | Data type | I/O | Description |
|-----------|-----------|-----|--|
| Msg | STRING | IN | Message to be displayed (max. 44 characters) |
| Enable | BOOL | IN | Trigger to start displaying message (rising edge) |
| MsgNr | DINT | OUT | Unambiguous message handle 0: Message could not be displayed. |

Timing diagram The figure shows the timing diagram for the status message “External EMERGENCY STOP”.






Fig. 8-22: Timing diagram “External EMERGENCY STOP”

- 1 Message is generated.
- 2 Message is cleared.

8.2.18 Clearing a status message

Description The function block ClearKCPStatusMsg can be used to have a status message cleared by the PLC program. Status messages cannot be acknowledged by the user.

 Only message handles returned by the function block DisplayKCPStatusMsg as a return value may be used.

 To prevent a message handle from being used a second time, it should be set to 0 after a message has been cleared.




Fig. 8-23: ClearKCPStatusMsg function block symbol

| Parameter | Data type | I/O | Description |
|-----------|-----------|-----|---|
| MsgNr | DINT | IN | Unambiguous message handle from previous call of DisplayKCPStatusMsg. (>>> 8.2.17 "Displaying status messages" Page 35) |
| Enable | BOOL | IN | Trigger to start clearing message (rising edge) |

8.2.19 Clearing all status messages

Description The function block ClearAllKCPStatusMsg can be used to clear all messages that have been displayed by means of the function block DisplayKCPStatusMsg.





Fig. 8-24: ClearAllKCPStatusMsg function block symbol

| Parameter | Data type | I/O | Description |
|-----------|-----------|-----|---|
| Enable | BOOL | IN | Trigger to start clearing message (rising edge) |

8.2.20 Converting the message number of the ISG core into plain text and displaying it

Description

The function block DisplayIsgMsg converts message numbers of the ISG core into plain text and displays the corresponding notification messages in the message window of the smartPAD.

 This module is only required if KUKA.CNC and Extended Motion are used.




Fig. 8-25: DisplayIsgMsg function block symbol

| Parameter | Data type | I/O | Description |
|-----------|-----------|-----|--|
| MsgNr | DINT | IN | Message number of the ISG core |
| AxPar | STRING | IN | Additional string parameter before the displayed message |
| Enable | BOOL | IN | Trigger for displaying the message (rising edge) |

8.2.21 Displaying/clearing status messages (simplified)


Description


The function block KRCStateMsg is a simplified function block for displaying and clearing a status message. The message handles are used internally by the function block. Access to the message handles is thus no longer required.

A rising edge at the input EnableMsg causes the status message to be displayed. A falling edge at the input EnableMsg causes the status message to be cleared again.

In the following cases, the messages displayed by this function block are implicitly cleared by the system software:

- Reboot of the PLC after a stop in cold start mode
- Reboot of the PLC after a stop in warm start mode
- System reconfiguration

 This function block can only be used with KUKA System Software 8.3 or higher.

 The messages displayed by this function block cannot be cleared by the function blocks ClearKCPStatusMsg and ClearAllKCPStatusMsg.




Fig. 8-26: KRCStateMsg function block symbol

| Parameter | Data type | I/O | Description |
|-----------|-----------|-----|---|
| Msg | STRING | IN | Message to be displayed (max. 44 characters) |
| EnableMsg | BOOL | IN | Trigger to start displaying message (rising edge) |

8.2.22 Reading the current state of the drives

Description

The function block RdPeriReady can be used to read, by means of the variable \$PERI_RDY, the current state of the drives.




Fig. 8-27: RdPeriReady function block symbol

| Parameter | Data type | I/O | Description |
|------------|-----------|-----|--|
| \$PERI_RDY | BOOL | OUT | <ul style="list-style-type: none"> ■ TRUE: Drives are switched on. ■ FALSE: Drives are switched off. |

8.2.23 Reading the current state of the robot brakes

Description

The function block RdBrakeSig can be used to read, by means of the variable \$BRAKE_SIG, the current state of the robot brakes.




Fig. 8-28: RdBrakeSig function block symbol

| Parameter | Data type | I/O | Description |
|-------------|-----------|-----|--|
| \$BRAKE_SIG | UINT | OUT | <p>Bit array for the brake signals of the robot axes of the robot controller. Each bit stands for a robot axis: Bit_0 = axis 1, Bit_1 = axis 2, etc.</p> <p>The bit values have the following meaning:</p> <ul style="list-style-type: none"> ■ 0: The robot axis is under servo-control. ■ 1: The holding brake for the robot axis is activated. <p>Examples:</p> <ul style="list-style-type: none"> ■ \$Brake_Sig = 0 (binary: 000000000000): All robot axes are under servo-control. ■ \$Brake_Sig = 63 (binary: 000000111111): The holding brakes for axis 1 to axis 6 are activated. |

8.2.24 Displaying/clearing messages

Description

The KrcUserMsg function block is used for displaying notification, status, acknowledgement and wait messages, as well as for clearing status and wait messages. Notification and acknowledgement messages are not cleared. In addition, the function block ensures the correct handling of acknowledgement checkback signals and simulation checkback signals.

The message handles are used internally by the function block. Access to the message handles is thus not required.

A rising edge at the input EnableMsg causes the message to be displayed. A falling edge at the input EnableMsg causes the status or wait message to be cleared again.

In the following cases, the status and wait messages displayed by this function block are implicitly cleared by the system software:

- Reboot of the PLC after a stop in cold start mode
- Reboot of the PLC after a stop in warm start mode
- System reconfiguration



The messages displayed by this function block cannot be cleared by the function block ClearAllKCPStatusMsg.




Fig. 8-29: KrcUserMsg function block symbol

| Parameter | Data type | I/O | Description |
|--------------------|-----------|-----|---|
| Enable Msg | BOOL | IN | <ul style="list-style-type: none"> ■ TRUE: Message is displayed. ■ FALSE: Message is cleared (status and wait messages only). |
| Message type | BYTE | IN | <ul style="list-style-type: none"> ■ 0: Notification message ■ 1: Status message ■ 2: Acknowledgement message ■ 3: Wait message |
| Message text / key | STRING | IN | <p>Message text with placeholders for the parameters, or database key for the KXR file.</p> <p>Maximum length: 80 characters</p> <p>Note: Message texts or keys which are longer than 80 characters result in an error reaction at the output nError.</p> |
| Message number | USINT | IN | Message number on the HMI |
| Sender | STRING | IN | <p>Sender ID on the HMI</p> <p>Note: ProConOS messages are identified by means of square brackets as the sender.</p> |
| Parameter_1 | ANY | IN | <p>1st parameter for the message, placeholder: %1</p> <ul style="list-style-type: none"> ■ STRING: Is transferred directly to the message. ■ SINT, INT, DINT, USINT, UINT, UDINT, WORD, DWORD, BYTE: Are converted into the string representation of the integer value and then sent as a message parameter to the robot controller. ■ BOOL: Converted into the string representation TRUE/FALSE and displayed as a parameter. ■ REAL, LREAL: Converted into the string representation (e.g. 0.01234) and displayed as a parameter. <p>Maximum length: 44 characters</p> <p>If the maximum length is exceeded, the parameter is implicitly shortened to the maximum length.</p> <p>Note: If the parameter is not required, omit the value or the variable.</p> |
| Parameter_2 | ANY | IN | <p>2nd parameter for the message, placeholder: %2</p> <p>Note: The data type has the same effects and the same maximum length as Parameter_1. If the parameter is not required, omit the value or the variable.</p> |

| Parameter | Data type | I/O | Description |
|-------------|-----------|-----|---|
| Parameter_3 | ANY | IN | 3rd parameter for the message, placeholder: %3 Note: The data type has the same effects and the same maximum length as Parameter_1. If the parameter is not required, omit the value or the variable. |
| nError | INT | OUT | Error code if a problem occurs on displaying the message: <ul style="list-style-type: none"> ■ 0: No error ■ -1: Message type is invalid ■ -2: Message key is too long (max. 80 characters allowed) ■ -3: Maximum number of messages has been reached (max. 20 status, wait and acknowledgement messages are possible) ■ -4: Maximum number of messages per second has been reached (max. 20 messages every 4 seconds are possible) ■ -5: General error on sending the message to the robot controller ■ -6: Interface to the robot controller is not available (e.g. if ProConOS is operated without a robot controller) ■ -11: Invalid data type in the 1st message parameter ■ -12: Invalid data type in the 2nd message parameter ■ -13: Invalid data type in the 3rd message parameter ■ -14: Error during generation of the ProConOS message in the ProConOS message management facility ■ -15: Invalid reference to the ProConOS message management facility ■ -16: General ProConOS error in the message function block |
| bDisplay | BOOL | OUT | Indicates that the message has been displayed in the message window of the HMI. <ul style="list-style-type: none"> ■ Notification messages: The parameter has no meaning and is therefore always FALSE. ■ Status messages: The parameter is TRUE for as long as the message is set. ■ Acknowledgement messages: The parameter is TRUE as long as the message has not been acknowledged. ■ Wait messages: The parameter is TRUE as long as the message has not been simulated in the message window. |

Examples

| | |
|--------------|---|
| Message text | Connection to device %1, device %2 and device %3 is established. |
| Parameter | <ul style="list-style-type: none"> ■ Parameter_1: String "Hugo" ■ Parameter_2: String "Otto" ■ Parameter_3: Integer "55" |
| Result | Connection to device Hugo, device Otto and device 55 is established. |

| | |
|--------------|--|
| Message text | Parameter 1 is %1 and parameter 2 has the value %2. |
| Parameter | <ul style="list-style-type: none"> ■ Parameter_1: Bool "TRUE" ■ Parameter_2: Real "0.0123" |
| Result | Parameter 1 is TRUE and parameter 2 has the value 0.0123. |

8.3 KrcExVarLib library

Description This library makes it possible to read and write in an array. The robot controller makes available the following array variables, which can be used for data exchange between ProConOS and the robot controller software:

- \$SOFTPLCBOOL[1...n]
- \$SOFTPLCINT[1...n]
- \$SOFTPLCREAL[1...n]

8.3.1 Reading a value from an array

Description The function blocks ReadPLCBool, ReadPLCInt and ReadPLCReal can each be used to read a single value from an array.

Example The example shows the function block ReadPLCBool, which reads the value of the KR C variable \$SOFTPLCBOOL[x] and assigns it to the ProConOS variable at the output "Value". The result is saved in the variable at the output "Result".




Fig. 8-30: RealPLCBool function block symbol

| Parameter | Data type | I/O | Description |
|-----------|-----------|-----|-------------------------|
| Index | INT | IN | Index valid from 1 to n |
| Value | BOOL | OUT | Value from the array |
| | DINT | OUT | |
| | REAL | OUT | |
| Result | BOOL | OUT | TRUE: Error |
| | | | FALSE: OK |

8.3.2 Writing a value to an array

Description The function blocks WritePLCBool, WritePLCInt and WritePLCReal can each be used to write a single value to an array.

Example The example shows the function block WritePLCInt, which reads the value of the KR C variable \$SOFTPLCBOOL[x] and assigns it to the ProConOS variable at the output "Value". The result is saved in the variable at the output "Result".




Fig. 8-31: WritePLCInt function block symbol

| Parameter | Data type | I/O | Description |
|-----------|-----------|-----|-------------------------|
| Index | INT | IN | Index valid from 1 to n |
| Value | BOOL | OUT | Value from the array |
| | DINT | OUT | |
| | REAL | OUT | |
| Result | BOOL | OUT | TRUE: Error |
| | | | FALSE: OK |

8.3.3 Reading multiple values from an array

Description

The function blocks ReadPLCBoolEx, ReadPLCIntEx and ReadPLCRealEx can be used to read a number of values from an array.

Example

The example shows the function block ReadPLCBoolEx, which reads the value of the KR C variable \$SOFTPLCBOOL[x...y] and assigns it to the ProConOS array at the output "BoolArray". The result is saved in the variable at the output "Result".




Fig. 8-32: ReadPLCBoolEx function block symbol

| Parameter | Data type | I/O | Description |
|-----------|-----------|-----|--|
| Index | INT | IN | Start index for reading within a range of values from 1 to 28. |
| Amount | BYTE | IN | Number of variables to be read |
| BoolArray | BOOL | OUT | ProConOS ARRAY[1 to n] which receives the data from \$SOFT-PLCBOOL[1 to 128]. Used with ReadPLCBoolEx. |
| DintArray | DINT | OUT | ProConOS ARRAY[1 to n] which receives the data from \$SOFT-PLCBOOL[1 to 128]. Used with ReadPLCIntEx. |
| RealArray | REAL | OUT | ProConOS ARRAY[1 to n] which receives the data from \$SOFT-PLCBOOL[1 to 128]. Used with ReadPLCRealEx. |
| Result | BOOL | OUT | TRUE: OK |
| | | | FALSE: Error |

8.3.4 Writing multiple values to an array

Description The function blocks WritePLCBoolEx, WritePLCIntEx and WritePLCRealEx can be used to write a number of values to an array.

Example The example shows the function block WritePLCRealEx, which writes the values of the ProConOS array at the input "RealArray" to the KR C variables \$SOFTPLCBOOL[x...y]. The result is saved in the variable at the output "Result".




Fig. 8-33: WritePLCRealEx function block symbol

| Parameter | Data type | I/O | Description |
|-----------|-----------|-----|--|
| Index | INT | IN | Start index for reading within a range of values from 1 to 1024. |
| Amount | BYTE | IN | Number of variables to be read |
| BoolArray | BOOL | IN | ProConOS ARRAY[1 to n] from which the data are written to \$SOFTPLCBOOL[1 to n]. Used with WritePLCBoolEx. |
| DintArray | DINT | IN | ProConOS ARRAY[1 to n] from which the data are written to \$SOFTPLCBOOL[1 to n]. Used with WritePLCIntEx. |
| RealArray | REAL | IN | ProConOS ARRAY[1 to n] from which the data are written to \$SOFTPLCBOOL[1 to n]. Used with WritePLCRealEx. |
| Result | BOOL | OUT | TRUE: OK FALSE: Error |

8.4 AutoExtLib library

The function blocks KRC_AutoExt and VKRC_AutoExt from the ProConOS library AutoExtLib make it possible to operate the Automatic External interface of the robot controller directly, without the need to use ProConOS I/Os. If the wrong block on the robot controller is used, an error message is generated when the project is downloaded in Multiprog.

The signal declarations are read from the following files:

- C:\KRC\Roboter\KRC\R1\System\Config.dat
- C:\KRC\Roboter\KRC\Steu\Mada\Machine.dat

The associated I/Os can be read and written directly by the function blocks.



The entry SIGNALFILES in the file ProConOS.xml is automatically set by the setup program and should not be modified.

The signal files are read in accordance with the entry SIGNALFILEREAD. If this entry is set to BOOT, the signal files are read once when ProConOS or the robot controller is started. Otherwise, the signal files are reloaded every time

ProConOS program execution is started. If Automatic External interface signals are reconfigured, ProConOS must be stopped and restarted.



Further information is contained in the operating and programming instructions for the KUKA System Software (KSS) or VW System Software (VSS).

8.4.1 Operating the Automatic External interface (KR C)

Description

The function block KRC_AutoExt can be used in the robot controller to operate the Automatic External interface.

To select a KRL program, its program number must be applied to the input PGNO and acknowledged in accordance with the value of the variable **PGNO_VALID**. The actual program number and parity are formed according to the following values:

- PGNO_FBIT
- PGNO_LENGTH
- PGNO_TYPE
- PGNO_PARITY

If the program number at input PGNO cannot be displayed with the bits defined in PGNO_LENGTH, program number 0 is written to the input map.




Fig. 8-34: Function block symbol KRC_AutoExt


| Parameter | Data type | KRL variable | Meaning |
|-------------|-----------|---------------|------------------------|
| PGNO | INT | PGNO_FBIT | Program number |
| PGNO_VALID | BOOL | PGNO_VALID | Program number valid |
| EXT_START | BOOL | \$EXT_START | Start of program |
| MOVE_ENABLE | BOOL | \$MOVE_ENABLE | Drive enable |
| CONF_MESS | BOOL | \$CONF_MESS | Acknowledge messages |
| DRIVES_ON | BOOL | \$DRIVES_ON | Switch on drives |
| DRIVES_OFF | BOOL | \$DRIVES_OFF | Switch off drives |
| I_O_ACT | BOOL | \$I_O_ACT | Activate interface |
| STOPMESS | BOOL | \$STOPMESS | Robot collective fault |
| ALARM_STOP | BOOL | \$ALARM_STOP | E-STOP of robot |
| USER_SAF | BOOL | \$USER_SAF | Operator safety |

| Parameter | Data type | KRL variable | Meaning |
|-------------|-----------|----------------|---|
| PGNO_REQ | BOOL | PGNO_REQ | Program number request |
| PGNO_REFL | INT | PGNO_FBIT_REFL | Reflected program number, -1 if deactivated (REFLECT_PROG_NR=0) |
| APPL_RUN | BOOL | APPL_RUN | Robot program running |
| PERI_RDY | BOOL | \$PERI_RDY | Drives are activated |
| T1 | BOOL | \$T1 | T1 mode |
| T2 | BOOL | \$T2 | T2 mode |
| AUT | BOOL | \$AUT | Automatic mode |
| EXT | BOOL | \$EXT | External mode |
| ON_PATH | BOOL | \$ON_PATH | Robot on path |
| NEAR_POSRET | BOOL | \$NEAR_POSRET | Robot near path |
| PRO_ACT | BOOL | \$PRO_ACT | Robot program execution active |
| PRO_MOVE | BOOL | \$PROMOVE | Robot program motion active |
| IN_HOME | BOOL | \$IN_HOME | Robot in home position 1 |
| IN_HOME1 | BOOL | \$IN_HOME1 | Robot in home position 2 |
| IN_HOME2 | BOOL | \$IN_HOME2 | Robot in home position 3 |
| IN_HOME3 | BOOL | \$IN_HOME3 | Robot in home position 4 |
| IN_HOME4 | BOOL | \$IN_HOME4 | Robot in home position 5 |
| IN_HOME5 | BOOL | \$IN_HOME5 | Robot in home position 6 |
| ERR_TO_PLC | BOOL | ERR_TO_PLC | Controller or technology fault |
| RC_RDY1 | BOOL | \$RC_RDY1 | Robot controller ready |
| ROB_CAL | BOOL | \$ROB_CAL | Robot mastered |
| I_O_ACTCONF | BOOL | \$I_O_ACTCONF | Interface active |
| ROB_STOPPED | BOOL | \$ROB_STOPPED | Robot stopped |

8.4.2 Operating the Automatic External interface (VKR C)

Description

The function block VKRC_AutoExt can be used in the VKR C to operate the Automatic External interface.



To select a KRL Folge (program), its Folge number must be applied to the input of the FOLGE and acknowledged at the input SRB.

The Folge number is formed according to the following values:

- P_FBIT
- P_LEN
- P_TYPE




Fig. 8-35: VKRC_AutoExt function block symbol

| Parameter | Data type | KRL variant | Meaning |
|------------|-----------|---------------|----------------------------------|
| ANTEIN | BOOL | \$DRIVES_ON | Drive enable |
| SRB | BOOL | SRB | Start Folge |
| FOLGE | INT | P_FBIT | Folge number |
| BEREIT | BOOL | \$RC_RDY1 | Operating mode |
| FOLGE_REFL | INT | R_FBIT | Reflected Folge number |
| FOLGE_ALT | INT | P_OLD | Last Folge in Automatic mode |
| RK23 | BOOL | \$PR_MODE | Programming mode |
| RK8 | BOOL | \$SS_MODE | Single Step mode |
| RK9 | BOOL | \$EXT | Automatic mode |
| RK100 | BOOL | RK100 | Enable start actuators |
| WPROZ | BOOL | WPROZ | Wait for process |
| WSLAV | BOOL | WSLAV | Wait for slave |
| LPKT | BOOL | LPKT | Last point reached |
| PF0 | BOOL | PF0 | Home position |
| SAK | BOOL | \$NEAR_POSRET | Block coincidence, robot on path |

9 Diagnosis

9.1 Global variables

The status of global variables can provide information for diagnosis.

| Variable | Description |
|---------------------------|--|
| bRetainValid | TRUE: Reading of the Retain data was successful last time ProConOS was started. |
| bSPOC_UserSafeActive | The variables are described in the chapter "Safety". (>>> 3 "Safety" Page 11) |
| bSPOC_MotionEnabled | |
| PDD_KRC_RW_SUSPEND | TRUE: Access to PDD variables is temporarily suspended, e.g. due to a file download of KRL programs. |
| PDD_KRC_READ_NO_INIT | TRUE: Access to PDD variables is not possible because a KRL variable is not initialized (e.g. a variable such as \$POS_INT which can temporarily become invalid). |
| PDD_KRC_WRITE_FAILED_SPOC | TRUE: Access to PDD variables is not possible because the previous SPOC state is blocking access. |

10 KUKA Service

10.1 Requesting support

Introduction The KUKA Roboter GmbH documentation offers information on operation and provides assistance with troubleshooting. For further assistance, please contact your local KUKA subsidiary.

Information The following information is required for processing a support request:

- Model and serial number of the robot
- Model and serial number of the controller
- Model and serial number of the linear unit (if applicable)
- Model and serial number of the energy supply system (if applicable)
- Version of the KUKA System Software
- Optional software or modifications
- Archive of the software
 - For KUKA System Software V8: instead of a conventional archive, generate the special data package for fault analysis (via **KrcDiag**).
- Application used
- Any external axes used
- Description of the problem, duration and frequency of the fault

10.2 KUKA Customer Support

Availability KUKA Customer Support is available in many countries. Please do not hesitate to contact us if you have any questions.

Argentina Ruben Costantini S.A. (Agency)
Luis Angel Huergo 13 20
Parque Industrial
2400 San Francisco (CBA)
Argentina
Tel. +54 3564 421033
Fax +54 3564 428877
ventas@costantini-sa.com

Australia Headland Machinery Pty. Ltd.
Victoria (Head Office & Showroom)
95 Highbury Road
Burwood
Victoria 31 25
Australia
Tel. +61 3 9244-3500
Fax +61 3 9244-3501
vic@headland.com.au
www.headland.com.au

| | |
|----------------|---|
| Belgium | KUKA Automatisering + Robots N.V. Centrum Zuid 1031 3530 Houthalen Belgium Tel. +32 11 516160 Fax +32 11 526794 info@kuka.be www.kuka.be |
| Brazil | KUKA Roboter do Brasil Ltda. Travessa Claudio Armando, nº 171 Bloco 5 - Galpões 51/52 Bairro Assunção CEP 09861-7630 São Bernardo do Campo - SP Brazil Tel. +55 11 4942-8299 Fax +55 11 2201-7883 info@kuka-roboter.com.br www.kuka-roboter.com.br |
| Chile | Robotec S.A. (Agency) Santiago de Chile Chile Tel. +56 2 331-5951 Fax +56 2 331-5952 robotec@robotec.cl www.robotec.cl |
| China | KUKA Robotics China Co.,Ltd. Songjiang Industrial Zone No. 388 Minshen Road 201612 Shanghai China Tel. +86 21 6787-1888 Fax +86 21 6787-1803 www.kuka-robotics.cn |
| Germany | KUKA Roboter GmbH Zugspitzstr. 140 86165 Augsburg Germany Tel. +49 821 797-4000 Fax +49 821 797-1616 info@kuka-roboter.de www.kuka-roboter.de |

France KUKA Automatismes + Robotique SAS
Techvallée
6, Avenue du Parc
91140 Villebon S/Yvette
France
Tel. +33 1 6931660-0
Fax +33 1 6931660-1
commercial@kuka.fr
www.kuka.fr

India KUKA Robotics India Pvt. Ltd.
Office Number-7, German Centre,
Level 12, Building No. - 9B
DLF Cyber City Phase III
122 002 Gurgaon
Haryana
India
Tel. +91 124 4635774
Fax +91 124 4635773
info@kuka.in
www.kuka.in

Italy KUKA Roboter Italia S.p.A.
Via Pavia 9/a - int.6
10098 Rivoli (TO)
Italy
Tel. +39 011 959-5013
Fax +39 011 959-5141
kuka@kuka.it
www.kuka.it

Japan KUKA Robotics Japan K.K.
YBP Technical Center
134 Godo-cho, Hodogaya-ku
Yokohama, Kanagawa
240 0005
Japan
Tel. +81 45 744 7691
Fax +81 45 744 7696
info@kuka.co.jp

Canada KUKA Robotics Canada Ltd.
6710 Maritz Drive - Unit 4
Mississauga
L5W 0A1
Ontario
Canada
Tel. +1 905 670-8600
Fax +1 905 670-8604
info@kukarobotics.com
www.kuka-robotics.com/canada

| | |
|-----------------|--|
| Korea | KUKA Robotics Korea Co. Ltd. RIT Center 306, Gyeonggi Technopark 1271-11 Sa 3-dong, Sangnok-gu Ansan City, Gyeonggi Do 426-901 Korea Tel. +82 31 501-1451 Fax +82 31 501-1461 info@kukakorea.com |
| Malaysia | KUKA Robot Automation Sdn Bhd South East Asia Regional Office No. 24, Jalan TPP 1/10 Taman Industri Puchong 47100 Puchong Selangor Malaysia Tel. +60 3 8061-0613 or -0614 Fax +60 3 8061-7386 info@kuka.com.my |
| Mexico | KUKA de México S. de R.L. de C.V. Progreso #8 Col. Centro Industrial Puente de Vigas Tlalnepantla de Baz 54020 Estado de México Mexico Tel. +52 55 5203-8407 Fax +52 55 5203-8148 info@kuka.com.mx www.kuka-robotics.com/mexico |
| Norway | KUKA Sveiseanlegg + Roboter Sentrumsvegen 5 2867 Hov Norway Tel. +47 61 18 91 30 Fax +47 61 18 62 00 info@kuka.no |
| Austria | KUKA Roboter Austria GmbH Vertriebsbüro Österreich Regensburger Strasse 9/1 4020 Linz Austria Tel. +43 732 784752 Fax +43 732 793880 office@kuka-roboter.at www.kuka-roboter.at |

Poland KUKA Roboter Austria GmbH
Spółka z ograniczoną odpowiedzialnością
Oddział w Polsce
Ul. Porcelanowa 10
40-246 Katowice
Poland
Tel. +48 327 30 32 13 or -14
Fax +48 327 30 32 26
ServicePL@kuka-roboter.de

Portugal KUKA Sistemas de Automatización S.A.
Rua do Alto da Guerra n° 50
Armazém 04
2910 011 Setúbal
Portugal
Tel. +351 265 729780
Fax +351 265 729782
kuka@mail.telepac.pt

Russia OOO KUKA Robotics Rus
Webnaja ul. 8A
107143 Moskau
Russia
Tel. +7 495 781-31-20
Fax +7 495 781-31-19
kuka-robotics.ru

Sweden KUKA Svetsanläggningar + Robotar AB
A. Odhners gata 15
421 30 Västra Frölunda
Sweden
Tel. +46 31 7266-200
Fax +46 31 7266-201
info@kuka.se

Switzerland KUKA Roboter Schweiz AG
Industriestr. 9
5432 Neuenhof
Switzerland
Tel. +41 44 74490-90
Fax +41 44 74490-91
info@kuka-roboter.ch
www.kuka-roboter.ch

| | |
|-----------------------|--|
| Spain | KUKA Robots IBÉRICA, S.A. Pol. Industrial Torrent de la Pastera Carrer del Bages s/n 08800 Vilanova i la Geltrú (Barcelona) Spain Tel. +34 93 8142-353 Fax +34 93 8142-950 Comercial@kuka-e.com www.kuka-e.com |
| South Africa | Jendamark Automation LTD (Agency) 76a York Road North End 6000 Port Elizabeth South Africa Tel. +27 41 391 4700 Fax +27 41 373 3869 www.jendamark.co.za |
| Taiwan | KUKA Robot Automation Taiwan Co., Ltd. No. 249 Pujong Road Jungli City, Taoyuan County 320 Taiwan, R. O. C. Tel. +886 3 4331988 Fax +886 3 4331948 info@kuka.com.tw www.kuka.com.tw |
| Thailand | KUKA Robot Automation (M)SdnBhd Thailand Office c/o Maccall System Co. Ltd. 49/9-10 Soi Kingkaew 30 Kingkaew Road Tt. Rachatheva, A. Bangpli Samutprakarn 10540 Thailand Tel. +66 2 7502737 Fax +66 2 6612355 atika@ji-net.com www.kuka-roboter.de |
| Czech Republic | KUKA Roboter Austria GmbH Organisation Tschechien und Slowakei Sezemická 2757/2 193 00 Praha Horní Počernice Czech Republic Tel. +420 22 62 12 27 2 Fax +420 22 62 12 27 0 support@kuka.cz |

Hungary KUKA Robotics Hungaria Kft.
Fő út 140
2335 Taksony
Hungary
Tel. +36 24 501609
Fax +36 24 477031
info@kuka-robotics.hu

USA KUKA Robotics Corporation
51870 Shelby Parkway
Shelby Township
48315-1787
Michigan
USA
Tel. +1 866 873-5852
Fax +1 866 329-5852
info@kukarobotics.com
www.kukarobotics.com

UK KUKA Automation + Robotics
Hereward Rise
Halesowen
B62 8AN
UK
Tel. +44 121 585-0800
Fax +44 121 585-0900
sales@kuka.co.uk

Index

A

Accessing robot controller signals 25
 Array, \$SEN_PINT\ 31, 32
 Array, \$SEN_PREA\ 32
 AutoExtLib library 44

C

Clearing a status message 36
 Clearing all status messages 36
 Configuration 19
 Converting the message number of the ISG core into plain text and displaying it 37
 Current actual position values of axes A1 to A12, reading 28
 Current state of drives, reading 38
 Current state of robot brakes, reading 38

D

Diagnosis 49
 Displaying notification messages 35
 Displaying status messages 35
 Documentation, industrial robot 5

E

Exception 6
 ExtensionLibV8 library 25

F

Function, ClearAllKCPStatusMsg 36
 Function, ClearKCPStatusMsg 36
 Function, DisplayIsgMsg 37
 Function, DisplayKCPNotifyMsg 35
 Function, DisplayKCPStatusMsg 35
 Function, KRC_AutoExt 45
 Function, RdBrakeSig 38
 Function, RdPeriReady 38
 Function, ReadAxisAct_Md 28
 Function, ReadBaseAct 29
 Function, ReadIpoMode 34
 Function, ReadModeOp 33
 Function, ReadOvPro 30
 Function, ReadPLCBool 42
 Function, ReadPLCInt 42
 Function, ReadPLCReal 42
 Function, ReadPosAct_Md 31
 Function, ReadProState 34
 Function, ReadSenInt 31
 Function, ReadSenReal 32
 Function, ReadToolAct 33
 Function, RobStop 27
 Function, RobStopRel 28
 Function, SaveRetain 26
 Function, VKRC_AutoExt 47
 Function, WriteOvPro 30
 Function, WritePLCBool 42
 Function, WritePLCBoolEx 44
 Function, WritePLCInt 42
 Function, WritePLCIntEx 44

Function, WritePLCReal 42
 Function, WritePLCRealEx 44
 Funktion, PlcSleep 27
 Funktion, WriteSenInt 32
 Funktion, WriteSenReal 32

I

Installation 15
 Introduction 5

K

KLI 6
 KrcExVarLib library 42
 KrcLibV8 library 27
 KrcSignalRead 25
 KrcSignalWrite 26
 KUKA Customer Support 51
 KUKA.PLC Multiprog 5-35 6
 KUKA.PLC Multiprog 5-35, installing 15
 KUKA.PLC Multiprog 5-35, uninstalling 15

M

Mapping Multiprog variables 20
 Messages, clearing 39
 Messages, displaying 39
 Multiprog project, importing into WorkVisual 20
 Multiprog project, opening in WorkVisual 19

N

Notification message 6

O

Operating the Automatic External interface (KR C) 45
 Operating the Automatic External interface (VKR C) 47
 Operation 17
 Overview, KUKA.PLC Multiprog 5-35 9

P

PDD 7
 ProConOS 6
 Product description 9
 Programming 23
 Provide CPU computing time 27

R

Reading a value from an array 42
 Reading KR C signals 25
 Reading multiple values from an array 43
 Reading robot controller variables (Integer-type) 31
 Reading robot controller variables (REAL-type) 32
 Reading the current actual values of the robot position 31
 Reading the current operating mode 33
 Reading the current override value of the robot

controller 30
Reading the current position of the base origin
29
Reading the current position of the tool origin 33
Reading the current state of the submit and robot
interpreters 34
Reading the interpolation mode of the robot 34
ReadPLCBoolEx 43
ReadPLCIntEx 43
ReadPLCRealEx 43
Retentive data 6

S

Safety 11
Safety instructions 5
Saving retentive data using a program 26
Service, KUKA Roboter 51
Setting the current override value of the robot
controller 30
Single point of control 11
SPOC 6, 11
Status message 7
Status messages, clearing (simplified) 37
Status messages, displaying (simplified) 37
Support request 51
System requirements 15

T

Target group 5
Terms used 6
Time slice 6
Trademarks 6
Training 5

V

Variable, \$AXIS_ACT 28
Variable, \$BASE_ACT 29
Variable, \$BRAKE_SIG 38
Variable, \$IPO_MODE 34
Variable, \$IPO_MODE_C 34
Variable, \$MODE_OP 33
Variable, \$OV_PRO 30
Variable, \$PERI_RDY 38
Variable, \$POS_ACT 31
Variable, \$POS_TOOL 33
Variable, \$PRO_STATE 34
Variables, global 49

W

Warnings 5
Watchdog 6
WorkVisual 6
Writing a value to an array 42
Writing KR C signals 26
Writing multiple values to an array 44
Writing to robot controller variables (Integer-type) 32
Writing to robot controller variables (REAL-type)
32

