


Controller Option

KUKA Roboter GmbH

KR C4 PROFIBUS CP 5614 1.0

For KUKA System Software 8.2

For VW System Software 8.2



Issued: 23.03.2012

Version: KR C4 PROFIBUS CP 5614 1.0 V2 en

© Copyright 2012

KUKA Roboter GmbH
Zugspitzstraße 140
D-86165 Augsburg
Germany

This documentation or excerpts therefrom may not be reproduced or disclosed to third parties without the express permission of KUKA Roboter GmbH.

Other functions not described in this documentation may be operable in the controller. The user has no claims to these functions, however, in the case of a replacement or service work.

We have checked the content of this documentation for conformity with the hardware and software described. Nevertheless, discrepancies cannot be precluded, for which reason we are not able to guarantee total conformity. The information in this documentation is checked on a regular basis, however, and necessary corrections will be incorporated in the subsequent edition.

Subject to technical alterations without an effect on the function.

Translation of the original documentation

KIM-PS5-DOC

Publication:	Pub KR C4 PROFIBUS CP 5614 1.0 en
Bookstructure:	KR C4 PROFIBUS CP 5614 1.0 V1.1
Version:	KR C4 PROFIBUS CP 5614 1.0 V2 en

Contents

1	Introduction	5
1.1	Target group	5
1.2	Industrial robot documentation	5
1.3	Representation of warnings and notes	5
1.4	Trade mark	5
1.5	Terms used	6
2	Product description	7
3	Safety	9
4	Installation	11
4.1	System requirements	11
4.2	Routing the data cables	11
4.3	Installing or updating PROFIBUS CP 5614	11
4.4	Uninstalling PROFIBUS CP 5614	12
5	Configuration	13
5.1	Overview	13
5.2	Configuring PROFIBUS with Step 7 or NCM	13
5.3	Exporting the bus configuration and LDB file from Step 7 or NCM	14
5.4	Importing the bus configuration and LDB file into WorkVisual	14
5.5	Configuring the driver for the master part of the CP 5614 A2 in WorkVisual	15
5.5.1	“ Master settings ” tab	15
5.5.2	“ Device settings ” tab	16
5.6	Configuring the driver for the slave part of the CP 5614 A2 in WorkVisual	17
5.6.1	“ Slave settings ” tab	17
5.7	Mapping inputs/outputs in WorkVisual	18
6	Operation	21
6.1	Coupling/decoupling devices	21
7	Diagnosis	23
7.1	Displaying diagnostic data	23
8	Messages	25
9	KUKA Service	27
9.1	Requesting support	27
9.2	KUKA Customer Support	27
	Index	35

1 Introduction

1.1 Target group

This documentation is aimed at users with the following knowledge and skills:

- Advanced KRL programming skills
- Advanced knowledge of the robot controller system
- Advanced knowledge of field buses
- Knowledge of WorkVisual

1.2 Industrial robot documentation

The industrial robot documentation consists of the following parts:


- Documentation for the manipulator
- Documentation for the robot controller
- Operating and programming instructions for the KUKA System Software
- Documentation relating to options and accessories
- Parts catalog on storage medium


Each of these sets of instructions is a separate document.


1.3 Representation of warnings and notes


Safety


These warnings are relevant to safety and **must** be observed.

 **DANGER** These warnings mean that it is certain or highly probable that death or severe physical injury **will** occur, if no precautions are taken.

 **WARNING** These warnings mean that death or severe physical injury **may** occur, if no precautions are taken.


 **CAUTION** These warnings mean that minor physical injuries **may** occur, if no precautions are taken.

 **NOTICE** These warnings mean that damage to property **may** occur, if no precautions are taken.

 These warnings contain references to safety-relevant information or general safety measures. These warnings do not refer to individual hazards or individual precautionary measures.

Notes

These hints serve to make your work easier or contain references to further information.

 Tip to make your work easier or reference to further information.

1.4 Trade mark

Windows is a trade mark of Microsoft Corporation.

Step 7 is a trademark of Siemens AG.

1.5 Terms used

Term	Description
GSD	Device description file for PROFIBUS
PLC	Programmable logic controller
DP	Decentralized periphery
PA	Process automation
Step 7	Configuration software from Siemens for field bus configuration and diagnosis
NCM	Free extract from Step 7 with the same range of functions for PROFIBUS configuration
WorkVisual	Configuration software from KUKA for field bus configuration
LDB	Local database: configuration file for the CP 5614 A2 with hardware information
CFG	Configuration file with information about the hardware configuration

2 Product description

PROFIBUS is a universal field bus which enables communication between devices from different manufacturers without special interface adaptations. Data exchange is carried out on a master-slave basis.

The CP 5614 A2 is a PCI card for connecting the robot controller to the PROFIBUS. The card has a master ring and a slave ring. The master and slave rings may be operated individually or in parallel.

The card is connected to slot 1 of the robot controller:




Fig. 2-1: Slot for the CP 5614 A2

1 CP 5614 A2 in slot 1

Compatibility KR C4 PROFIBUS CP 5614 1.0 is compatible with the following field buses:

- KR C4 PROFINET 2.2
- KR C4 EtherCAT

Restrictions Only the device class PROFIBUS DP-V0 is supported.

The following device classes / functions are not supported, for example:


- PROFIBUS DP-V1 (includes the function “acyclic communication”)
- PROFIBUS DP-V2
- PROFIBUS PA
- Profiles, e.g. PROFIdrive or PROFIsafe
- Gateway devices (for converting PROFIBUS to other field buses)

Configuration software KR C4 PROFIBUS CP 5614 is configured on a laptop or PC. The following software is required for configuration:

- Step 7 from Siemens, version 5.4 or higher
- WorkVisual 2.4 or higher
- With use of a higher-level controller, the corresponding configuration software from the manufacturer of the higher-level controller is also required, e.g. Step 7 from Siemens.

3 Safety

This documentation contains safety instructions which refer specifically to the product described here. The fundamental safety information for the industrial robot can be found in the “Safety” chapter of the operating or assembly instructions for the robot controller.

 **WARNING** The “Safety” chapter in the operating instructions or assembly instructions of the robot controller must be observed. Death to persons, severe physical injuries or considerable damage to property may otherwise result.

4 Installation

4.1 System requirements

Robot controller

Hardware:

- KR C4

Software:

- KUKA System Software 8.2.17 or higher
- Or VW System Software 8.2.17 or higher

Laptop/PC

- WorkVisual 2.4 or higher

The requirements for installation of WorkVisual are contained in the WorkVisual documentation.

- Step 7, version 5.4 or higher

The requirements for installation of Step 7 are contained in the documentation of this software.

4.2 Routing the data cables

- The PROFIBUS cables are routed linearly from the master to the slaves. In the line structure, all devices are connected in parallel.

4.3 Installing or updating PROFIBUS CP 5614



It is advisable to archive all relevant data before updating a software package.

Preparation

- Copy the folder with the software from the CD to the USB stick.



Recommendation: Use a KUKA stick. Data may be lost if any other stick is used.

Precondition

- "Expert" user group

Procedure

1. Connect the USB stick to the robot controller.
2. In the main menu, select **Start-up > Install additional software**.
3. Press **New software**. The entry **KR C4 Profibus-CP5614** must be displayed in the **Name** column and drive **E:** in the **Path** column.
If not, press **Refresh**.
4. If the specified entries are now displayed, continue with step 5.
If not, the drive from which the software is being installed must be configured first:
 - Click on the **Configuration** button. A new window opens.
 - Select a line in the **Installation paths for options** area.
Note: If the line already contains a path, this path will be overwritten.
 - Press **Path selection**. The available drives are displayed.
 - Select **E:**.
 - Press **Save**. The window closes again.

The drive only needs to be configured once and then remains saved for further installations.

5. Mark the entry **KR C4 Profibus-CP5614** and click on **Install**. Answer the request for confirmation with **Yes**.
6. Confirm the reboot prompt with **OK**.
7. Remove the stick.
8. Reboot the robot controller.

LOG file A LOG file is created under C:\KRC\ROBOTER\LOG.

4.4 Uninstalling PROFIBUS CP 5614



It is advisable to archive all relevant data before uninstalling a software package.

Precondition ■ “Expert” user group


Procedure

1. In the main menu, select **Start-up > Install additional software**.
2. Mark the entry **KR C4 Profibus-CP5614** and click on **Uninstall**. Reply to the request for confirmation with **Yes**. Uninstallation is prepared.
3. Reboot the robot controller. Uninstallation is resumed and completed.


LOG file A LOG file is created under C:\KRC\ROBOTER\LOG.

5 Configuration

5.1 Overview

 If the CP 5614 A2 is operated exclusively as a slave, steps 1 to 3 can be skipped.

Step	Description
1	Configure PROFIBUS with Step 7 or NCM. (>>> 5.2 "Configuring PROFIBUS with Step 7 or NCM" Page 13)
2	Export the bus configuration and LDB file from Step 7 or NCM. (>>> 5.3 "Exporting the bus configuration and LDB file from Step 7 or NCM" Page 14)
3	Import the bus configuration and LDB file into WorkVisual. (>>> 5.4 "Importing the bus configuration and LDB file into WorkVisual" Page 14)
4	Configure the drivers for the master and slave part of the CP 5614 A2 in WorkVisual. (>>> 5.5 "Configuring the driver for the master part of the CP 5614 A2 in WorkVisual" Page 15) (>>> 5.6 "Configuring the driver for the slave part of the CP 5614 A2 in WorkVisual" Page 17)
5	Map the inputs and outputs in WorkVisual. (>>> 5.7 "Mapping inputs/outputs in WorkVisual" Page 18)
6	Transfer the bus configuration from WorkVisual to the robot controller.
7	Reconfigure the PROFIBUS driver or reboot the controller.

 Information about procedures in WorkVisual is contained in the WorkVisual documentation.

5.2 Configuring PROFIBUS with Step 7 or NCM

Procedure

1. Create a new project in the Simatic Manager.
2. Right-click in the empty space and select **Insert New Object > SIMATIC PC-Station** from the context menu.
3. Enter a name for the PC station.
4. Right-click on the PC station and select **Open Object**.
The program HW Config opens. The virtual PC is displayed.
5. Right-click on slot 1 and select **Insert Object... > CP Profibus > CP 5614 A2 > Firmware 6.2** from the context menu.
6. Select a PROFIBUS number for the bus configuration and create a new PROFIBUS network. The card is inserted.
7. Right-click on slot 2 and select **Insert Object... > User Application > Application > SW V6.3** from the context menu. The application is inserted.
8. Right-click on **CP 5614 A2** and select **Add Master System** from the context menu.

9. Select the application and confirm with **OK**. The master system of the PROFIBUS master is displayed.
10. Add all the PROFIBUS devices to the master system.
11. In HW Config, right-click on **CP 5614 A2** and select **Object Properties...** from the context menu.
12. On the **Operating Mode** tab, activate the **Create LDB file** check box.
13. Via **Browse...**, specify the directory in which the LDB file is to be created and confirm the selection with **OK**.

Supported baud rates

The following baud rates are supported for operation of the master ring:

- 19.2 kbaud
- 45.45 kbaud
- 93.75 kbaud
- 187.5 kbaud
- 500 kbaud
- 1.5 MBaud
- 3 MBaud
- 6 MBaud
- 12 MBaud

The following baud rates are supported for operation of the slave ring:

- 9.6 kbaud
- 19.2 kbaud
- 45.45 kbaud
- 93.75 kbaud
- 187.5 kbaud
- 500 kbaud
- 1.5 MBaud
- 3 MBaud
- 6 MBaud

5.3 Exporting the bus configuration and LDB file from Step 7 or NCM

Procedure

1. In HW Config, select **Station > Export**.
2. Activate the check boxes **Export default values**, **Export symbols** and **Export subnets**.
3. Activate the radiobox **Readable**.
4. Confirm with **Save**.
The CFG file is generated.



The LDB file is located in the directory that was selected during creation of the LDB file.

5.4 Importing the bus configuration and LDB file into WorkVisual

Precondition

- A project is open.
- A robot controller has been added and set as active.

Procedure

1. Select the menu sequence **File > Import / Export**.
The **Import/Export Wizard** window is opened.
2. Select **Profibus CP 5614 Import** and click on **Next >**.

3. Click on **Browse...** and specify a directory.
4. Confirm with **Next >**.
5. Click on **Finish**.
The LDB and CFG files are imported.
6. Close the **Import/Export Wizard** window.



It is possible to reimport a configuration. The Profibus address is used for the comparison between the existing and the newly imported configuration. In the case of a reimport, it is always the data in the CFG file that are relevant:

- If a device is contained in the CFG file but not in WorkVisual, the device will be created in WorkVisual.
- If a device is contained in WorkVisual but not in the CFG file, the device and its I/O mappings will be deleted in WorkVisual.
- If a device is contained in the CFG file and in WorkVisual, the device name will be taken from the CFG file and the I/O mappings will be retained.

5.5 Configuring the driver for the master part of the CP 5614 A2 in WorkVisual

- Precondition**
- The bus configuration and the LDB file have been imported into WorkVisual.
 - The robot controller has been set as the active controller.

- Procedure**
1. Expand the tree structure of the robot controller on the **Hardware** tab in the **Project structure** window.
 2. Right-click on **CP 5614 A2** in the tree structure and select **Settings...** from the context menu.
 3. A window opens. Select the **Master settings** tab.
(>>> 5.5.1 "Master settings" tab" Page 15)
 4. Set the data as required and save with **OK**.
 5. Right-click on the device in the tree structure and select **Settings...** from the context menu. A window with device settings is displayed.
(>>> 5.5.2 "Device settings" tab" Page 16)
 6. Set the data as required and save with **OK**.

5.5.1 "Master settings" tab




Fig. 5-1: "Master settings" tab

Box	Description
Activate Profibus master	<ul style="list-style-type: none"> ■ Activated: Master ring of the CP 5614 A2 is used in I/O mode. ■ Deactivated: Master ring of the CP 5614 A2 is not used.
Watchdog time	<p>The CP 5614 A2 checks internally whether the cycle time for I/O data exchange can be adhered to. The value should only be changed if necessary.</p> <p>Default value: 30 ms</p> <p>Note: Only values ≥ 30 ms can be entered. The value entered must be divisible by 10. If a value is entered that is not divisible by 10, the value is rounded down automatically on closing.</p>
Reset outputs in the event of an error	<ul style="list-style-type: none"> ■ Activated: The outputs of all slaves are set to zero in the event of a communication error of a slave in the master ring. ■ Deactivated: A communication error of a slave in the master ring has no effect on the outputs of the other slaves.
Wait for all slaves	<ul style="list-style-type: none"> ■ Activated: On booting, the master ring waits approx. 5 seconds for the connected slaves to reach the READY work mode. If a slave has not yet reached the READY work mode after this time, a communication error is output. ■ Deactivated: On booting, the master ring starts cyclical data exchange immediately. If a slave has not yet reached the READY work mode, a communication error is output. <p>Note: It is recommended to activate the check box, as the master ring often boots more quickly than the slaves.</p>

5.5.2 “Device settings” tab

Device settings

Device name: B-8DI/8DO DP

Profibus address: 6

Always present

Fig. 5-2: “Device settings” tab

Box	Description
Device name	Enter the name of the device (optional). Note: By default, the name of the device type from the Step 7 configuration is entered here; this can be changed. The name can have a maximum length of 32 characters.
Profibus address	Address of the device in accordance with the PROFIBUS configuration. This is taken from the CFG file during import and cannot be changed.
Is Active	<ul style="list-style-type: none"> ■ Activated: The robot controller expects the device to be active when the controller boots up. If the device is not active, the robot controller issues an error message. ■ Deactivated: The robot controller does not expect the device to be active when the controller boots up.

5.6 Configuring the driver for the slave part of the CP 5614 A2 in WorkVisual

Precondition ■ A robot controller has been added and set as active.

- Procedure**
1. Expand the tree structure of the robot controller on the **Hardware** tab in the **Project structure** window.
 2. Right-click on **Bus structure** and select **Add...** from the context menu.
 3. A window opens. Select the entry **CP 5614 A2** in the **Name** column and confirm with **OK**. The entry is inserted in the tree structure.
 4. Right-click on **CP 5614 A2** in the tree structure and select **Settings...** from the context menu.
 5. A window opens. Select the **Slave settings** tab.
(>>> 5.6.1 "“Slave settings” tab" Page 17)
 6. Activate the check box **Activate Profibus slave**.
 7. Set the remaining data as required and save with **OK**.

5.6.1 “Slave settings” tab




Fig. 5-3: “Slave settings” tab

Box	Description
Activate Profibus slave	<ul style="list-style-type: none"> ■ Activated: Slave ring of the CP 5614 A2 is used for I/O data exchange with a higher-level slave. ■ Deactivated: Slave ring of the CP 5614 A2 is not used.
Timeout	<p>The value influences the start-up behavior of the slave ring when establishing communication with the higher-level master.</p> <p>Default value: 0</p> <p>Note: It is advisable not to change this value.</p>
Profibus address	Enter the address assigned to the slave ring of the CP 5614 A2 in the PROFIBUS configuration of the higher-level master.
Error reaction: No stop	<ul style="list-style-type: none"> ■ Activated: Communication errors in the slave ring result in stop-triggering error reactions in the robot controller. ■ Deactivated: Communication errors in the slave ring do not result in stop-triggering error reactions in the robot controller.
Check the configuration data	<ul style="list-style-type: none"> ■ Activated: The configuration settings are additionally checked. ■ Deactivated: The configuration settings are not checked.
Word database	<ul style="list-style-type: none"> ■ Activated: The system checks whether the configured data width corresponds to the database of the slave configuration. ■ Deactivated: No check is carried out.
Check data consistency	<ul style="list-style-type: none"> ■ Activated: The system checks whether data consistency is activated in the database assigned to the slave part by the higher-level master. ■ Deactivated: No check is carried out. <p>Note: This check is only carried out if Check the configuration data is activated.</p>

5.7 Mapping inputs/outputs in WorkVisual

Procedure

- Map the inputs/outputs in WorkVisual.

Signal names

The signal names of PROFIBUS CP 5614 have the following structure in WorkVisual:

Example **001 Input**

I/O	Name	Type	Address
◀	001 Input	BYTE	0
▶	001 Output	BYTE	0
◀	002 Input	BYTE	1
▶	002 Output	BYTE	1
◀	003 Input	BYTE	2
▶	003 Output	BYTE	2

Fig. 5-4: Signal names of PROFIBUS CP 5614 in WorkVisual

Name	Meaning	In the example
Value	Index number (consecutive ascending numbering of the individual inputs/outputs)	001
Input/Output	Direction of processing	Input

6 Operation

6.1 Coupling/decoupling devices

For certain applications, e.g. tool change, it is necessary to couple and decouple devices. Coupling and decoupling can only be carried out via KRL.

Decoupling

Properties of decoupled devices:

- If decoupled devices are disconnected from PROFIBUS or the power supply, no error is triggered.
- All I/O operations on decoupled devices remain without effect.
- Decoupled devices cannot carry out error treatment in the case of read/write errors.

Coupling

The `ioCtl` function is executed synchronously. It only returns when the device is functional and can be written to once again.

If a coupled device is not functional, e.g. because it is disconnected from the bus or supply voltage, a message is displayed after a timeout of 5 s.

Is Active

The option **Is Active** affects the way the robot controller reacts to a decoupled device in the event of a cold start or I/O reconfiguration. **Is Active** can be set on the **Device settings** tab in WorkVisual.

(>>> 5.5.2 "Device settings" tab" Page 16)

	Is Active: Yes	Is Active: No
Device coupled	No error message	No error message
Device decoupled	Error message	No error message

Syntax

```
ret = ioCtl("[bus instance name]", [command code], [Profibus address])
```

Description

[Profibus address]: The Profibus address of a device is displayed in WorkVisual on the **Device settings** tab in the **Profibus address** box.

(>>> 5.5.2 "Device settings" tab" Page 16)

Return values for RET:

Value	Meaning
-1	Device could not be coupled/decoupled.
0	Device successfully coupled/decoupled

Examples

Here, the device with the Profibus address 3 is decoupled.

```
...
Ret = ioCtl("ProfibusMasterInstance",60,3)
...
```

Here, the device with the Profibus address 5 is coupled.

```
...
Ret = ioCtl("ProfibusMasterInstance",50,5)
...
```

Check state

The state of a device can be checked using the command code 1001. Here, the state of the device with the Profibus address 4 is checked:

```
Ret = ioCtl("ProfibusMasterInstance",1001,4)
```

Return values for RET:

Value	Meaning
0	The device is ready.
1	The device is not ready.

7 Diagnosis

7.1 Displaying diagnostic data



The diagnostic data can also be displayed in WorkVisual. Information about procedures in WorkVisual is contained in the WorkVisual documentation.

Procedure

1. Select **Diagnosis > Diagnostic monitor** in the main menu.
2. Select the **Profibustreiber (ProfibusDrv)** module in the **Module** box.
The diagnostic data are displayed for this module.

Description

Name	Description
Internal driver name	Internal name of the driver
Version of driver	Version of the driver and build number
LDB file name	Path and name of the LDB file
CP5614A2 HW version	Hardware version of the CP 5614 A2 card
Profibus master activated	<ul style="list-style-type: none"> ■ YES: The master ring of the card is activated. ■ NO: The master ring of the card is not activated.
Profibus slave activated	<ul style="list-style-type: none"> ■ YES: The slave ring of the card is activated. ■ NO: The slave ring of the card is not activated.
Operating state Master circuit	<ul style="list-style-type: none"> ■ DP_OPERATE: Operational state for I/O mode <p>Note: Other states are not permissible for I/O mode.</p>
Wait for slaves	<ul style="list-style-type: none"> ■ YES: On booting, the master ring waits until the connected slaves are ready. ■ NO: On booting, the master ring does not wait for the connected slaves.
Set output to FALSE on bus error	<ul style="list-style-type: none"> ■ YES: The outputs are set to zero in the event of a communication error. ■ NO: The values of the outputs are not changed in the event of a communication error.
Address of slave circuit	<p>Address of the slave part set in the configuration file.</p> <p>Note: The address must match the Profibus address assigned to the slave ring in the configuration of the higher-level master.</p>
Status of slave circuit	<ul style="list-style-type: none"> ■ DPS_DATA_EX: I/O data are transmitted to the higher-level master. <p>Note: In all other states, no I/O data can be transmitted to the higher-level master.</p>
Status of upper master	<ul style="list-style-type: none"> ■ DP_OPERATE: Data are exchanged with the slave ring of the card. <p>Note: In all other states, no data can be exchanged with the slave ring of the card.</p>

Name	Description
Error reaction on errors in slave circuit	<ul style="list-style-type: none">■ ERROR_REACTION ON: A stop-triggering message is generated on the robot controller in the event of an error in the slave ring.■ ERROR_REACTION OFF: No stop-triggering message is generated on the robot controller in the event of an error in the slave ring.
Data width of configuration	<ul style="list-style-type: none">■ DATABASE DATATYPE WORD: The database has the data width WORD.■ DATABASE DATATYPE BYTE: The database has the data width BYTE.

8 Messages

No. / message text / type	Possible cause	Remedy
2858 <i>Ackn. Stop due to field bus error</i> Stop message	The power or network cable is incorrectly plugged in or defective.	Correctly plug in the power or network cable, or exchange.
	The driver is incorrectly configured or the parameters are incorrectly set.	Check and correct the configuration.
1034 Write error, driver: <i>driver name</i> Status message	The power or network cable is incorrectly plugged in or defective.	Correctly plug in the power or network cable, or exchange.
	The driver is incorrectly configured or the parameters are incorrectly set.	Check and correct the configuration.
10056 <i>Profibus master is in the AUTOCLEAR state. Please execute the RESET command</i> Status message	The master ring is in a non-permissible state.	In the main menu, select Configuration > Inputs/outputs > I/O drivers and click on Reset .
10058 Profibus driver: communication error in module [<i>Profibus address (device name)</i>] Status message	The module is incorrectly plugged in or defective.	Correctly plug in the module, or exchange.
	The module is incorrectly configured.	Check and correct the configuration.
10059 <i>Profibus driver: watchdog error in the master ring</i> Status message	The watchdog time set for monitoring the cyclical communication was exceeded.	Increase the set watchdog time in the configuration.
10060 <i>Profibus driver: communication error in the slave ring</i> Status message	The cabling for the slave ring is incorrectly plugged in or defective.	Correctly plug in the cabling, or exchange.
	The slave ring is incorrectly configured.	Check and correct the configuration.
10069 <i>Profibus master is not in the OPERATE state</i> Status message	The LDB file contains errors.	<ol style="list-style-type: none"> 1. Check and correct the configuration. 2. Create and load a new LDB file.
10070 Profibus slave [<i>device name</i>] could not be activated Status message	The cabling is incorrectly plugged in or defective.	Correctly plug in the cabling, or exchange.
	An incorrect Profibus address was entered during coupling.	Correct the Profibus address and execute the coupling command again.

9 KUKA Service

9.1 Requesting support

Introduction The KUKA Roboter GmbH documentation offers information on operation and provides assistance with troubleshooting. For further assistance, please contact your local KUKA subsidiary.

Information The following information is required for processing a support request:

- Model and serial number of the robot
- Model and serial number of the controller
- Model and serial number of the linear unit (if applicable)
- Version of the KUKA System Software
- Optional software or modifications
- Archive of the software
- Application used
- Any external axes used
- Description of the problem, duration and frequency of the fault

9.2 KUKA Customer Support

Availability KUKA Customer Support is available in many countries. Please do not hesitate to contact us if you have any questions.

Argentina Ruben Costantini S.A. (Agency)
Luis Angel Huergo 13 20
Parque Industrial
2400 San Francisco (CBA)
Argentina
Tel. +54 3564 421033
Fax +54 3564 428877
ventas@costantini-sa.com

Australia Headland Machinery Pty. Ltd.
Victoria (Head Office & Showroom)
95 Highbury Road
Burwood
Victoria 31 25
Australia
Tel. +61 3 9244-3500
Fax +61 3 9244-3501
vic@headland.com.au
www.headland.com.au

Belgium	KUKA Automatisering + Robots N.V. Centrum Zuid 1031 3530 Houthalen Belgium Tel. +32 11 516160 Fax +32 11 526794 info@kuka.be www.kuka.be
Brazil	KUKA Roboter do Brasil Ltda. Avenida Franz Liszt, 80 Parque Novo Mundo Jd. Guançã CEP 02151 900 São Paulo SP Brazil Tel. +55 11 69844900 Fax +55 11 62017883 info@kuka-roboter.com.br
Chile	Robotec S.A. (Agency) Santiago de Chile Chile Tel. +56 2 331-5951 Fax +56 2 331-5952 robotec@robotec.cl www.robotec.cl
China	KUKA Automation Equipment (Shanghai) Co., Ltd. Songjiang Industrial Zone No. 388 Minshen Road 201612 Shanghai China Tel. +86 21 6787-1808 Fax +86 21 6787-1805 info@kuka-sha.com.cn www.kuka.cn
Germany	KUKA Roboter GmbH Zugspitzstr. 140 86165 Augsburg Germany Tel. +49 821 797-4000 Fax +49 821 797-1616 info@kuka-roboter.de www.kuka-roboter.de

France	KUKA Automatismes + Robotique SAS Techvallée 6, Avenue du Parc 91140 Villebon S/Yvette France Tel. +33 1 6931660-0 Fax +33 1 6931660-1 commercial@kuka.fr www.kuka.fr
India	KUKA Robotics India Pvt. Ltd. Office Number-7, German Centre, Level 12, Building No. - 9B DLF Cyber City Phase III 122 002 Gurgaon Haryana India Tel. +91 124 4635774 Fax +91 124 4635773 info@kuka.in www.kuka.in
Italy	KUKA Roboter Italia S.p.A. Via Pavia 9/a - int.6 10098 Rivoli (TO) Italy Tel. +39 011 959-5013 Fax +39 011 959-5141 kuka@kuka.it www.kuka.it
Japan	KUKA Robotics Japan K.K. Daiba Garden City Building 1F 2-3-5 Daiba, Minato-ku Tokyo 135-0091 Japan Tel. +81 3 6380-7311 Fax +81 3 6380-7312 info@kuka.co.jp
Korea	KUKA Robotics Korea Co. Ltd. RIT Center 306, Gyeonggi Technopark 1271-11 Sa 3-dong, Sangnok-gu Ansan City, Gyeonggi Do 426-901 Korea Tel. +82 31 501-1451 Fax +82 31 501-1461 info@kukakorea.com

Malaysia	KUKA Robot Automation Sdn Bhd South East Asia Regional Office No. 24, Jalan TPP 1/10 Taman Industri Puchong 47100 Puchong Selangor Malaysia Tel. +60 3 8061-0613 or -0614 Fax +60 3 8061-7386 info@kuka.com.my
Mexico	KUKA de Mexico S. de R.L. de C.V. Rio San Joaquin #339, Local 5 Colonia Pensil Sur C.P. 11490 Mexico D.F. Mexico Tel. +52 55 5203-8407 Fax +52 55 5203-8148 info@kuka.com.mx
Norway	KUKA Sveiseanlegg + Roboter Sentrumsvegen 5 2867 Hov Norway Tel. +47 61 18 91 30 Fax +47 61 18 62 00 info@kuka.no
Austria	KUKA Roboter Austria GmbH Vertriebsbüro Österreich Regensburger Strasse 9/1 4020 Linz Austria Tel. +43 732 784752 Fax +43 732 793880 office@kuka-roboter.at www.kuka-roboter.at
Poland	KUKA Roboter Austria GmbH Spółka z ograniczoną odpowiedzialnością Oddział w Polsce Ul. Porcelanowa 10 40-246 Katowice Poland Tel. +48 327 30 32 13 or -14 Fax +48 327 30 32 26 ServicePL@kuka-roboter.de

Portugal KUKA Sistemas de Automatización S.A.
Rua do Alto da Guerra n° 50
Armazém 04
2910 011 Setúbal
Portugal
Tel. +351 265 729780
Fax +351 265 729782
kuka@mail.telepac.pt

Russia OOO KUKA Robotics Rus
Webnaja ul. 8A
107143 Moskau
Russia
Tel. +7 495 781-31-20
Fax +7 495 781-31-19
kuka-robotics.ru

Sweden KUKA Svetsanläggningar + Robotar AB
A. Odhners gata 15
421 30 Västra Frölunda
Sweden
Tel. +46 31 7266-200
Fax +46 31 7266-201
info@kuka.se

Switzerland KUKA Roboter Schweiz AG
Industriestr. 9
5432 Neuenhof
Switzerland
Tel. +41 44 74490-90
Fax +41 44 74490-91
info@kuka-roboter.ch
www.kuka-roboter.ch

Spain KUKA Robots IBÉRICA, S.A.
Pol. Industrial
Torrent de la Pastera
Carrer del Bages s/n
08800 Vilanova i la Geltrú (Barcelona)
Spain
Tel. +34 93 8142-353
Fax +34 93 8142-950
Comercial@kuka-e.com
www.kuka-e.com

South Africa	Jendamark Automation LTD (Agency) 76a York Road North End 6000 Port Elizabeth South Africa Tel. +27 41 391 4700 Fax +27 41 373 3869 www.jendamark.co.za
Taiwan	KUKA Robot Automation Taiwan Co., Ltd. No. 249 Pujong Road Jungli City, Taoyuan County 320 Taiwan, R. O. C. Tel. +886 3 4331988 Fax +886 3 4331948 info@kuka.com.tw www.kuka.com.tw
Thailand	KUKA Robot Automation (M)SdnBhd Thailand Office c/o Maccall System Co. Ltd. 49/9-10 Soi Kingkaew 30 Kingkaew Road Tt. Rachatheva, A. Bangpli Samutprakarn 10540 Thailand Tel. +66 2 7502737 Fax +66 2 6612355 atika@ji-net.com www.kuka-roboter.de
Czech Republic	KUKA Roboter Austria GmbH Organisation Tschechien und Slowakei Sezemická 2757/2 193 00 Praha Horní Počernice Czech Republic Tel. +420 22 62 12 27 2 Fax +420 22 62 12 27 0 support@kuka.cz
Hungary	KUKA Robotics Hungaria Kft. Fő út 140 2335 Taksony Hungary Tel. +36 24 501609 Fax +36 24 477031 info@kuka-robotics.hu

USA KUKA Robotics Corp.
22500 Key Drive
Clinton Township
48036
Michigan
USA
Tel. +1 866 8735852
Fax +1 586 5692087
info@kukarobotics.com
www.kukarobotics.com

UK KUKA Automation + Robotics
Hereward Rise
Halesowen
B62 8AN
UK
Tel. +44 121 585-0800
Fax +44 121 585-0900
sales@kuka.co.uk

Index

C

CFG 6
Configuration 13
Coupling, device 21

D

Decoupling, device 21
Diagnosis 23
Diagnostic monitor (menu item) 23
Documentation, industrial robot 5
DP 6

G

GSD 6

I

Installation 11
Installation, PROFIBUS CP 5614 11
Introduction 5

K

KUKA Customer Support 27

L

LDB 6

M

Mapping, inputs/outputs 18
Messages 25

N

NCM 6

O

Operation 21

P

PA 6
PLC 6
Product description 7

S

Safety 9
Safety instructions 5
Service, KUKA Roboter 27
Step 7 6
Support request 27
System requirements 11

T

Target group 5
Trade mark 5

U

Uninstallation, PROFIBUS CP 5614 12

W

Warnings 5

WorkVisual 6

